

# SIEMENS

## SIMATIC NET

**Product Information**      **C79000-Z8964-C37-01**

**Stand / Dated**  
**6 / 98**

---

---

**CP 342-2 AS-Interface for the S7-300 Programmable  
Controller**

---

---

This document contains information in English.

© SIEMENS AG 1998  
Änderungen vorbehalten  
Subject to change  
Sous réserve de modifications  
Con riserva di modifiche

## **Hinweis / Note / Avertissement / Avvertenza /**

### **Achtung**

Vor der Inbetriebnahme Hinweise in der entsprechenden aktuellen Dokumentation beachten. Die Bestelldaten hierfür entnehmen Sie bitte den Katalogen oder wenden Sie sich an Ihre örtliche SIEMENS-Niederlassung. Die Inbetriebnahme ist solange untersagt, bis festgestellt wurde, daß die Maschine, in die diese Komponenten eingebaut werden soll, den Bestimmungen der Richtlinie 89/392/EWG entspricht.

### **Attention**

Prior to startup you must observe the notes in the relevant documentation. For ordering data of the documentation please refer to catalogs or contact your local SIEMENS representative.

Startup must not take place until it is established that the machine, which is to accommodate this component, is in conformity the directive 89/392/EEC.

### **Attention**

Avant la mise en service, respecter les instructions de la documentation actuelle correspondante. Pour les références de commande de la documentation, veuillez-vous reporter aux catalogues ou consulter votre agence locale SIEMENS. La mise en service est interdite tant que la machine dans laquelle est incorporé ce composant n'est pas conforme aux prescriptions de la directive 89/392/CEE.

### **Attenzione**

Prima della messa in funzione, osservare attentamente le avvertenze riportate nella documentazione corrente. Per i dati di ordinazione consultare i cataloghi oppure rivolgersi alla locale filiale SIEMENS. La messa in funzione è vietata fino a quando non è stato accertato che la macchina, in cui il componente deve essere installato, non rispetta le disposizioni della direttiva 89/392/CEE.

**Notes**

This product information contains the latest information about installation and startup. Please make sure that you also read the instructions in the manual accompanying the CP 342-2. The AS-i power supply unit used must provide an extra-low voltage safely isolated from the mains power supply. This isolation can be implemented according to the following requirements:

- VDE 0100 Part 410 = HD 384-4-4 = IEC 364-4-41  
(as functional extra-low voltage with safe isolation)  
or
- VDE 0805 = EN60950 = IEC 950  
(as safety extra-low voltage SELV) or
- VDE 0106 Part 101

## 1 Technical Specifications of the Module

Bus cycle time	5 ms with 31 Slaves
Configuration	Using button on the front panel
Supported AS-i profiles	M0 (without FC "ASI-3422") M1 (with FC "ASI-3422")
AS-i interface connection	Via S7-300 front panel connector Terminal 17-18, 19-20
Address range	16 bytes in the analog area of the S7-300
Power supply	5 V DC via S7 backplane bus
Environmental conditions	
Operating temperature	0 to 60°C
Transport and storage temperature	-40°C to +70°C
Relative humidity	max. 95% at + 25°C
Current consumption	
from 5V	max. 200 mA
from the AS-i cable	max. 100 mA
Design	
Module format	S7-300U format
Dimensions (W x H x D) in mm	40 x 125 x 115
Weight approx.	250 g

## 2 Permitted Slots

**Slots** The CP 342-2 can be used in all slots operated by the S7-300 CPU. The CP is addressed like an analog module with 16 input bytes and 16 output bytes.

**Start Address** The start address of this 16 byte I/O area depends on the slot. The address assignments are as shown below:

Rack 0								
Slot	4	5	6	7	8	9	10	11
CP 342-2 start address	256	272	288	304	320	336	352	368

Rack 1								
Slot	4	5	6	7	8	9	10	11
CP 342-2 start address	384	400	416	432	448	464	480	496

Rack 2								
Slot	4	5	6	7	8	9	10	11
CP 342-2 start address	512	528	544	560	576	592	608	624

Rack 3								
Slot	4	5	6	7	8	9	10	11
CP 342-2 start address	640	656	672	688	704	720	736	752

### 3 Installing the CP

- 👉 **When handling modules, please adhere to the guidelines for handling devices sensitive to electrostatic discharge ESD).**
- 👉 **Components and modules must only be inserted and removed when the power supply is turned off.**

#### Installation

The CP is inserted in any slot of the PLC (see Section 2). It is then secured by the screws in the casing.

The AS-i cable is connected to the terminals of the front connector of the CP. It is connected to terminal pairs 17, 18 or 19, 20 of the front connector. the terminals are connected electrically by the CP 342-2 as follows: 17 with 19 and 18 with 20.

The assignment of the terminal pair and the polarity are labeled on the front panel of the CP. The second terminal pair is intended for connection of the AS-i power supply unit or for a branch of the AS-i cable. The AS-i power supply unit can, however, be connected at any point on the AS-i cable.

- 👉 **Noise immunity/grounding**  
**To ensure that the CP 342-2 is immune to noise, the PLC and the AS-i power supply unit must be correctly grounded.**

## 4 Restrictions when Operating the CP 342-2

Remember the following restrictions when operating the CP 342-2 in the ET200M system:

- Standard operation of the CP (without FC "ASI\_3422") is possible with all IM 153 modules (exception: IM 153 with order number 6ES7 153-1AA00-0XB0)
- Extended operation of the CP (with FC "ASI\_3422") is only approved with the IM 153-2 order number 6ES7153-2AA01-0XB0).
- When reading data record 1 (the "delta list") with SFC "RD\_REC", the error message 80C2 (hex) (module temporarily overloaded) may appear sporadically. In this case, repeat the call in the cyclic program.
- Read and write access is only possible using word or double word access to even I/O addresses.  
**Example:**  
correct: L PIW 288  
wrong: T PQB 288  
wrong: L PIW 291
- The versions of the S7-CPU's listed in the manual no longer apply. The CP 342-2 can only be used with the following CPU versions:

<b>CPU</b>	<b>Order No..</b>	<b>Version</b>
312 IFM	6ES7 312-5AC00-0AB0	from A05
313	6ES7 313-1AD00-0AB0	from A03
314	6ES7 314-1AE01-0AB0	from A06
314 IFM	6ES7 314-5AE00-0AB0	from A01
315	6ES7 315-1AF00-0AB0	from A03
315-2DP	6ES7 315-2AF00-0AB0	from A03
614	6ES7 314-1AH00-0AB3	from A06

## **STEP 7 Configuration of the CP 342-2**

When configuring in STEP 7, you can select the previous module (order no. 6GK7 342-2AH00-0XA0) for the CP 342-2 since the configuration data of the two modules are the same.



## 5 Further Support

**Further Support** If you have questions about using the product and cannot find the answers to your problem in the manuals or in the online help, please contact your local representative or distributor. You can obtain the addresses as follows: in the catalog IK10, in CompuServe (go autforum -> library area SINEC) and on the Internet (<http://www.ad.siemens.de>).

Our hotline is also available for questions:

Tel. +49(911) 895-7000 (Fax -7001)

Our customer support on the Internet provides answers to common questions. Under FAQ (Frequently Asked Questions), you will find information about our range of products.

The AUT home page is in the worldwide web under the following address:

<http://www.ad.siemens.de>.

**Notes on the CE Approval of SIMATIC NET Products**

**Product Name:** CP 342-2 6GK7342-2AH00-0XA0

**EU Directive EMC89/336/EWG** The SIMATIC NET product listed above meets the requirements of the EU directive 89/336/EEC "Electromagnetic Compatibility".



The EU conformity certificates are available for the relevant authorities according to the EU guideline and are kept at the following address:

Siemens Aktiengesellschaft  
Automation and Drives PT2D  
Postfach 4848  
D-90327 Nürnberg  
Federal Republic of Germany

**Area Of Application** The product meets the following requirements:

Area of Application	Requirements in terms of	
	Noise emission	Noise immunity
Industry	EN 50081-2 : 1993	<b>EN 50082-2 : 1995</b>

**Installation Guidelines** The product meets these requirements providing you adhere to the installation instructions described in the following documentation:

1. CP 342-2 Manual
2. SIMATIC S7-300 System Manual  
or the ET 200M Manual

**Notes for the Manufacturers of Machines** The product is not a machine in the sense of the EU directive on machines. There is therefore no conformity certificate for this product in terms of the EU directive on machines 89/392/EEC. If the product is part of the electrical equipment of a machine, the manufacturer of the machine must include the product in the conformity certification process.

