

CC 100 M

# User Handbook

Version

# 104

CC 100 M

# User Handbook

1070 073 401-104 (89.04) GB

(S32)



Reg. Nr. 16149-03

© 1989

by Robert Bosch GmbH,  
All rights reserved, including applications for protective rights.  
Reproduction or handing over to third parties are subject to our written permission.

Discretionary charge 21,30 DM

---

<b>1 DESCRIPTION</b>	<b>Page</b>
<b>Component parts</b>	
General	1-1
Survey of modules	1-2
Operating panel	1-3
Manual panel	1-4
CP/MEM module	1-5
<b>Interfaces</b>	
Data interfaces, general	1-6
Data format	1-7
V.24 cable	1-8
20 mA cable	1-9
20 mA terminal	1-10
<b>Peripherals</b>	
Cassette unit DCR terminal	1-11
Mini cassette unit	1-14
<b>Program Header</b>	
External program production	1-16
General header format	1-17
Program header - example	1-18
Program header in DFS format	1-19
Position, calculation, input and output of the checksum	1-22
<b>2 OPERATING</b>	
<b>Main Modes</b>	
Survey	2-1
Subdivision of VDU display; reset conditions	2-2
<b>Edit</b>	
General	2-3
Program editor and cycles	2-4
<b>Machine</b>	
Manual machine operation	2-5
MDI	2-6
Teach In	2-7
<b>Automatic</b>	
Operating procedure before program/cycle start	2-9
Interruption/re-entry	2-10
Operating procedure after cycle start	2-11
Accessing tables	2-12

<b>Information</b>	<b>Page</b>
General, machine status	2-13
Axes display, PIC/PLC display	2-15
Inch/metric switching	2-18

**Data Handling**

General, load/save	2-20
Load programs/cycles	2-21
Save programs/cycles	2-22
Delete programs/cycles	2-23
Load tools, zero shifts, variables	2-25
Save tools, zero shifts, variables	2-26
Load machine parameters, texts, graphics	2-26
Output logbook data	2-27

**3 PROGRAMMING****General**

Program production, memory allocation	3-1
Memory allocation - programs/cycles	3-2
Part programs and cycles	3-3
Subprograms	3-4
Jump instructions	3-5
Subprogram call-ups	3-5
Parallel programming	3-7
Drip feeding	3-9

**Addresses**

F-address, T-address	3-14
M-address	3-15
S-address, gear ranges	3-16
H-address	3-17
Operator instruction programming	3-18

**Tables**

Tools, zero shifts, variables	3-19
-------------------------------	------

**G-Functions**

Linear interpolation in rapid G0	3-20
Linear interpolation in feed G1	3-21
Circular interpolation G2, G3, G5	3-22
Dwell G4	3-27
Linear interpolation in rapid with extended in position range G6	3-28
Plane selection G17/18/19	3-29
Setting a pole G20	3-30
Conditional subprogram call-up G21	3-32
Subprogram call-up G22	3-33
Conditional jump G23	3-34

---

	Page
Unconditional jump G24	3-35
Field limitation G25/26/27	3-36
Scale factor switching G36	3-37
Programmable mirroring G38/39	3-39
Tool radius compensation G40/41/42	3-41
Zero shift G53, G54 - G59	3-42
In position logic ON/OFF G61/G62	3-43
Feedrate and spindle speed G63/G66	3-44
Effect of feedrate G64/G65	3-45
Contour transitions G68/G69	3-46
Referencing G74	3-47
Measuring probe input G75	3-48
<b>Machining of bores G80 , G81 - G87</b>	<b>3-49</b>
Survey of fixed machining cycle	3-51
Fixed machining cycles G80 - G87	3-52
Drilling G81	3-55
Boring/end facing G82	3-56
Deep hole drilling	3-57
Tapping	3-59
Boring G85	3-61
Reaming G86	3-63
Thread milling G87	3-65
Dimensioning G90/G91	3-67
Setting position stores G92	3-68
Feedrates G93/ G94	3-70
Automatic calculation of cutting speed G96	3-72
Spindle speed, direct G97	3-73
Subprogram end G99	3-74
<b>Three-digit G-codes G800 - G869</b>	<b>3-75</b>
General G890 - G898	3-76
Intersection circle/circle G890	3-78
Intersection line/circle G891	3-79
Rounding corners (3 points) G892	3-80
Rounding corners (2 angles) G893	3-81
Chamfering G894	3-82
Calculate end point of an arc G895	3-83
Transition point arc/arc tangential G896	3-84
Calculate end point of a straight line G897	3-85
Intersection of two straight lines G898	3-86
Survey of firmly allocated cycles	3-87

<b>4 PARAMETRIC FUNCTIONS</b>	Page
<b>General</b>	
Range, programming	4-1
Program planning, aims, use of forms	4-2
Memory allocation form	4-3
Program planning form	4-4
Variable (global) form	4-5
Load function	4-6
Arithmetic functions	4-7
Trigonometric functions	4-9
<b>Tools</b>	
Load tool store	4-10
Copy tool data	4-10
Load/copy zero shifts	4-11
Unconditional branching	4-12
Conditional branching, setting condition register	4-13
Conditional branching/condition register (CR)	4-13
Conditional branching after mathematical comparison	4-15
Branching condition: NC instruction	4-17
Axis information	4-18
Positioning POS	4-19
STV function	4-20
<b>CPC programming examples</b>	
Ellipse	4-22
Row of holes	4-23
Bolt hole circle	4-24
 <b>5 TECHNOLOGY</b>	
Internal processing of tool technology data	5-1
Tool compensation, general	5-2
Tool length compensation T-address	5-3
Tool radius compensation G40/41/42	5-5
Starting point, beginning of contour	5-6
Entry into contour from different starting points	5-7
Contour transitions with G68 (auxiliary arcs)	5-8
Contour transitions with G69 (intersections)	5-9
Examples for G41/42	5-10
End point, cancelling the compensation	5-11
 <b>Special Cases - Tool Compensation</b>	
Change of compensation, switching between G41/G42	5-12
Examples	5-13
Suppression of contour elements	5-14
Cancelling compensation at inside corners	5-14
Outside corners	5-15

---

**6 APPENDIX**

Page

**Programming Code**

G-codes, 2-digit	6-1
G-codes, 3-digit	6-2
M-codes	6-3
Parametric functions	6-4
Axis information, auxiliary functions, subprograms and jumps, special characters, control characters	6-6
ASCII character set	6-7

**Output of Error Messages**

Definition, operating	6-8
Error message group 0	6-9
Error message group 1	6-11
Error message group 2	6-13

**SUBJECT INDEX**




**1. DESCRIPTION**



# CC 100 M

Full CNC continuous path control for up to 4 numerically controlled axes plus controlled main spindle.

Programming based on DIN 66025, extended by graphic and arithmetic functions.



This manual is intended for the use by the enduser of the control.


Component parts of the control, operating elements, maintenance, working with the data interface are described in chapter 1.

Reset conditions, the reference system, operation of the operating panel and the manual panel, and the technology stores are described in chapter 2.

Chapter 3 describes the conventional programming to DIN, 3-digit G-codes and contour cycles.


Parametric functions, user graphic, operation of the tool compensation and special applications are described in chapters 4 - 7.

COMPONENT PARTS




**Operating Panel**

graphic screen, 10", green  
soft keys  
main mode  
input keyboard



**Manual Panel**

handwheel, jog buttons, override switches  
customer keyboard  
reentry / display distance to go  
start / stop / emergency stop button



**Logic Modules:**

**CP/MEM module:**

connections for 2 serial  
data I/O devices, operating  
panel, external VDU, battery  
and software module

**Module PS 75:**

Displays for  
- Ready (green)  
- 24 V (green),  
- internal voltage  
levels ok (green)  
reset button

connections for:


- ready 2
- 24V

**SERVO module:**


connections for  
5 incremental  
measuring systems,  
analogue outputs  
time-critical signals

**P I C module or  
P L C connection**

OPERATING PANEL



OPERATIONAL PANEL



Functions

Override potentiometers:

The feedrate value is set on the potentiometer in %.

The button deactivates the potentiometer (sets value to 100% when the potentiometer is set between 80 and 120%).

The potentiometers can be used in MACHINE and AUTOMATIC modes.

Customer keys:


Effective in MACHINE mode;

Depression of one of the keys in the top two rows triggers an MDI function, which is stored in memory.

Bottom row for direct switching of PLC input signals.



CP/MEM



battery

X11  
25-pole

X12  
25-pole

X21

X22  
20-pole

X10  
4-pole

Overwrite protection switch for machine parameter area.

1 = protected

"Start up" test during the runup phase;  
switch position 1 = test active

Buffer battery for data in RAM.

**The battery must be replaced yearly.**

The battery voltage is checked automatically in a 24 hr cycle and each time the control is switched on. If undervoltage is detected an error is signalled.

With normal battery discharge (no defect on PCB) a further buffer period of at least 14 days is guaranteed after the first error signal.

The CP/MEM incorporates a capacitor for the temporary buffering of the RAM data. If the battery is changed with the control switched off the period for which the supply is interrupted must not exceed 5 min.

To change the battery the battery cover must be opened; the battery is fastened to the cover by means of a mounting.

Battery: 4.5 V alkali battery, part no. 107 - 913 572.

The executive system software is contained on a plug-in PCB (soft-board) under the cover.

To change the software remove the battery cover and withdraw the soft-board. (POWER OFF first!)

### Serial Data Interfaces

Interface 1

V.24 or 20 mA

Desired characteristics selected by pin allocation.

Connector: sub-miniature D-type socket.

Interface 2

V.24

Second voltage interface; can be connected in addition to X 11.

Connector: sub-miniature D-type socket.

Ext. VDU monitor (BAS signals)

Connection for an additional VDU with 75 Ohm.

Connector: BNC socket.

Operating panel connection.

Connection between control system and CC operating panel.

Connector: sub-miniature D-type socket with integral coaxial connector.


External 24 V **logic** DC supply (to supply the VDU in the operating panel)

Connector: Weidmüller terminal strip.

Max. cable size 1.5 mm<sup>2</sup>

## INTERFACES

### INTERFACES, general



The user can connect up to 2 external data terminals at the CP/MEM.

#### **20 mA**

1 device of this type can be connected to X11 (see page 1-5).

This interface is particularly suitable for use where long distances are involved and/or where there is a high level of interference in the surroundings.

With this type of interface one side is active (serves as source of current), the other must be made passive. This is achieved by specific pin allocations in the connections (see page 1-10, 1-11).

#### **V.24**

1 device of this type can be connected to X11 or X12.

This interface allows higher transfer speeds than the TTY interface but is more susceptible to interference.

#### **Control Signals**

**DTR** Data Terminal Ready: Status of readiness to receive data is output (output signal).

**DSR** Data Set Ready: Status of permission to send is recognized (input signal).

**Note:** Switch off handshake by means of a bridge, Pins 4 and 6 at the control side.

#### **Data Lines**

**TX** Data output at the device sending the data.

**RX** Receipt of data at the receiving device.

Make sure not to confuse the plugs when connecting the devices!  
Only connect one device per interface (V.24/20mA) !

**DATA FORMAT**

1 start bit, 7 data bits, 1 stop bit, "even" parity bit  
(1 start bit, 7 data bits, 2 stop bits, "even" parity bit for 110 Bd)


**Control Characters (ASCII)**

DC1 Tape reader ON or input START.  
DC2 Punch ON or output START. Output comes from the controlling device. It starts the transmission.

DC3 Tape reader OFF or input STOP.  
DC4 Punch OFF or output STOP. Output comes from the controlling device. It interrupts (stops) the transmission.


STX Start of text.  
ETX End of text.  
EOT End of transmission.

Sub-miniature D-type connector  
25-pole  
socket on device  
plug on cable




Plug: side for soldering

**Reading in Data**



**Data output**




**V.24 CABLE**

Cable length                   max. 15 m

transfer rate  
max. 9600 Baud, always  
with handshake

Signal levels                   high +3 V to +12 V  
low -3 V to -12 V



Note: X12 interface does not use handshake signals.



20 mA CABLE

Cable lengths:	CC active	max. 15 m
	CC passive	max. 100 m


Baudrates:  
 max. 4800 Bd with handshake  
 max. 300 Bd without handshake

Signal levels:	high	approx. 20 mA
	low	approx. 0 mA

max. external voltage drop 2 V

**CC active**                  The CC serves as source of current:


Pin Allocation



**20 mA TERMINAL**


**CC passive**

The peripheral device serves as source of current.  
Max. admissible voltage drop in the control 2V.  
The supply to the driving device can be up to 24V.



**PERIPHERALS**










**CASSETTE UNIT DCR-TERMINAL**



**GENERAL**


- recording process:  
ECMA 34
- storage capacity:  
256 KB, unformatted
- data format and baudrate  
set on back
- parallel and serial  
interface

**DISPLAYS**





- ?  - device not ready
-   - bad cassette
-   - beginning of recording
-   - end of recording
-   - mains and DCR switched on

**OPERATING ELEMENTS**


- Read (DCR → serial) -
- Write (serial → DCR) -
- Search backwards -



- Read (DCR → parallel)
- fast rewind
- Search forwards



DCR Rear Panel



**Settings:**

1. **CODE:** BIN
2. **BAUDRATE:** C (= 4800 Bd)
3. **PARITY:** EVEN
4. **STOP BIT:** 1 (as in control)
5. Connector for use with CC 100 M is **SERIAL**
6. Cable used: 046266

Explanations:


NETZ EIN/AUS - MAINS ON/OFF

Schalterst. - switch position

Vor Öffnen des Gehäuses Netzstecker ziehen!

- Unplug mains cable before opening the housing !

MINI CASSETTE UNIT




GENERAL

- recording process:  
ECMA 34
- storage capacity:  
20 KB each side
- data format and baudrate  
set on back
- automatic self-diagnosis  
after switch-on with  
"Ready" indicator
- serial interface with  
V24 or 20 mA


DISPLAYS

- Error  error indicator
- Test  ready indicator

OPERATING ELEMENTS



**Rear Panel of MINI CASS**



**Settings:**

1. code:            BIN
2. **MODE:**        4
3. **BAUDRATE:**  7 (= 1200 Baud)
4. cable used:    20 mA - 2.5 m part no. 046266

**Data carrier:**

Digital mini-cassette LDB 400 part no. 910749

Control	Mode	Number of data bits	Parity bit	Start bit	Stop bit	Operating buttons active	Binary data
micro 5/8 CC 100/200/300	4	7	even	1	1	yes	no

**PROGRAM HEADER**

**EXTERNAL PROGRAM PRODUCTION**

The following text explains the methods by which part programs and part program type subprograms (or cycles) are produced.

Such programs are constructed from program language elements to DIN 66025 and can be produced by one of the following methods:

1. via keyboard input, using the program editor in the NC
2. via the manual panel with 'Teach In', in the NC
3. via a programming unit onto a data carrier (paper tape, for instance), outside the NC
4. by computer, outside the NC

Programs produced outside the NC must conform to the NC machine code and the NC syntax.

In addition programs which are input from a data carrier (tape or digital cassette) or via an interface (V24/20 mA) must have a leader (header) and a trailer. Leader and trailer, the beginning of the individual program lines, as well as the program identifications of the header lines of data blocks must be provided in the correct format.

**Note:** When data needs to be transmitted the external data carrier must be activated before the control.





**Program Header - Original Print-out**

Data is output by the control in this format, and the same format must be used when programming data externally (see also previous page).

Tool

```

      IDENTIFICATION AS TOOL DATA
-----TOOL-----1-----
T1   R= 18.0      DR= 0.0      L= 200.0      S= 0.0
T2   R= 0.0      DR= 0.0      L= 0.0       S= 0.0
    
```

Zero Shift

```

      IDENTIFICATION AS ZERO SHIFT
-----ZERO-SHIFT-----2-----
G54  X= 91.20052  Y= 0.0      Z= 55555.0  E= 0.0
G55  X= 0.0      Y= 0.0      Z= 0.0     E= 0.0
    
```

Variable

```

      IDENTIFICATION AS VARIABLE
-----VARIABLE-----3-----
      V1 = 45.0      V2 = 0.707106
    
```

Program

```

      PROGRAM NAME      INCH/METR.      ACCESS LEVEL
      |                 |                 |
-----PROGRAM-----1-----REF-----M-----RWED-----4-----
N 1   G879
N 2   G1 X200 F2000
N 3   M2
N 4   (PROGRAM END)
    
```

Cycle

```

      IDENTIFICATION AS CYCLE
-----CYCLE-----20-----*****-----M-----RWED-----5-----
N 1   G92 X0 Y0
N 2   M21
    
```

- = space character

**Identification Letters**

The access level is identified as follows:

RWED read, write execute, delete permitted

RE read, execute permitted

E execute permitted (cycles only)

**Dimensioning:**

M = metric      I = inch

## PROGRAM HEADER IN DFS FORMAT

The CC 100 program header in DFS format has been designed on the basis of the header format of the cc 200/300, in order to create uniformity in this area for the future. Specific types of files can be loaded and output.

The uniform DFS program header has the following (basic) format:

(DFS \* , \* file type \* file number [ , \* [ file \* ] suffix\* ] , \* access level )

At the positions indicated by an asterisk it is possible to insert one, several or no space character (s).

### Different possibilities

(DFS, Pxx)  
(DFS, Pxx, . suffix)  
(DFS, Pxx, name . suffix)  
(DFS, Pxx, . suffix, RWED)  
(DFS, Pxx, name . suffix, RWED)

### Explanations

#### - DFS

Identification of the program header in DFS format (defined storage).

#### - File type

Specific letters identify the file type:

P = program  
C = cycle  
E = text  
K = compensation table (K0)  
V = zero shift table (V0)  
X = variables (X0)  
L = machine parameters

#### File number

- Program numbers can contain up to 9 digits, cycle numbers up to 2 digits.

#### File name

The file name can contain up to 15 characters, which can be letters as well as numbers. Tables are transferred without name. The file type to be transferred is simply identified as X0, V0 or K0.

**- Suffix**

The suffix consists of one letter and determines the dimensioning method (I = inch/M = metric).  
It is separated from the file name by a decimal point.

**- Access level**

The access level is defined by a 2-character code.  
2-char.: RE (read, execute)  
4-char.: RWED (read, write, execute, delete)

**Note**

Input of file name, suffix and access level is not compulsory.  
They are purely optional .  
If no file name is programmed the suffix can be omitted. The control will then automatically assume the dimensioning to be metric (= suffix M).  
If a file name is stated in the program header the suffix must be entered too.

**Examples of DFS program header for different file types**

- |                              |   |
|------------------------------|---|
| (DFS, P12)                   | - transfer of a single program,<br>program number 12                          |
| (DFS, P10,.M)                | - transfer of a metric program,<br>program number 10                          |
| (DFS, C 4,TOOL CHANGE . I)   | - transfer of the tool change<br>cycle in inch format                         |
| (DFS, P1, TEST RAPID.M,RWED) | - transfer of program P1 with<br>metric dimensions under access<br>level RWED |
| (DFS, X0)                    | - transfer of the variable table  |
| (DFS, K0)                    | " compensation table  |
| (DFS, V0)                    | " zero shift table  |

**Examples:**

(DFS,P 1,TEST RAPID.H,RWED)

(DFS,C 79,.H,RWED)

(DFS,K 0)

(DFS,X 0)

(DFS,V 0)

**OPERATING SEQUENCES FOR OUTPUT AND INPUT**

The files to be **output** are determined via soft key and marked on the screen in reverse video:

- |   |   |
|---|---|
| SELECTED FILE ONLY                                    | - Output if specific file had previously been selected.   |
| PROGRAMS OR CYCLES                                    | - Output if no specific file had previously been selected. Whether programs or cycles are output depends on the file type active at the time. |
| PROGRAMS AND CYCLES                                   | - Selection via soft key.   |
| FILE + TOOLS<br>FILE + ZERO SHIFT<br>FILE + VARIABLES | - Output of a specific file, as well as tool, zero shift or variable file.  |

Files to be **loaded** can be transferred several at a time in any sequence.

If loading via interface is selected in main mode MEMORY a specific number of files can be selected by soft key operation:

ALL FILES	START	PORT NO	BAUDRATE	CONTROL
YES NO				YES NO

How many? (1...99)

- CHECKSUM**
- Whatever the tape format, programs can be output with or without checksum.
  - The DFS program header is output without checksum.
  - In each program block the checksum is inserted directly before the CR LF control character.

**Position, calculation, input/output of the checksum**

**1) Position of the checksum**

At the end of the data and before CR LF, a space, the character ":" and then the checksum value (a 2-digit number) are written.

e.g. N-11- - - G1 CR LF becomes  
 N-11- - - G1-:nn CR LF

- = space
- nn = 2-digit number for the checksum

**2) How to calculate the checksum**

Every character between the LF of the previous line and the ":" is included into the checksum calculation. The ASCII value of each character is added up and multiples of 256 are removed until 255 or less remain, and this remainder is converted into a hexadecimal number.

e.g. N-11- - -G1-:nn CR

CODE	ASCII VALUE
N	78
-	32
1	49
1	49
-	32
-	32
-	32
G	71
1	49
-	32

$456 - 256 = 200 = C8$

The block will now read: N-11- - -G1-:C8 CR LF

**3) Input/output of the checksum**





- INPUT**
- SK "CONTROL YES" active - control checks syntax
  - SK "CONTROL NO" active - control checks the checksum, if it exists, otherwise it checks the syntax
- OUTPUT**
- SK "CHECKSUM YES/NO" is called up via SK "FORMAT".
  - SK "CHECKSUM YES" active - programs are stored **with** checksum
  - SK "CHECKSUM NO" active - programs are stored **without** checksum



**2. OPERATING**

**MAIN MODES**

**SURVEY** The operation of the control is subdivided into the following main modes, which are directly selectable by pushbuttons:

EDIT	MACHINE	AUTOMATIC	INFO
 working with stored data	 manual operation	 execution of programs	 additional information
display input, modification of: programs, subprograms, cycles, tools zero shifts variables  input and output via data interfaces V.24/20 mA  baudrates  automatic generation of header lines for PROGRAM/ CYCLE etc.	direct execution without storage execution of cycles  reference axes, reference cycle, MDI, manual machine, operation, teach in  customer keys handwheel jog buttons  distance to go display	execution of stored programs, cycles  execution continuous/ block by block, variable step size, block selection, break points, reentry  with/without path compensation tool length compensation  CPC test distance to go display  milling conditions	status displays, NC/IO, axis displays, error list  deletion of: programs, variables, tool/zero shift tables  control reset  MTB SERVICE only for machine tool builder  SERVICE load M-parameters  logbook set clock mode read in text

The active main mode is displayed continuously in the top right corner of the screen.

To come out of the current main mode altogether:


Use the page back button to revert through the levels until the 1st soft key level is reached, then select new mode. Exception: For change-over MEMORY/EDIT to AUTOMATIC no paging back required.

To come out of the current main mode temporarily:

Select a different main mode directly. The old main mode is retained in the background (display flashes) and can be reactivated by pressing the relevant mode key once more.



**Subdivision of  
VDU Display**



data blocks:  
  
program  
cycle  
variable table  
zero shift table  
tool table

**Reset  
Conditions**

Immediately after switch-on the following modal conditions are active:

- G1 linear interpolation
- G17 plane X/Y
- G39 programmed mirror image off
- G40 radius compensation off
- G53 no zero offset
- G62 in position operation off
- G65 programmed feedrate applies to cutter centre path
- G66 feedrate and spindle speed can be modified
- G68/ G69 contour transition as arc/intersection (dependent on machine parameter)
- G80 no fixed cycle active
- G90 absolute dimensions
- G94 feedrate in mm/min
- G97 direct spindle speed programming  
scale for factor 1  
no feedrate effective

These modal conditions are active in all main modes.

The G-codes which become active on switch-on are denoted with an "A" in the following descriptions, i.e. G39A.

**Note**

When working in AUTOMATIC or MACHINE mode the control will output the following types of messages, as and when appropriate:

MESSAGE xxx - further operation possible

ERROR xxx - further operation is inhibited

The content of the message can be displayed in INFO mode.

**EDIT**



**Access to Data**

In this main mode all user data can be handled (see EDITOR).

Selectable data blocks:

- tool table
- zero shift table
- variable table
- programs
- cycles

The menu for part programs and cycles can be paged forwards with soft key "NEXT PAGE".

**Access Levels**

Unauthorized accessing of the data can be prevented via softkey operation. Execution is always permitted.

The access levels are expressed as follows:

- RWED read, write, execute and delete are possible
- RE only reading and executing are possible
- E only executing is possible (cycles only)

**Dimensioning**

The dimensions can be selected by soft key to be in metric or inch.

Display in index and in "active datablock" line:

- M metric
- I inch

**Commands**

Under this SK the following functions are available in 2 levels:


- |                               |                   |
|-------------------------------|-------------------|
| - resequence block numbers    | - copy file       |
| - transfer program to a cycle | - file protection |
| - rename a file               | - delete file     |
| - inch/metric                 |                   |

**Data Interfaces**

See chapter on "Data Handling"

**Copy**

Programs stored in the memory can be duplicated with SK function "COPY". The user must enter a new file name and the control will select the file number.



Selection via SK "PROGRAMS" or "CYCLES", program name or number  
SK "EDIT"


The position of the arrow indicates which line is being worked with. This block is repeated in the edit line which contains a cursor (bright rectangle)

**Cursor Functions**


Switch-over between MODIFY/INSERT



Scrolling blocks up/down by simultaneous actuation of



Moving cursor sideways



**Block Selection**

The cursor is placed to the right of the position at which a letter is to be inserted/modified.

**Search Functions**

A characteristic string (sequence of letters, numbers and characters) from the required line is entered, i.e. G41.




**Delete**

- individual character to the left of the cursor



**Line Delete**

- content of the line to the right of the cursor is deleted




**Modify**

- First delete individual character,  
- then key in new character(s)



**Insert**

- enter new character(s)




**MACHINE**



**MANUAL MACHINE OPERATION**

The manual panel is always activated in MACHINE mode.



Recording of elements of a sample contour (see p. 2 - 7)

**MDI**


After SK selection of MDI one block can be executed after the relevant data has been entered. The execution is initiated with the start button.

Under the SK HELP the permanently stored drilling and milling cycles can be selected, parameterized and executed, as well as the user-definable cycles.

REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
----------------	-----------------	-----	----------	-------------

HELP	←		→	CLEAR BLOCK
------	---	--	---	-------------

			BORING CYCLES	CONTOUR CYCLES
--	--	--	---------------	----------------




MTB-specific soft keys (cycles)

**Note:**

- It is not possible to return to previous SK levels while a block/cycle is being executed.
- G41/G42 are not permitted.
- MTB cycle PRIORITY ROUTINE can not be called up.
- Axes which have been driven onto the software limit switches can only be moved by means of the JOG

buttons



in reverse direction.

When working in manual mode the type of traversing movement needs to be defined:

- With the jog buttons the axes can be traversed individually in incremental steps (of 1, 10, 100, 1000 or 10,000 increments). The max. feedrate corresponds to the limit determined by the machine parameter for manual feed (1 - 120,000 mm/min).
- The electronic handwheel can be activated for individual axes.
- Change-over between feed and rapid.

**TEACH IN**

**Definition** By tracking the outline of a sample contour with the machine the specific contour features are recorded by key actuation (soft key RECORD). During this procedure the control stores the position values of all axes. A circular movement is generated by positioning to three points of the circle (soft key CIRCLE COMPUTE).

**MDI function** As in MDI mode blocks can be keyed in. The data is transferred into memory with SK "RECORD".

**Operating**

Main mode MACHINE



REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
----------------	-----------------	-----	----------	-------------

RECORD	←	CIRCLE COMPUTE	→	CLEAR BLOCK
--------	---	----------------	---	-------------

**Function Keys**

RECORD
--------

- Storing positions of moved axes
- Storing entered blocks
- Storing positions of blocks generated internally

CIRCLE COMPUTE
----------------

- Automatic calculation of circles
- The CC 100 calculates circle data from 3 scanned points (SK 'RECORD POINT 1', 'RECORD POINT 2' and 'RECORD POINT 3')
- Circular interpolation G2/G3 is also modal in TEACH IN mode. If a linear movement is to follow G0/G1 must be programmed: Key in G0/G1 before the linear movement and transfer into memory with SK RECORD.

CLEAR BLOCK
-------------

- Clearing blocks which have not yet been stored from the edit line.

**TEACH IN**

**Calculation of  
Circles with  
Parameter R**

The control calculates the radius R from the 3 recorded axis positions and generates the circular contour.

The current axis position is the 1st point for the calculation of the circle.

The display will show the last axis position with the calculated radius.

**Display**

**G2/3 X... Y... R...**

The block is stored with soft key RECORD.

**Note**

- The CC 100 automatically generates a program with the name "TEACH IN".  
If a program with this name is already stored in the memory, this program has the newly entered TEACH IN functions added to it.  
If several independent programs are to be generated via TEACH IN, the old program must first be renamed in EDIT mode with SK RENAME.
  
- Switching of the dimensioning unit INCH/METRIC during TEACH IN operation is not permitted.  
Should it be attempted an error message will be displayed:  
"inch/metric selection incorrect".

**AUTOMATIC**




Execution of programs and/or cycles from memory.

PROGRAM / CYCLE - Selection

The stored cycles and programs are listed in ascending numerical order. The selection is made by entering the name or the number.

**OPERATING PROCEDURE BEFORE START OF PROGRAM/CYCLE**

NORMAL step: no





**AUTOMATIC**

**INTERRUPTION / RE-ENTRY** during program execution

Possibility of external intervention by the operator with tool compensation active / not active, after at least one block has been executed completely:

**Sequence**

a) Cycle stop 

Response of machine and possible actions:  
feed hold is effective

b) Press 

manual mode/MDI are activated

c) Manual intervention


manual panel is active. spindle can be stopped or oriented

movement away from contour for measuring purposes, for instance

d) Tool change with  
- replacement by identical tool  
- replacement by a different tool

old values are retained, input of new tool data is possible (tool wear is set to 0)


**Tool Change**




it is also possible to modify the active block; re-entry onto linear and circular contour elements

e) Drive to suitable position S to start re-entry

**This position must allow direct traversing onto the contour.**(no automatic evasion of obstacles)

f) Press 


control drives back onto the contour, with the tool centre vertical above the beginning of the unfinished contour-program execution is resumed

g) 

**Note:**

- G92 must not be active (see chapter 3)
- If main mode AUTOMATIC is selected between exit and reentry the reentry operation is abandoned and the basic display for main mode AUTOMATIC is displayed. Continuation is possible via reselection of the program and CYCLE START.

**OPERATING PROCEDURE AFTER CYCLE START**



After selection of block or a jump target the previous SK line will appear once more. The breakpoint should then be set.

**TABLES**

DRY RUN RAPID	STEP	SELECT BREAKPOINT	BREAKPOINT	TABLE
------------------	------	----------------------	------------	-------

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--

Zero shifts and variables can be checked, tools can be checked and edited.

**TOOLS**

TOOLS	ZERO SHIFTS	VARIABLES	↓	
-------	----------------	-----------	---	--

Tool data appears in the edit line.

TOOL NUMBER	↓	SCROLL		
----------------	---	--------	--	--

Tool data can be selected directly via their number (+ ENTER) or by cursor control. The cursor is positioned on the DR value (wear). The wear value compensation value can now be updated by an incremental input. Conclude with ENTER (see p. 4 - 1).

**ZERO SHIFTS**

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--

Zero shift data appears in the edit line.

ZERO SHIFT NUMBER	↓	SCROLL	↑	
----------------------	---	--------	---	--

Direct selection via number (+ ENTER) or by cursor control (+ SCROLL).

**VARIABLES**

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--

VARIABLE NUMBER	↓	SCROLL	↑	
--------------------	---	--------	---	--

Operating and function as for zero shifts.


**INFO**



The **INFO** mode is subdivided into two separate sections:

- the machine tool builder section, protected by the MTB code
- the user section.

Within the user section additional information is made available to the operator.



**CC 100M STATUS** - Display of the set modal functions, potentiometers, zero shifts, scale factors, SW limit switches

**I/O STATUS** - Status of the CNC-PIC interface

**MESSAGE LIST** - Display of the last 10 error texts with error number and error location (program, block)

selection

CC 100M STATUS	EXTERNAL STATUS	MESSAGE LIST	AXES DISPLAY	PIC/PLC DISPLAY
-------------------	--------------------	-----------------	-----------------	--------------------

TABLE	LIST			
-------	------	--	--	--

TABLE	LIST	PAGE +	PAGE -	
-------	------	--------	--------	--

Display of machine status conditions, defined by MTB.

(Seperate DNC description in preparation)

**AXES  
DISPLAY**

THE FOLLOWING SOFT KEYS APPEAR:

COMMAND POSITION	LAG	MACHINE POSITION	DISTANCE TO GO	INCH METRIC
---------------------	-----	---------------------	-------------------	----------------

- COMMAND POSITION** - The programmed position is displayed.
- LAG** - The lag, (also called following error), is displayed.
- MACHINE POSITION** - The actual position is displayed as long as there are neither zero shifts nor G92 active. The MACHINE POSITION results from the COMMAND POSITION minus the lag.
- DISTANCE TO GO** - The difference between the programmed command position and the actual position, i.e.the distance to go, is displayed.
- INCH METRIC** - The default setting is metric. The dimensioning system selected with this soft key determines the display in the other main modes; a change-over is however also possible in these modes.

**PIC/PLC  
DISPLAY**

The PIC program is displayed and the following soft keys are offered:

SEARCH	↑	↑	TABLES	TRIGGER
--------	---	---	--------	---------

- SEARCH** With this soft key
- addresses
  - instructions (command + operator)
  - commands (CMD)
  - operators
- can be searched for and displayed, entered either with the full number or part of the number or without the number.


If a string is not found the message STRING NOT FOUND appears in the edit line. If an instruction, a command etc. is not found the NC gives the message NOT FOUND in the edit line.

- SOFT KEYS** - The program display can be scrolled up and down line by line (no repeat function)



**TABLES**

- makes the following soft keys available:



soft keys  
INPUT  
OUTPUT  
TEMP.STORE

- These soft keys are used to select the corresponding data or clear them from the screen. Selected data is marked by highlighting of the corresponding soft key. Data used in the NC-PLC interface are highlighted in the display. Several or all sets of data can be selected simultaneously.


soft keys



- The selected data displayed on the screen can be scrolled up or down line by line (no repeat function).

**TRIGGER**


- makes the following soft keys available:



soft keys  
LOW, HIGH

- The trigger function responds to a low signal or a high signal.

soft keys



- The trigger function responds to a rising or falling edge.

If one of these soft keys is actuated the following soft keys appear:



The selected trigger condition is displayed in the highlighted line at the top of the screen.

The highlighted line at the top of the screen contains the following information:

**STATUS      SIGNAL TYPE      INSTRUCTION      ADDRESS**

**STATUS**

- waiting for  
(signal has not occurred yet)
- triggered  
(signal has occurred)

**SIGNAL TYPE** as selected by soft key

- low level
- high level
- rising edge
- falling edge

**INSTRUCTION** - instruction marked by the cursor in the displayed program

**ADDRESS** - address of the displayed instruction

While the trigger function is switched on it is possible to page through the program. Soft key TRIGGER OFF switches the trigger function off. The purpose of the trigger function is the monitoring of signals which occur intermittently; it is an important aid for fault finding.

**LINES SERVICE SOFTKEY LINE FOR DNC OPERATION**

**Lines service**

PORT SET UP		DNC RESET	STATUS MASK	DNC ON OFF

(separate DNC description in preparation)



**DIMENSIONING - SWITCHING BETWEEN INCH/METRIC**

**MEMORY mode**

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

ACCESS ON/OFF	INCH METRIC	EDIT	LOAD	SAVE
------------------	----------------	------	------	------

TOOLS	ZERO	VARIABLES	PROGRAMS	CYCLES
-------	------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	--------------	--	------	------

e.g. 1 

ENTER
-------

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	--------------	------	------	------

		INCH METRIC		RENAME
--	--	----------------	--	--------

VARIABLES can not be switched to INCH/METRIC.  
Whether the file types, tools and zero shifts are to be effective in metric or inch is determined by soft key.

**Effect:** The file types program and cycles are stored with the dimensioning index I/M. Metric is preset for new files.

**MACHINE mode**

In main mode MACHINE the INCH/METRIC switching is effected in the first soft key line:

REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
-------------------	--------------------	-----	----------	----------------

**Effect:** The selection is effective for all functions in MACHINE mode.  
The selection is retained even after a hardware reset and it also applies after a switch into INFO mode.

**AUTOMATIC mode**

File types such as programs and cycles are already defined with respect to the dimensioning during the generation process. The chosen dimensioning method also applies for the execution.

**INFO mode**

The axis measurement format (INCH/METRIC) selected in INFO mode sets the priority for the axis display in machine mode.

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
-------------------	---------	----------------	------------------	-----------------

CC 100M STATUS	I/O STATUS	MESSAGE LIST	OTHER SELECTION	PIC/PLC DISPLAY
-------------------	---------------	-----------------	--------------------	--------------------

CC 100M STATUS	EXTERNAL STATUS	MESSAGE LIST	AXES DISPLAY	PIC/PLC DISPLAY
-------------------	--------------------	-----------------	-----------------	--------------------

COMMAND POSITION	LAG	MACHINE POSITION	DISTANCE DISPLAY	INCH METRIC
---------------------	-----	---------------------	---------------------	----------------

- The desired dimensioning method is selected for the particular axis display (command/position, machine position, lag, distance to go).
- On switch-on the dimensioning method last active is reactivated.


DATA HANDLING

GENERAL

LOAD / SAVE

The CC100M has two serial data interfaces, the sockets of which are located on the CP/MEM board.

The first interface, which is identified by the control as "Port No. 1", is connected to socket X11. The second interface, identified as "Port No. 2", is connected to socket X12.



Input and output of data is possible in main modes INFO and EDIT. Interface selection and parameterisation are made via soft keys.

In main mode "EDIT" the following types of data can be loaded and saved:

(soft keys:)

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

In "INFO" mode it is possible load machine parameters, M-functions, texts and graphics.

Programs, tools, zero shifts and variables can only be cleared.

**LOAD**

Operating procedure:

- Select main mode EDIT



- Actuate soft keys as shown below:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	-----------	--	------	------

- Optional: Key in program number or name and press "ENTER".

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	-----------	------	------	------

ALL FILES	START	PORT NO	BAUDRATE	CONTROL
YES NO				YES NO

- Soft key "ALL FILES"

"YES" selected: All files on the data carrier are loaded.

"NO" selected: Only the specified number of successive files (number is requested) are loaded.

- Soft key "START": The loading operation is started; the control waits for data. After the initial actuation the soft key changes to "STOP" and can be used to stop the data transfer.

- Soft key "PORT NO": Enter port number 1 or 2. The corresponding interface (X11 or X12) will be activated.

- Soft key "BAUDRATE": Set baudrate. A list of the code numbers for the baudrates appears on the screen. The baudrate set on the control must be the same as the one set on the peripheral.

- Soft key "CONTROL YES/NO":  
With CONTROL YES the syntax is checked.

With CONTROL NO only the checksum is checked, if it exists.


If the program or cycle does not contain checksums the control will carry out a syntax check.

**Note** Under SK "PROGRAMS" it is also possible to load cycles, tool compensations, zero shifts and variables; the same applies for SK "CYCLES". Cycles are loaded in succession, like the programs. When the last program or cycle has been loaded the load operation is stopped. If there are tool, zero shift and variable files on the data carrier loading is stopped after each file, if an EOT signal separates the files. If the subsequent files are to be loaded too SK "START" must be actuated for each one.

**Protection** When loading data via serial interfaces programs are automatically protected against overwriting. If a program is loaded which is already stored in the memory the control will ask whether to

- overwrite the existing program (input 1)
  - store the program under a new number (input 2)
  - abort the loading operation (SK "STOP")
- A program with overwrite protection can not be overwritten.  
Error message: "file protected".

**SAVE** Operating procedure:

- Select main mode EDIT 
- Actuate soft keys as shown below:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE	LOAD		SAVE
--	-----------	------	--	------

- Optional: Key in program or cycle name or number and actuate "ENTER".

ANOTHER SELECTION	START	PORT NO	BAUDRATE	CHECKSUM YES/NO
----------------------	-------	---------	----------	--------------------

The screen displays the message "SELECTED FILE ONLY" (highlighted characters)

- Soft keys "START", "PORT NO" and "BAUDRATE" are operated as for loading.
- Soft key "CHECKSUM" switches the generating of a checksum, which is to be output, on and off.

PROGRAMS + CYCLES	START	FILE + TOOLS	FILE + ZEROSHIFTS	FILE + VARIABLES
----------------------	-------	-----------------	----------------------	---------------------

- Soft key "PROGRAMS + CYCLES" determines whether only either programs or cycles are to be saved, depending on the selection in the first SK line, or whether programs and cycles are to be output. (Display with highlighted characters.)  
The page back button resets the display to "SELECTED FILE ONLY".

- Soft keys "FILE + TOOLS", "FILE + ZEROSHIFTS" and "FILE + VARIABLES". When one of these is selected the corresponding term will be displayed in highlighted characters.

If one of these soft keys is selected the parameters "from" and "to" must be defined. Unless this is done no page back or other selection is possible.

The parameter ranges are as follows:

tools            1 - 48; input e.g.: 1,7,14,15,16, 23, 44  
zero shifts    54 - 59; input e.g.: 54, 57, 58  
variables      1 - 99, A - Z; input e.g. 7, 9,10, 25, 49,A,C,L,X

Only the numbers should be entered, not the associated letter codes. The sequence for the variables is numbers first, then letters.

Output without file selection:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	-------------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	-----------	--	------	------

PROGRAMS + CYCLES	START	PORT NO	BAUDRATE	FORMAT
-------------------	-------	---------	----------	--------

		CHECKSUM YES NO	FORMAT DFS CC100	
--	--	--------------------	---------------------	--

Soft key "PROGRAMS + CYCLES" offers the choice of outputting programs or cycles. Either programs or cycles are preselected, depending on the choice made in the first soft key line.

During the output of programs and cycles the selection of the dimensioning unit "INCH" or "METRIC" is output in the program header.

Main mode INFO



Operating procedure:

- Activate main mode "INFO"
- Continue with soft key operation

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET + DELETE
----------------	---------	-------------	---------------	----------------

DELETE TOOLS	DELETE ZEROSHIFTS	DELETE VARIABLES	DELETE PROGRAMS	CONTROL RESET
-----------------	----------------------	---------------------	--------------------	------------------

The selected soft key is highlighted on the display.  
The delete operation can be aborted with the page back button.

**Caution**

When the "ENTER" key is pressed all programs will be deleted, even those with write protection.

Delete function in main mode EDIT



In main mode "EDIT" programs are deleted individually (or cycles, depending on the soft key selection), and only those without read/write protection can be deleted in this mode.

Operating procedure:

- Select main mode "EDIT"
- Continue with soft key operation:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	-----------	--	------	------

Select program or cycle by name or number.

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	-----------	------	------	------

COMMAND	PROTECTION ON OFF	INCH	DELETE	RENAME
---------	----------------------	------	--------	--------

**Note**

If an attempt is made to delete a program or cycle with read/write protection the message "file protected" will appear on the screen.

In "EDIT" mode it is not possible to delete tool data, variable data and zero shifts.

**TOOLS, ZERO SHIFTS, VARIABLES**

These types of data can be loaded and saved in "EDIT" mode;  
they can only be deleted in "INFO" mode.

**Load**

Main mode EDIT



Soft keys:

TOOLS	ZEROSHIFTS	VARIABLE	PROGRAMS	CYCLES
-------	------------	----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

ACCESS ON/OFF	INCH METRIC	EDIT	LOAD	SAVE
------------------	----------------	------	------	------

The soft key "INCH/METRIC" does not appear for variables.

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--

**Note**

Data can also be loaded under "PROGRAMS" or "CYCLES"  
Write protection is then not effective. The selection of inch or metric made in this way  
is not stored on the data carrier and must be made at the control.



**Save**

TOOLS	ZEROSHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	------------	-----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

	START	PORT NO	BAUDRATE	FORMAT
--	-------	---------	----------	--------


		CHECKSUM YES NO	FORMAT DFS CC100	
--	--	--------------------	---------------------	--

The delete function in "INFO" mode works as described in chapter "Load and save programs and cycles".

**Machine Parameters, Text Strings and Graphics**

In "INFO" mode these types of data can only be loaded.

Operating procedure:

- Select "INFO" mode with  key.
- Continue with soft key operation:

	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
--	---------	----------------	------------------	-----------------

LOAD MACH. PARAMETER	LOGBOOK	SET CLOCK	MODE	LOAD TEXT
-------------------------	---------	--------------	------	--------------

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--


**Note**

During the loading operation the data previously in the memory is overwritten. Enter only the appropriate data under the selected type of data, i.e. do not select soft key "LOAD TEXT" if you have previously selected LOAD MACHINE PARAMETERS.

**Logbook**

If a logbook exists the data can be output in "INFO" mode.

Operating procedure:

- Select main mode "INFO" with  key.
- Continue with soft key operation:

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
-------------------	---------	----------------	------------------	-----------------

LOAD MACH. PARAMETER	LOGBOOK	SET CLOCK	MODE	LOAD TEXT
-------------------------	---------	--------------	------	--------------

ACTIVATE LOGBOOK	LOGBOOK DISPLAY	CLEAR LOGBOOK	SAVE LOGBOOK	
---------------------	--------------------	------------------	-----------------	--

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--

**Note**

If no logbook has been generated the soft key "LOGBOOK DISPLAY" will not be displayed.

### **3. PROGRAMMING**

**GENERAL**

**Program Production**

Part programs can be produced by the following methods:

- directly at the control via panel input in modes EDIT or MACHINE (TEACH IN) or
- at programming stations For transmissions please note the instructions in sections: DATA INTERFACES (chapter 1) Data handling (chapter 2)

**Memory Allocation**

The following types of user data are stored in the control:

Memory areas	Contents
part program memory	part programs and cycles, with the relevant subprograms
technology table	tool geometry and tool wear data, cutting speeds
zero shift table	zero shifts G54 to G59
variable table	CPC variables VI-V99 and VA-VZ
machine parameter memory	machine specific data

**Basic Conditions**


Descriptions in the programming instructions relate to the control as used on a machine tool (milling machine) with a Cartesian axis configuration within a clockwise coordinate system. Unless otherwise stated the following G-functions are assumed to be active:

- G17 plane XY
- G27 no field limitation
- G40/T00 no tool compensation
- G53 no zero shift active
- G62 in position function off
- G90 absolute dimensions

The reset status or the status after switching to automatic mode is indicated by 'A'.

**Possibilities of Program Construction**

**Memory Allocation**



**Explanations**


- Up to 99 subprograms can be assigned to a program or cycle.
- Main programs and their subprograms can call up cycles.
- From within cycles and their subprograms other cycles and subprograms can be called up, up to a 10-fold total nesting depth.
- call-up source

**PART PROGRAMS AND CYCLES**

A program or a cycle describes a sequence of machining operations and is subdivided into blocks. The blocks contain preparatory functions, axis information, miscellaneous and auxiliary functions.

**Block**

A block is made up of the block number and one or several words.



The block length is variable. During external programming the words can be written in any order. The block number must be at the beginning of the block. No space characters required between blocks. But note the gap between the block number and the first word (see transmission protocol, p. 3-4).


**Word**

A word consists of an address letter and a sequence of figures, which represent the address contents.

Only those figures which contain information need be written.

N10 G0 X5.100 Z0.500 M3 T01 or  
N10 G0 X5.1 Z.5 M3 T01

Blocks are built up from individual words which begin with an address letter.



With DIN programming an address may only be programmed once in each block.

**Block Numbers**

The first word of a program block is the block number. It is made up of the address letter "N" (ISO format) and a 1 to 4-digit sequence of figures.

**- sequence**

During **external** program production no block numbers need to be programmed. The control will store data in ascending order.


During **panel input** the control generates the block numbers automatically in the course of the input dialogue.

**- steps**

Block numbers are programmed or generated in steps of 1. If additional blocks are entered via "INSERT" the control will mark these blocks with a "+". The jump addresses remain valid after insertions or deletions since they are marked with symbolic "labels".

The control can store 1 or several user programs. During the programming these programs can be marked as main programs, or subprograms (SBP), or cycles.

**Program** A program is defined by the  
 - HEADER in the first line and  
 - PROGRAM END instruction in the last line.



The header line is generated automatically by the control after call-up of the program or input of the program name.

**Program end** **M2** program end  
**M30** program end - renewed execution with CYCLE START


**Subprogram** Subprograms are of local character; i.e. they are always assigned to a specific program. Subprogram numbers may be used repeatedly as long as they are assigned to different programs.

A subprogram (SBP) is defined by

**\$.** up to 2-digit subprogram number in first line  
**G99** subprogram end in the last line

The subprogram and the main program are stored in the same file.

**Cycle** Cycles are of global character.  
 In other words: Each cycle number may only be used once in the program memory, but can be called up from each program/subprogram or with a direct call-up.



**Cycle end** **M2** cycle end  
 During panel input the headers are generated by soft key selection.

**Jump Instructions**

Program jumps can be used for a more efficient usage of the individual program segments.  
The jump instructions relate to jump addresses (labels) which are to be previously defined. These symbolic addresses are retained even when program alterations are carried out by inserting or deleting blocks.

Programming of

**G24 P x x** (unconditional jump)

or


**G23 P x x** (conditional jump)

P = jump address number

effects branching to a program line which is marked as a jump address:

**\$ x x.**

**Example**



sequence if  
signal **OPTIONAL JUMP** = high:

N10 to N20 / N11 to N20  
sequence if

signal **OPTIONAL JUMP** = low:

N10 to N25 / N11 to N25.

**SBP Call-ups**

The calling up of subprograms must only be possible by programming

**G22 P .. L..** unconditional SBP call-up or

**G21 P... L..** conditional SBP call-up

P = SBP number 1 to 99


L = repetition 0 .... 99

For this reason the subprogram call-ups G21/G22 in the main program must be separated from the subprograms themselves by M2/M30.

One SBP can be called up repeatedly and from different places within the relevant main program.



**Example**



**Decisions**

Subprogram calls or jumps can be linked to a condition, which can be


- the logic state of interface contacts or
- the result of a mathematical comparison (parametric functions)

The jumps or calls are carried out if the stated condition is fulfilled. They are not carried out (and the program is continued at the next line) if the condition is not fulfilled.

**PARALLEL PROGRAMMING**


**Definition** Parallel programming allows the control to be used in EDIT mode while an active program is being executed. In edit mode tool data, zero shift tables, variables and part programs can be entered, edited and output. Active programs and cycles can not be edited in parallel operation.

**PARALLEL PROGRAMMING**



**Functions available in Parallel Operation**

**Tables** TOOL, ZERO SHIFT and VARIABLE tables can be edited, entered and output. Contents of tables which need to be accessed by the active program can not be edited in parallel operation. A possibility does, however, exist to edit table contents during program execution. After the program has been completed the existing table is overwritten with the modifications (updated). The control generates a passive table for this purpose.



**CYCLES**           Cycles can not be edited in parallel operation. But they can be input and output via the serial interface.

**PROGRAMS**       Programs can be edited in parallel operation and can also be input from and output to external data carriers.

The **active** program can **not** be edited.  
There is, however, the possibility of copying the active program in the memory before starting program execution. The copied program can then be edited.

**Soft key**           During AUTOMATIC execution of a program while in parallel  
**TABLES**           operation the soft key TABLES appears.  
Under this soft key it is possible to look at the tables  
TOOLS, ZERO SHIFTS and VARIABLES without having to come  
out of main mode AUTOMATIC.

**DRIP FEEDING**

**DEFINITION** Long programs which do not fit into the program memory can be loaded via interface for direct execution.

**DRIP FEEDING - SINGLE ACTIVATION**

Single drip feeding operation is activated via soft key

DRIP  
FEEDING

IN AUTOMATIC mode (direct selection).

**DRIP FEEDING - CONTINUOUSLY ACTIVE**

If drip feeding is to be activated automatically when AUTOMATIC mode is selected the operator must switch to


ACTIVE ON  
POWER ON

(reverse video) in the 3rd soft key level (INFO mode).


**DRIP FEEDING - USER INTERFACE**

In AUTOMATIC mode the preset parameters for DRIP FEEDING will appear on the display once it is activated.

**Example**



The DRIP FEEDING parameters are preset in INFO mode.  
The parameters do not affect the program which is to be executed.



Main mode INFO

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
-------------------	---------	----------------	------------------	-----------------

	DRIP FEEDING		DNC	
--	-----------------	--	-----	--

ACTIVE ON POWER ON	BUFFER SIZE	PORT NO.	BAUDRATE	BLOCK OFFSET
-----------------------	----------------	----------	----------	-----------------

**Meaning of the DRIP FEEDING parameters**

ACTIVE ON  
POWER ON

If this parameter is active (reverse video) the control defaults to DRIP FEEDING mode when AUTOMATIC is selected.

BUFFER  
SIZE

The BUFFER SIZE parameter determines the buffer size in 0.5 kBytes, which is to be kept free for DRIP FEEDING in the part program memory of the control.

Input format: 512 bytes

Min. buffer size: 1 (= 512 bytes)

Max. buffer size:  $\leq$  max. available memory capacity (see Drip Feeding and main memory)

PORT NO.

Selection of the interface on the CP/MEM

Port 1 - V.24/20 mA (with handshake)

Port 2 - V.24 (with or without handshake)

BAUDRATE

Setting of the baudrate.

The following baudrates are recommended (- 1800 Bd):

- 8 = 1800Bd
- 9 = 2000Bd
- 10 = 2400Bd
- 11 = 3600Bd
- 12 = 4800Bd
- 13 = 7200Bd
- 14 = 9600Bd

**BLOCK  
OFFSET**

This parameter is originally preset so that the program execution begins after 12 program blocks have been loaded (min.).

The setting "n" determines after how many loaded blocks the execution is to begin.

- Possibilities:
- |        |   |
|--------|---|
| n = -1 | execution begins when the buffer is full or when M30/M2 is transferred from the DRIP FEEDING program. |
| n = 0  | Execution begins when 12 program blocks are loaded.   |
| n > 12 | Execution begins when the specified number (n) of program blocks are loaded.                          |

**START POINT?** Input of the block number at which DRIP FEEDING is to start (1 = beginning of the program).  
NC blocks before the start point are ignored.

**Note:** The DRIP FEEDING parameters can only be changed in INFO mode. Port no. and baudrate are independent of the parameters as described in chapter "Data Handling".

### DRIP FEEDING AND MAIN MEMORY

Part programs and cycles occupy a certain area in the part program memory; the remaining available storage capacity is used for DRIP FEEDING.

When the buffer size for DRIP FEEDING has been determined in INFO mode and DRIP FEEDING is activated in AUTOMATIC mode the control checks whether the selected buffer size does not exceed the available storage capacity. If it does an error message will be produced. If the buffer size is not defined the user can utilize the max. available storage capacity.

Input:      available storage capacity      (see basis display  
                                 512                                  in AUTOMATIC)

If the available storage capacity is not sufficient there are two possibilities:

- deletion of individual programs or cycles to increase the available storage capacity
- reduce the buffer size in INFO mode

### PROGRAM EXECUTION WITH DRIP FEEDING AFTER CYCLE START

The DRIP FEEDING operation is started with Cycle Start.

During program execution only the active block is displayed on the screen.

DRY RUN RAPID	STEP	LIST		TABLE
------------------	------	------	--	-------

By actuating SK LIST the 6 blocks following the active block can be listed.

Program execution is possible with the following options:

- step size in program
- rapid / dry run of the program
- starting the program at a set start point (block N)

### **Recommendations for achieving fast data input with drip feeding**

- When the control has "some time" (e.g. long traversing path, G4 active, or FEED HOLD active) it loads data into the buffer. It is therefore advantageous to choose the buffer to be as large as possible. The control is then able to "live" on data from the buffer for those program parts where the block cycle time is critical. In this case the loading of new blocks is inhibited until only the minimum number of blocks are in the buffer. The block cycle time will then be the same as when working from memory.

- Drip feeding and checksum:

Drip feeding programs should be transferred to the control with checksum in order to increase the speed of the transmission. Also the baudrate should not be below 1800.

### **Position and calculation of the checksum**

(see program header in DFS format, page 1-22)

### **Restrictions**

- Jumps, subprograms and the setting of stop points are not permitted in DRIP FEEDING programs;

- Parallel programming is not possible since there are several functions active simultaneously during DRIP FEEDING:

- automatic program execution

- block processing

- transfer function from external data carrier (LOAD, SAVE)

- The REENTRY function is not possible.



---

**ADDRESSES**

**ADDRESS F**

G1 F.. F defines the path feedrate in mm/min.  
G2 F..  
G3 F..  
G5 F..

**G04 F..** F takes effect as dwell in seconds.

**G93 F..** F takes effect as execution time for the programmed path section in seconds.

**G94 F..** F takes effect as feedrate in mm/min. G94 is active on switch-on.


Programmable range: F0.001 to F 50 000

**G95 F..** F takes effect as feedrate in mm/rev.  
The programmed path feedrate is derived from the actual speed of the main spindle.  
G95 is used for tapping and finishing.

CONTROL RESET clears any programmed F-address.

**ADDRESS T**

T determines the tool number, which is to be output, and/or the tool length compensation, which is to be applied internally. T is programmed with 2 or 4 digits.



If T is programmed with only 2 digits these are always interpreted as the compensation group.

The operation of the tool length and tool radius compensation is described in detail under TOOL COMPENSATION, chapter 5.

**ADDRESS M**

**Definition** Output signals can be generated by means of the program.

**Range of M-Functions** The control itself allows all M-codes from M0 to M99 to be used. The user can utilize all M-functions which have a machine function assigned to them.

**Internal** Listed below are a number of codes which have fixed internal functions:

Functions	Code	Internal function	
	M0	Program stop after execution of the block. All other conditions unchanged; does not cause spindle stop. New start with next block number via CYCLE START.	
	M2	Main program end, cycle end, programmed separately system then switches into program selection level <b>Irrespective</b> of the start point selection a new program will start at the beginning.	} machine specific effect
	M3	Spindle rotation, clockwise. A direction of rotation must be active when spindle speeds or gear ranges are programmed.	
	M4	Spindle rotation, counter-clockwise, otherwise as M3.	
	M5	Spindle stop, programmed separately, spindle speed and gear range remain stored internally.	
	M6	Call-up of automatic tool change cycle (cycle 77)	
	M13	Spindle CW coolant on	
	M14	Spindle CCW coolant on	
	M19	Orientation of main spindle to fixed position in degrees. M19 S . . . . : positioning to programmable position. M19 is output at the interface; address S is not	
	M21	Call-up of MTB cycle 76. No output at interface.	
	M22	Call-up of MTB cycle 75. No output at interface.	
	M30	Program end. Mode of operation and other conditions are retained. Change of mode after reset. <b>Dependent</b> on the start point selection a restarted program after M30 will be executed from the selected start point onwards.	
	M40	Automatic gear range selection (Active on switch-on, machine specific operation).	
	M41–	Selection of fixed gear ranges 1 to 4	
	M44	(machine specific operation).	
	M98	SINGLE BLOCK command is not allowed for as long as M98 is active. Programmed in a block of its own.	
	M99	SINGLE BLOCK is possible, i.e. M98 is cancelled. M99 is active on switch-on. Programmed in a block of its own	

**External effects** and further M-functions are particular to each machine and details must be provided by the machine tool builder; for instance: coolant on/off, delivery and removal of workpieces.

---

**ADDRESS S**

- Definition** Programmed on its own the S-address determines the spindle speed, or the position for spindle orientation.
- G92 S . .** When programmed in conjunction with G92 the S-address limits the maximum speed of the main spindle.
- M19 S . .** The spindle is oriented onto the position programmed with S (degrees). If M 19 is programmed on its own the value defined by machine parameter 111 will apply as orientation point (range 00 - 359.999°).
- S . . . . .** Spindle speed in rpm. The direction of rotation (M3/M4) must have been defined.

**SPINDLE SPEEDS**

- Definition** Inputs are evaluated as follows:  
With G 97 S = spindle speed directly in rpm format 4.3  
The direction of rotation must be determined together with the programming of S or beforehand.  
Minimum and maximum speeds are predetermined for the particular machine (M-parameters).

**ADDRESS M GEAR RANGES**

Machines with a gearbox which can be controlled via the CNC can operate in two ways:

- Fixed Selection M41-44** One particular gear range is programmed in the user program with M41 to 44, corresponding to gear ranges 1 to 4:  
The control assists with the change-over between gear ranges by the output of idling speeds, by the processing of signals relating to the gear ranges etc.  
If a speed is programmed which is not achievable within the selected gear range, the control outputs the max. or min. speed possible within that range.
- Automatic Selection M40** When M40 is active the control itself selects the appropriate gear range on the basis of the following criteria:  
- up to 4 gear ranges with min. and max. speed values can be controlled  
- output range for the speed:  
1 to 9999 rpm (MTB can restrict the range for the particular machine)  
- when S is programmed the appropriate gear range is automatically selected, on the basis of the current program data  
- where gear ranges overlap the control selects the lower of any two possible gear ranges (higher motor speed).
- G96 + M40** A new gear range is only selected for the following block if the required speed can not be achieved in the active gear range. Idling speed is output for as long as the activation of the correct gear range has not been acknowledged.

**H-ADDRESS**

**Hxx**  
**Hxxxx**

**Definition**

H-address = "FLYING OUTPUT"

As opposed to the M-address, which is output before each traversing movement, the H-address is output simultaneously with the traversing movement.

This simultaneous output prevents drops in the command value.

**Use**

This function can be used in programs for machining operations during which any momentary stopping of the axes would result in damage to the workpiece (for instance during laser cutting).

This 4-digit auxiliary function permits additional control and switching functions for time-critical applications.

**Programming**

- The H-address should be regarded as an additional auxiliary function; it should not be programmed with other auxiliary functions in the same block.

- The programming format is up to 4-digit.

- Variables can be allocated to the H-address  
(V1 = 1212; H = V1).

**Output**

The H-address is output to the interface in BCD code.  
If the address has 4 digits the last two are output first.

**Note**

H-addresses can also be used for the extension of certain functions (e.g. speed programming in dual spindle operation:  
S1 = 1000 rpm; H = 500 rpm).

### **OPERATOR INSTRUCTION PROGRAMMING**

**Definition**        The operator instruction programming facility allows the display of texts during the program execution. These texts can be purely informative or they can give instructions to the operator. The contents of the texts do not affect the program sequence or machine functions in any way.

**Programming**    The text is programmed in brackets and must be written in a separate block.

**Usage**            This facility can be used to provide documentation for the program. Since the display always shows the next block to be execution while the program is being actioned it is possible to put message up on the screen by programming M0 beforehand.

If a program block is programmed in brackets, i.e. as an operator instruction, it will not be actioned. In this way blocks can be blanked out in a program.


**Example:**

```
.  
.   
.   
N5  
N6  
N7 M0  
N8 (NOTE - SWITCH ON COOLANT  
N9 X... Y...  
N10 X... Y...  
.   
.   
.   
.
```

The program sequence stops in block 7 (due to M0).  
The operator instruction will then be displayed.

**TABLES**

**Tools** Up to 48 tool compensation stores are available.  
Each tool compensation store comprises the following:




Input dimension defined as metric or inch via soft key.

**Example:** \*\*\*\*\*TOOL\*\*\*\*\*1\*\*\*\*\*  
T1 R= 16.0 DR= 0.9 L= 25.0 S= 10.0

\* = space character

**Zero Shifts** 6 zero shifts are available (G54-G59). See under section "G-Functions"  
G53,G54-G59 for definition.

Each zero shift comprises the following:



The dimension is defined as metric or inch via soft key.

**Example:** \*\*ZERO\*SHIFT\*\*\*\*\*2\*\*\*\*\*  
G54 X= 10.0 Y= 20.0 Z= 30.0 E= 40.0

**Variables** A maximum of 125 variables are available for the writing of  
variable programs (V1...V99 and VA...VZ).  
Variables represent numbers of up to 7 digits.

**Example:** \*\*\*VARIABLE\*\*\*\*\*3\*\*\*\*\*  
V1 = 116.0 V2 = 8.0 V3 = 0.6 V4 = -1.0

**Header line:** When programming tool data, zero shifts, variables, programs, cycles  
and (M) parameters externally, identifying HEADERS  
as shown above must be provided. These **must** be written in  
a specific format which is explained on page 1-17.

**G - FUNCTIONS**

**LINEAR INTERPOLATION IN RAPID**

**G0**

**Definition** The axes travel to the programmed position with linear interpolation. The speed is determined by machine parameter.

**Feedrate** No feedrate should be programmed (address F). The machine parameter values for rapid will become effective.

**Interaction** This mode remains modal until a different mode of motion is selected. G0 cancels modes G1, 2, 3 and 5.

Execution of the next block is not started until all axes are "IN POSITION". THE IN POSITION range is defined by machine parameter.

Positioning with G0 is possible when the main spindle is stopped.


**Programming** **G0 X..... Y ..... Z..... E .....**  
Programmable with or without axis addresses.

**Path** The traversing movement is linear even if the distances for the individual axes are different, or if the axes have different rapid speeds. The override potentiometer can be deactivated for G0 and AUTOMATIC by machine parameter.

**Example**

```
N1 G0
N2     X 100     Y 100 (starting position A)
N3 G0 X500     Y 300 (end position B)
N4 M30
```

Resulting movement with different distances in two axes:



**Speeds** The axis which has the longest distance to cover traverses at maximum speed. The speeds of other axes are regulated in such a way that all axes reach the programmed position simultaneously.

**Note - G0 slope:** Axis acceleration and deceleration during rapid traverse are controlled by means of a command ramp. The constant acceleration parameters are programmed for the different axes via machine parameters (see Connections manual, Chapter 4). This does not apply to the 4th axis if it is defined as a Hirth axis.

**LINEAR INTERPOLATION IN FEED**

**G1 A** (A = active on switch-on)

**Definition** The axes traverse to the programmed point in a straight line at the active feedrate (F-word).  
The movement is coordinated in such a way that all involved axes (up to 4 axes: X, Y, Z, E) reach the programmed point simultaneously.

**Feedrate** The programmed feedrate value (F) takes effect as the path feedrate; this means that if several axes are involved in the movement the portion of each individual axis is smaller than F.

The speed can be influenced via the feedrate override potentiometer. If X, Y, Z and a rotary axis (E) are to traverse together, an angular velocity is calculated for E. It is therefore advisable to use time programming G93 for movements involving both linear and rotary axes (see G2, G3, G5).


**Interactions** G1 cancels G0, 2, 3, 5 and is modal, as is the programmed feedrate (main address F).

**Programming** **G1 X... Y... Z... E... (F...)**

G1 can be programmed with or without axis information. It must be programmed together with an F-word if no F-word is active yet. Once a feedrate is programmed it remains effective until it is overwritten by a new value. (Servo Error or switching off cancels the modal feedrate). The programming of "F0" is not admissible.

**Example**

```
N1 G1 X50 Y30 F1000 (feedrate 1000 mm/min)
N2 X30 Y20
N3 M30
```





**CIRCULAR INTERPOLATION**

**G2, G3, G5**

**Definition** The axes traverse to the programmed point at the active feedrate on a circular or helical path.  
The movement is coordinated in such a way that all involved axes reach the programmed point simultaneously.  
Circles can only lie in parallel with one of the planes generated by two of the coordinate axes.

**Feedrate** There must already be a feedrate active, or a feedrate must be programmed in the same block.

The following functions, are possible:


- G64 / G65 feedrate applies to the contour / tool centre
- G93 programming in time segments
- G94 programming in mm/min
- G95 programming in mm/rev

The achievable feedrate can be limited by the ratio between the feedrate and the contour radius, as well as the programmed distance. See F-address.  
The max. feedrate is determined by machine parameter.

**Interactions** G0/1/2/3/5 cancel each other.

- Entry into Circle**
- G5 X... Y... tangential entry, automatic calculation of the radius
  - G2/G3 X... Y... R... any type of entry with programming of the radius
  - G2/G3 X... Y... I... J... any type of entry with programming of the centre of the circle

**Direction of Rotation**



Any size of arc can be defined. Full circles can be programmed using I,J,K. The centre coordinates are always necessary for full circle programming.

**Exit from the Circle** There are no restrictions regarding the exit from a circular contour

**CIRCULAR INTERPOLATION WITH ANY TYPE OF ENTRY INTO THE CIRCLE**

**G2/G3 with R**

**Programming**    **G2 X.... Y.... R.... (X/Y plane)**


**Entry into the Arc**    If the radius is defined during the programming any entry into the arc can be realized.

**Radius R**    The radius is programmed by the R-address with sign.  
Maximum input value: 100 m.  
**Negative sign:** arc smaller than a semicircle.  
**No sign:** arc larger than a semicircle.  
(see examples)

**Definition of the Arc**    Given the same starting and end points and radius 4 different arcs are possible.


These are distinguished by determining the direction of rotation and the sign of the radius as follows:

**Examples    G2 clockwise**



**Programming:**  
N1 G0 X0 Y0 (point P1)  
N2 G2 X0 Y-20 R22 F1000  
(broken line circle)  
or  
N2 G2 X0 Y-20 R-22 F1000  
(continuous line circle)  
N3 M30

**G3 counter-clockwise**



**Programming:**  
N1 G0 X0 Y0  
N2 G3 X0 Y-20 R22 F1000  
(broken line circle)  
or  
N2 G3 X0 Y-20 R-22 F1000  
(continuous line circle)  
N3 M30

**Note**    No programming of full circles possible with R.

**CIRCULAR INTERPOLATION WITH ANY TYPE OF ENTRY INTO THE CIRCLE**

**G2/G3 with I, J, K**

**Programming**    **G2 X.... Y....**        **I....J....**        **(X/Y plane)**  
                          **G2 X.... Z....**        **I....K....**        **(X/Z plane)**  
                          **G2 Y.... Z....**        **J....K....**        **(Y/Z plane)**


**Entry into the Arc**        If the position of the centre of the circle is defined with I, J, (K) any type of entry onto the circular contour can be realized, as well as full circles.

NOTE: If I, J or K = 0 then this value need not be entered into the program.

**Parameters of the Centre of the Circle**    The position of the centre of the circle is determined by I, J and K.  
 I, J and K are modal in effect.  
 X/Y,Z, as well as I, J and K are programmed in absolute or incremental dimensions.

	<b>G90 absolute dimensions</b>	<b>G91 distances to existing position</b>
<b>I</b>	X position of centre, absolute	distance in X-direction $(X_M - X_A)$
<b>J</b>	Y position of centre, absolute	distance in Y-direction $(Y_M - Y_A)$
<b>K</b>	Z position of centre, absolute	distance in Z-direction $(Z_M - Z_A)$

**Example**        starting point = A, end point B, centre of circle M



Calculation of centre:  
 $I = X_M - X_A = 0$   
 $J = Y_M - Y_A = -100 - 0 = -100$

Programming with G90:  
 N1 G1 X-40 Y-20 F1000 (S)  
 N2 X0 Y0 (A)  
 N3 G2 X100 Y-100 J-100 (B)  
 N4 G1 X100 Y-120 (E)  
 N5 M30  
 (G90 active on switch-on)

Programming with G91:  
 N1 G1 X-40 Y-20 F 1000 (S)  
 N2 G91  
 N3 X40 Y20 (A)  
 N4 G2 X100 Y-100 J-100 (B)  
 N5 G1 X0 Y-20 (E)  
 N6 M30

**CIRCULAR INTERPOLATION**


**G2/G3**

**Examples  
G90**

Starting point X40 Y60.  
Radius: 40 mm.

A = starting point  
B = end point  
M = centre of circle

**G2**



Calculations:

**Programming with R**


N1 G1 X40 Y60 F1000 (A)  
N2 G2 X80 Y20 R40 (B)  
N3 M30

**Programming with I, J**

N1 G1 X40 Y60 F1000 (A)  
N2 G2 X80 Y20 I80 J60 (B)  
N3 M30

**G3**

Full circle with a radius of 50 mm



A and B are identical  
for a full circle.

The circle must be subdivided  
into 2 parts when programming with R.

**Programming with R**

N1 G0 X30 Y100 (A)  
N2 G3 X80 Y150 R50 (A')  
N3 X30 Y100 R-50 (B)  
N4 M30

**Full circle programming with I, J**

N1 G1 X30 Y100 (A)  
N2 G3 X30 Y100 I80 J100 (B)  
N3 M30

**CIRCULAR INTERPOLATION WITH TANGENTIAL ENTRY**


**G5**

**Programming** G5 X.... Y....


**Entry into the Arc** When G5 is programmed the control will calculate a tangential entry into the circular contour. No radius is programmed. Only those contour transitions are considered tangential which do not involve a reversal of direction. The control calculates the size and the position of the arc as illustrated in the following examples:

When several G5 movements follow one another the 1st entry tangent influences all subsequent contour elements with G5.


**Different End Points**



```
N1 G1 X0 Y70 F200
N2 X50
N3 G5 X110 Y 10
N4 M30
```






```
N1 G1 X0 Y70 F200
N2 X50
N3 G5 Y130 Y100
N4 M30
```



```
N1 G1 X-15 Y40 F200
N2 G2 X50 Y70 R-60
N3 G5 X90 Y120
N4 M30
```

**Different Tangents**



**Restriction** G5 can not be programmed in MDI or as the first block in a part program, since it would not be possible to calculate a tangent.

$T_n$  = tangent                      A = starting point of arc  
 $M_n$  = centre of circle            E = end point of arc

**DWELL**

**G4**

**Definition** The execution of the subsequent blocks is not started until the programmed time has elapsed.

**Operation** G4 only becomes effective in the block in which it is programmed and must be programmed on its own.

Modal conditions are retained.

**Programming** **G4 F . . . .** F in seconds  
 input range 0.01 to 9 999 999.

**Example**

N12	G1	X10	Y100	F150	
N13	<b>G4</b>			<b>F2</b>	2 sec.dwell
N14		Z-60			
N15	<b>G4</b>			<b>F 1.78</b>	1.78 sec. dwell
N16		Z0			
N17	M30				

**LINEAR INTERPOLATION IN RAPID WITH  
EXTENDED IN POSITION RANGE**

**G6**

**Definition**

In interpolation mode the control waits until an In Position range is reached before starting the interpolation for the next block.

G6 corresponds to the G0 function, but with a larger In position range (as a rule).

As opposed to the G0 IN-POS range, which is determined as a constant value in the machine parameters (see MP 49, 69, 89, 109) the IN-POS range of the G6 function is related to the max. rapid feedrate (see MP 35, 55, 75, 95):

$$\text{IN-POS range} = \frac{\text{max. rapid feedrate}}{1000}$$

The **smaller** the max. rapid feedrate determined by the machine parameters the more precise (smaller) is the IN-POS range.

After this range is reached the control stops for a short time before the interpolation for the next block is started. The length of this stop time is determined in a separate machine parameter (MP 23) and applies for all axes.


Reactivation of the "normal" IN-POS range by programming G0, G1, G2, G3 or G5.

**PLANE SELECTION**

- G17 A X/Y plane**
- G18 Z/X plane**
- G19 Y/Z plane**

**Definition** These G-codes are used to determine the working plane. They also influence the operation of functions G2, G3 and G5, of the tool radius compensation and of the tool length compensation.

**Interactions** G17, 18, 19 are modal functions and cancel each other. **The definition of a pole with G20 also effectively makes a plane selection.**



**Programming** A change in the working plane must be programmed before the first circular movement (G2, G3).

A change in the working plane must not be programmed while tool radius or tool length compensation (G41, G42, Txx) is active.

**Plane Selection**

G-code	circular interpolation tool radius comp. positioning plane for standard boring cycles	tool length comp. feed-in axis for standard boring cycles
G17	X/Y plane	Z-axis
G18	Z/X plane	Y-axis
G19	Y/Z plane	X-axis



**SETTING A POLE**

**G20**


**Definition** The pole and the associated plane G17/18/19 are determined by 2 axis addresses, which are programmed together with G20. The pole relates to the active zero point. The setting of the pole does not produce any axis movement.

**Programming with Contour points** are defined by the radius and an angle. The data relates to a pole, **Polar Coordinates** which is to be defined, and a plane. Positions described in this way are converted within the control into command values for standard axes in a Cartesian system.

<b>Terms</b>	<b>Polar plane</b>	Plane defined by 2 cartesian axes within which the polar coordinates lie.
	<b>Pole</b>	Centre of the polar coordinate system. Position of the pole: Without/before G20: on the active program zero point After G20: on the point defined with G20
	<b>Radius D</b>	Program address assigned to the vector length.
	<b>Angle A</b>	Program address assigned to the vector angle. In mathematical terms the angle relates to the active reference plane..
	<b>Reference axis for angle A</b>	The axis in <b>bold print</b> written first in the plane selection.

**G17 XY G18 ZX G19 YZ**

**Operation** The interpolation modes G0, 1, 2, 3, 5 etc. are not affected by this function.



- P = pole
- Xp = distance of the pole from the Cartesian zero point in X
- Yp = distance of the pole from the Cartesian zero point in Y
- A = angle
- D = vector length

Programming:  
G20 X100 Y200

**Example G17** Setting a pole in plane XY (polar plane) at position X = 100 Y = 200


**Effect with G91** Angle A absolute, vector length D incremental.

**POLAR COORDINATES**

**G 20**

**Example**

Machining a row of holes with G81



Program:

```


N1 F1000 S500 M3 T01
N2 G81 VI=80 V2=30

N3 G20 X100 Y200
N4 X100 Y200
N5 A30 D200 (D1)
N6 D400 (D2)
N7 D600 (D3)
N8 D800 (D4)
N9 M30
    
```

P = position of the pole

**Example**

Machining a bolt hole pattern with G81



Programm:

```

N1 F1000 S500 M3 T01
N2 G81 VI=80 V2=30
N3 G20 X400 Y500
N4 X700 Y500 (A)
N5 A45 D300 (B)
N6 X400 Y800 (C)
N7 A135 (D)
N8 A180 (E)
N9 A225 (F)
N10 A270 (G)
N11 A315 (H)
N12 M30
    
```

**CONDITIONAL SUBPROGRAM CALL-UP**

**G21**

**Definition** The subprogram call-up is dependent on the status of I/F signal "CONDITIONAL SUBPROGRAM CALL-UP"  
Any program label (marked with "\$") can be used.

**Operation** The interface signal "CONDITIONAL SUBPROGRAM CALL-UP" must be present at least 3 blocks before the block in which G21 is programmed.

Status of signal "CONDITIONAL SUBPROGRAM CALL-UP":


High The subprogram is carried out.

Low The subprogram is not carried out.

(Next block is executed.)

By using backwards jumps it is possible to produce endless program repetitions, for series production for instance.

Subprogram nesting up to 10 programs deep is possible (nesting: one SBP calls up other subprograms).



MP = main program

SBP = subprogram

Explanation of above example:

All the subprograms are only carried out if signal "CONDITIONAL SUBPROGRAM CALL-UP" is high when block 8 is read in.

**General Format** G21 P . . . L . . .

P = subprogram number ranging from 0 to 99

L = repetition factor (in addition to 1st execution)  
ranging from 1 to 99  
input of L is dispensable

**Programming**

Example: G21 P10 L1

SBP 10 is executed  $(1 + 1) = 2$  times, if the signal is at high level.

G21 must not be used if tool radius compensation is active.

G21 must be programmed on its own.

**SUBPROGRAM CALL-UP**


**G22**

**Definition** Programs which are marked as subprograms are called up with G22  
Any program label (marked "\$") can be used.

**Operation** Subprograms called up with G22 P... (L...) are carried out unconditionally.  
The subprograms of the CC 100 are of local character,  
in other words they are always assigned to a particular main program or cycle.

**Programming** Example: G22 P5 Subprogram 5 is carried out once.

Subprogram nesting up to 10 programs deep is possible  
(nesting: one SBP calls up other subprograms).



MP = main program

SBP = subprogram

Explanation of the above example:

On its own the call-up of SBP 8 in block 44 will produce  
4 program runs (1.execution + 3 repetitions).

The preceding call-up of SBP 7 in block 32, on its own,  
will produce 2 runs of SBP 7.

Total number of	MP	SBP5	SBP2	SBP7	SBP8
program runs:	1	1	1	1+1=2	2x(1+3)=8

**General Format** G22 P... L...

P = subprogram number ranging from 0 to 99

L = repetition factor (in addition to first execution)  
ranging from 1 to 99

input of L is dispensable

G22 must be programmed on its own.

**CONDITIONAL JUMP**

**G23**


**Definition** The jump is only carried out if the interface signal "OPTIONAL JUMP" is present. If this condition is not fulfilled, the subsequent block will be executed.

**Operation** Any programmed label can be used as jump address.  
Program labels are marked with \$.  
The interface signal "OPTIONAL JUMP" must be present at least three blocks before the block in which the jump is programmed.

**Programming** G23 P... P = 1 to 99 for the program label

G23 must always be programmed on its own.  
G23 must not be used while tool radius compensation is active.

**Example** Drilling holes at different positions, depending on the workpiece, if its identification triggers the I/F signal "OPTIONAL JUMP".  
Signal = high Blocks 10-12, 19-24, 16-18 are executed.  
Signal = low Blocks 10 to 18 are executed.



**UNCONDITIONAL JUMP**


**G24**

**Definition** During the execution the program is not continued at the next block but at the program label defined in the jump instruction. The program label is marked with \$.

**Operation** The jump is carried out unconditionally. By programming backwards jumps it is possible to produce endless program repetitions, for series production for instance.

**Programming** General format:  
**G24 P . . . P** for the program label  
 The programming range for P is 1 - 99.  
 A jump must not be programmed together with other instructions in the same block.

**Example** Backwards jump from the main program to the second block.



Explanation of above program:

Program 2 is repeated continually for as long as input "OPTIONAL JUMP" is low. As soon as this signal goes high machining is concluded with blocks 23 and 24.

**FIELD LIMITATION**

<b>SETTING MINIMUM VALUES</b>	<b>G25</b>
<b>SETTING MAXIMUM VALUES</b>	<b>G26</b>
<b>CANCELLING LIMITATION</b>	<b>G27 A</b>

**Definition** The field limitation prevents the axes from being driven into areas where collisions might occur.  
Unlike the limit switches these limitations must be determined separately for each program.

The axes can not position to any point with values  
- **under** those programmed with **G25**  
- **above** those programmed with **G26**

The input of the axis values does not produce any axis movement.


The limitation values relate to the active program zero point.  
Any offset programmed with G92 X... Y... is not considered.

**Operation** The limitation function is modal for all machining modes.  
It takes into account tool radius compensation as well as tool wear.

The field limitation does not become activated until the software limit switches are set and the axes have been referenced.

**Programming** **G25 X... Y... Z... E...**  
The axes must already be positioned within the field of operation.

**Cancelling** The limitations set with G25 and G26 are cancelled by programming G27 X Y Z without numerical values as well as by CONTROL RESET.  
The software limit switches remain valid.



**Example**

N10	G0	X750	Y400	Z300	axes position above workpiece zero point
N11	G92	X0	Y0		clamping position is taken into account
N12	G25	X-550	Y-300	Z-280	lower limit is determined
N13	G26	X150	Y100	Z200	upper limit is determined.
:	part program				
N80	G27	X	Y	Z	limitation is cancelled



**Note** The traversing field limitation set in the machine parameters can not be extended, but only be limited further with G25/G26.

**SCALING FACTOR SWITCHING**

**G 36**

**Definition**

Modification of the scaling factor of the coordinate system.  
 The contour lines of a workpiece are enlarged or reduced in the specified factor area, without having to change the programming of the actual contour lines.  
 The scaling factor always relates to a particular plane (see next page); the two axes of a plane can not be modified separately.



**Format** X.xxxxx (5 digits behind decimal point)

Scaling factor data is accepted in decimal format, for instance:

- X0.2 = 5-fold reduction (corresponds to reciprocal value of 5)
- X5.0 = 5-fold enlargement



**Display**            The defined scaling factors for the different axes can be displayed in main mode INFO under the CC 100M STATUS display.

**Operation**

- G36 always relates to a particular plane.  
 Example: The programming of the scaling factor for X automatically influences X and Y in plane G17.
- G36 is modal and can be reset with CONTROL RESET, G36 X1 (Y, Z, E) to factor 1.  
 A change in plane (G17/18/19) also resets a defined scaling factor. This means that the scaling factor needs to be redefined after each plane selection.
- G36 also operates in the E-axis, if this is defined as a linear axis, whatever working plane is selected.
- Any variables called up in the program are subject to modification according to the scaling factor. The scaled values are, however, not transferred into the variable table or tool table.
- G36 does affect the contents of the zero shift table if it precedes G54-59 in the program.  
 G36 does not affect any preceding zero shifts.
- If G36 is programmed in several blocks they overwrite each other. The block last programmed has highest priority and the programmed scaling factor remains effective until the next change in scaling factor. The scaling by means of the scaling factor is switched off by programming the scaling factor 1.

**Programing**

- G36 can be programmed together with main addresses F, S, T, H, but not with any other G-codes or with M-codes 6, 19, 21, 22 in one block.
- G36 is to be programmed with only one axis of the working plane; for working plane G17 this is either X or Y; axes Z and E can be programmed independently in the same block with a different scaling factor.

**Example**

N1	G0	X0 Y0 Z0	
N2	G17		selection of X/Y plane, clearing all programmed scaling factors
N3	G36	X2	scaling factor for X and Y-axis, 2-fold magnification
N4	G0	Y50	traversing to Y100 mm
N5	G36	X1	switch off scaling
N6	M30		


**PROGRAMMABLE MIRRORING**

**G38** switch on  
**G39A** switch off

**Definition** 1 or 2 specified axis(es) is (are) mirrored within the selected plane.  
**The axes are programmed together with G38.**

**Operation** The programmed workpiece positions are interpreted with inverted sign in the relevant axis. The position values are mirrored around the active zero point. This is the zero point which resulted after any possible setting of the position stores with G92, presets or zero shifts.

**Reference Points**



M = machine zero point  
W = workpiece zero point  
A = clamping zero point (G92)

X' = axis values after zero shift  
Y' = axis values after zero shift

X = X-axis values are mirrored  
Y = Y-axis values are mirrored


**Programming**

N10	G17 (G18/G19)	plane selection
N11	G38 X or Y or Z	(max. 3 axes)
N10	G39	to cancel all mirroring
N11	G39 X (Y) (Z)	selective cancelling of mirroring in particular axes

The axis addresses are always programmed without axis values.

**PROGRAMMABLE MIRRORING**

**Example**  
**Original**  
**Contour**  
**G17**




**G38 / G39**  
subprogram "contour":

```

N21  $1
N22  G0   X500  Y300  Start (S)
N23  G1   X450  F200
N24  X250  F500
N25  G3   X100  Y150  R-150
N26  G1   Y50
N27  X450
N28  Y360                               End (E)
N29  G99
    
```

N10	(G17)		execution in 1st quadrant (I)
N11	(G39)		<b>no mirroring</b>
N12	G22	P1 Y400	program call-up
N13	G38	X	execution in 2nd quadrant (II)
N14	G22	P1 X500	<b>X-values mirrored</b> program call-up
N15	G38	XY	execution in 3rd quadrant (III)
N16	G22	P1 Y400	<b>X and Y-values mirrored</b> program call-up
N17	G38	Y	execution in 4th quadrant (IV)
N18	G22	P1	<b>Y-values mirrored</b>
N19	G39		mirroring cancelled in both axes
N20	M30		

**Operating**  
**Sequence**  
**during**  
**Mirroring**



→ tool path  
for mirroring  
operations

● auxiliary points

**Note**


When the values are mirrored for just one axis the control converts G41 into G42 and G3 into G2 etc. internally. See also examples II and IV. This is not the case when the values for 2 axes are mirrored. See example III.

**TOOL RADIUS COMPENSATION**

**G40 A / G41 / G42**

**Definition**

When carrying out a part program with tool radius compensation the tool is guided along an equidistant parallel to the programmed path. Equidistant = path with a constant distance to the programmed contour. The tool length is taken into account by the call-up of the T-address.



**Interactions**

- G40 Cancellling radius compensation.**  
Active on switch-on, also automatically active when switching into AUTOMATIC mode. G40 must be active at the end of each program.
- G41 Call-up of tool radius compensation to the left of the programmed contour,** viewed in the direction of the path.
- G42 Call-up of tool radius compensation to the right of the programmed contour,** viewed in the direction of the path.

G40/41/42 are modal, exclude one another, and become active with the subsequent traversing movement. G41/G42 can not be used in manual operation.

**Programming**

<b>G41</b>	X...	Y... (T...)	During the phasing in of the compensation, T must either already be active or be programmed
<b>G1</b>	X...	Y... F...	
.	.	.	feedrate, compensation group call-up and cancellation with a positioning movement in the involved axes (XY for G17), which is suitable for phasing in/out the compensation.
.	.	.	
.	.	.	
<b>G40</b>	X... Y...		

For detailed description see TOOL RADIUS COMPENSATION, Chapter 5.

**Note:**

- A block with axis address without traversing movement, because the axes have already positioned, is not allowed with G41/42.

**Safety**

- During the exit from the contour a reversal of direction of the cutter movement must be prevented. The angle under which the cutter moves away must therefore always be smaller than 90°.

**Consideration**

**ZERO SHIFT**

**G53 A cancel zero shift**  
**G54 to G59**  
**activate zero shift**


**Definition** By using zero shifts programs can be carried out in different places without any modification. While a zero shift is active the machine parameters are temporarily overwritten. They can be reactivated simply by programming G53.

**Operation** Up to 6 zero shifts can be stored in the zero shift table.  
For each zero shift up to 1 value each can be stored for X, Y, Z and E.

If G54 is then called up, for instance, the control will shift the zero point to the machine coordinates which were stored under G54. In order to use a zero shift (for instance G54) the zero shift table must already have been loaded with the respective offset data.

**Programming** **G54** on its own this does not produce any axis movement (display changes to programmed position)  
or  
**G54 X.. Y.. Z..** the zero shift already applies to the position programmed in this block

**Example:**



Corresponding zero shift table:

G54 X100 Y100 Z70  
G55 X300 Y100 Z70  
G56 X500 Y100 Z70  
G57 X100 Y450 Z70  
G58 X300 Y450 Z70  
G59 X500 Y450 Z70

This table can be loaded by manual input at the control, via parametric functions, via the serial interface, or via the BCD data bus.

N10 **G54** 1st zero shift active  
N11 G22 P5 call-up of part program

N20 **G59** 6th zero shift active  
N21 G22 P5 call-up of part program  
N22 **G53** machine coordinates apply one more

- Condition**
- No circular interpolation (G2, G3, G5) must follow immediately after an active zero shift. Operation must start or continue with linear interpolation.
  - G36 modifies the contents of the zero shift table if it is written **in front of** G54-59 in the program. G36 only affects subsequent zero shifts.
  - When G92 is cancelled any active zero shifts G54-59 are also reset.

**'IN POSITION' LOGIC ON**  
**'IN POSITION' LOGIC OFF**


**G61**  
**G62 A**

**Definition G61** In interpolation modes G1, 2, 3, 5 the control waits for each block until the 'In Position' window has been reached before it starts with the interpolation for the next block. The width of this window is determined by machine parameter. Once the window has been reached the control stops for a short time before interpolating the next block. The duration of this stop time is determined by a machine parameter.

**Definition G62** When the 'In Position' function is switched off the control starts with the interpolation of the next block while the last path section from the previous block is being actioned. This results in a "cutting of corners", but saves time.

**Operation** Functions G61/G62 are modal and cancel one another.

**G62** G62 is effective on switch-on



**Programming** G61, G62 must be programmed at the latest in the block for which they are to be effective.

**Influence of machine parameters**

IN POS time	-	MP23
IN POS range	-	MP49, 69, 89, 109
(see Connections manual for CC100M)		

**Example**

N10	<b>G61</b>			no movement
N11	G1	Y500	F200	interpolation with IN POS
	or			
N10	<b>G62</b>			'IN POS' function off
N11	G1	Y500	F200	
:				
N50	<b>G61</b>	X200		interpolation with IN POS in this block

**FEEDRATE AND SPINDLE SPEED (S) 100%**

**G63**

**FEEDRATE AND SPINDLE SPEED OVERRIDE VIA POT**

**G66 A**

- Definition**      **G66** The position of the relevant override potentiometers on the manual panel affects the commanded values.
- Definition**      **G63** Feedrate and spindle speed are set to 100% of the programmed/entered value, whatever the position of the potentiometers.
- Operation**              G66 is active on switch-on.  
Both functions are modal and exclude one another.
- Override ranges:  
- feedrate    0 to 120% of the programmed value  
- spindle speed 50 to 150% of the programmed value
- Programming**              Can be programmed with other instructions in the same block.
- Application**              The override potentiometers for feedrate and spindle speed can be deactivated by means of programming.
- Note re.**              **G66** The potentiometers take effect even when the maximum feedrate is programmed. If the potentiometer is set to between 100% and 120% the maximum feedrate will be exceeded.

**EFFECT OF FEEDRATE**


**G64 cutting path  
G65 A cutter centre path**

**Definition** The feedrate determined with F relates to the cutting path of the cutter or to the cutter centre path when machining circular contour sections.

**Interactions** G64/65 are modal and exclude one another.

**G65** The control keeps the feedrate along the cutter centre path constant. G65 is active on switch-on and is used for roughing.

**Examples**




- $F_{prog}$  = programmed feedrate
- $F_M$  = feedrate along cutter centre path
- $F_S$  = feedrate along the cutting path
- $F_S = F_{prog}$

**In the example the feedrate effective on the actual contour is lower than the programmed value.**

**G64** The control keeps the feedrate along the cutting path constant. These calculations can only be carried out for arcs G2/3/5 if G41/G42 is active.

**Since the speed can increase considerably on circular contours this function should only be used during finish milling.**



**The effective axis feedrate is higher than the programmed one in the above example.**




**CONTOUR TRANSITIONS**

**G69 intersection  
G68 A\* arc**

**Definition** If tool radius compensation is active the control must create transitions for outside corners. These transitions can either be the intersections of the equidistants or automatically generated arcs. G68/69 are modal and cancel one another.

**Operation** **Arc**  
**G68** Only in conjunction with G41/42 with an angle alpha of between 0° and 180°  
The arc produces a continuous transition, which usually is the best solution technologically and puts less strain on the drives due to the soft transition.




ooo generated automatically

●●● programmed points

**G69** **Intersection**  
Only in conjunction with G41/42 with an angle alpha < 90°.

With angles of  $\geq 90^\circ$  up to 180° the control will produce transitions as if G68 had been selected.



The control can carry out the calculations for intersections much faster than those for arcs; therefore G69 is most suitable for contours which require extremely fast block sequences.

**Programming** G68/G69 without axis information.  
If G68/69 is used while path compensation is active the function must be programmed 3 blocks in advance.

**Function active on switch-on** Either G68 or G69 can be defined as active on switch-on by machine parameter.

\*dependent upon machine parameter


**REFERENCING**

**G74**

**Definition** The axes programmed in the block traverse simultaneously onto the reference point(s) at the feedrate determined by m/c parameter.

Once the reference point has been reached the axis position values are set to machine specific values (machine parameters).

**Example  
X-axis**



**Interactions** G74 cancels zero shifts which were activated with G54 to G59 or G92. No tool compensations must be active during G74. While G74 is carried out all modal conditions are temporarily suppressed.

**Programming** **G 74 X Y Z E**

G74 is programmed in a separate block with just the relevant axis addresses without numerical values.

**Example G74** X and Z traverse to the reference point.

N7 G74 X Z

**Note** Further details on interactions with other functions can be found under

- G25, G26 field limitation
- G53-59 zero shifts
- G92 setting position stores.

**MEASURING PROBE INPUT**

**G75**

**Definition**

The control drives the measuring axes in the direction of the programmed position with linear interpolation (G1). While the axes are traversing the switching condition of the measuring probe is being monitored.

As soon as the signal becomes 1 (probe touching surface to be measured) the control responds as follows:

- it stores the current position values and
- cancels the distance to go and G75.

Once the G75 operation is completed the control automatically retracts the measuring axis to the position at which contact was made.


**Interactions**

G75 is effective only in the block in which it is programmed and automatically sets linear interpolation G1. The control only responds to the closing of the probe contact, and not to the opening of this contact. If the end point programmed with G75 is reached without the probe contact closing the program is interrupted and the error message "probe not triggered" is output.

**Programming**

**G75 X... (and/or Y... / Z... / E... / F...)**

**Example**



The probe is to be used to measure the distance from the two surfaces on the left hand side of the workpiece to the zero point. The axes have been driven to the starting position in a machining program.

N1	G75 X70 F200	traverse towards workpiece until probe is triggered
N2	M0	programmed stop to read position value
N3	G0 X40	reposition for next measuring operation
N4	Y20	
N5	G75 X70	traverse towards workpiece to measure distance to upper surface
N6	G0 X0	
N7	M3	

**Applications**

The following tasks represent some of the applications:

- part recognition
- checking workpiece accuracy
- setting reference point at surface of workpiece
- tool inspection

**Note**

When working with the measuring probe the tool compensations must be switched off, otherwise the following error message will be displayed: "G-code not allowed with cut. or length comp."  
The feedrate should be kept moderate in order to avoid damage to the probe.

**MACHINING OF BORES**

**G80 A Fixed Cycles Off  
G81-87 Fixed Cycles On**

**Usage** The programming of fixed cycles to machine bores is simplified with the cycles described below.

In the course of the programming the user calls up the relevant fixed cycle. Values are entered for the variables; the variables are illustrated in the fixed cycle graphics.

**Conditions** The fixed cycles can not be used while tool radius compensation is active; if necessary the tool radius compensation must be deactivated with G40.


Further conditions:


- F feedrate in mm/min
- S spindle speed
- M3/4 spindle rotation clockwise/counter-clockwise




Movements in the positioning plane are all performed in rapid with IN POS operation. The spindle is switched on with the first positioning movement. The cycles can be used with G90 or G91 for both axis directions of the feed-in axis.



**OPERATION** Fixed cycles G81 - G87 are executed in each traversing block once the programmed position has been reached. The selected function is cancelled by programming G80, M2, M30 or by selecting another cycle.

Call-up of fixed cycles and input of variables:





The selection of the required fixed cycle graphic is made with the  and  keys. When the required cycle is reached (cycle name flashing) the selection is confirmed with . The control will then automatically transfer into the selected fixed cycle level.

The inputs for the different variables in a particular cycle can be confirmed with the keys  .

The cursor will then automatically jump to the next variable.

**Handling of cycles**

(RAM cycles, boring cycles, contour cycles)

See CC100M connections manual.

**SURVEY OF  
FIXED MACHINING CYCLES**

**G80 - 87**

Machining sequence

Type of machining	CODE	Feed- in movement	At depth	Retract movement
drilling	G81	M3 feed	-	rapid M3 active
boring with dwell	G82	M3 feed	dwell	rapid/ feed M3 active
deep hole drilling with swarf removal	G83	M3 (posit. in rapid + feed-in strokes in feed)	- -	swarf removal strokes in rapid M3 active
tapping with tap holder	G84	M3 (M4) feed	M4 (M3) dwell	feed M4(M3) active
boring with spindle orientation	G85	M3 feed	orient- ation, retract in pos- itioning axis	rapid active
reaming	G86	M3 feed	-	feed with stop for measuring M0 M5
thread milling	G87	M3 helical interpolation	retract in pos- itioning axis M5	rapid
cancelling fixed cycles	G80			


**Note**

When editing fixed cycles the control will display the appropriate graphic for the active plane.

**FIXED MACHINING CYCLES**

**G80 - 87**

**Plane Selection** The fixed cycles can be used in the 3 main planes.  
The selection of the interpolation plane determines the following:



Positioning plane	Feed-in axis, positioning level, tool length compensation, workpiece surface, working depth	Code
X, Y	Z	G17
Z, X	Y	G18
Y, Z	X	G19

The setting of a pole with G20 effectively also represents a plane selection.

**FIXED MACHINING CYCLES**

**G80 - 87**

**Programming  
Technique**


Fixed cycles simplify programming by their modal character. Programming is rationalized particularly well if the machining can be described by a machining graphic which can be used repeatedly. Only the different bore positions need then be programmed (see example).

**Machining  
Graphic**

The machining graphic contains the coordinates and data which remain constant.

The call-up of the machining graphic is preceded by the selection of the particular fixed cycle with the required feedrate and spindle speed etc.

**Example  
Machining in Z  
(G17)**



**Call-ups**

	:	G0	M ...	S ...	T ...	
		TCH				tool change
		Z <sub>1</sub>	F <sub>1</sub>	S <sub>1</sub>	M3	preconditions for drilling
G81		<b>G81</b>	V1 to	V4		
		G22 P1				call-up of <b>machining graphic</b>
		M5				
		TCH				
		Z <sub>2</sub>	F <sub>2</sub>	S <sub>2</sub>		precond. for deep hole drilling
G83		<b>G83</b>	V1 to	V6		
		G22 P1				call-up of <b>machining graphic</b>
		M5				
		TCH				
		Z <sub>3</sub>	F <sub>3</sub>	S <sub>3</sub>		precond. for tapping
G84		<b>G84</b>	V1 to	V5		
		G22 P1				call-up of <b>machining graphic</b>
		M5				



**FIXED MACHINING CYCLES**

**G80 - G87**

**Variables V**

The program variables V1 to V6 are used by the fixed machining cycles. The fixed cycles use program variables V1 to V6, i.e. the contents of these parameters are modified by the call-up of a fixed cycle. When calling a fixed cycle all the relevant parameters must be defined. The variables must be programmed in one line together with the G-code for the particular fixed cycle.

**Positions**

Position values in the positioning plane relate to

the active zero point with G90

the previous position with G91

The data V1 to V6 for the feed-in axis are independent of G90/91 and are marked individually as

abs. = absolute values or

inc. = incremental values

**Spindle  
Rotation**

Unless otherwise described for the particular cycle, the main spindle is switched on before the start of the movement in the positioning plane, and it is not stopped automatically after the execution of the cycle.

**Safety**

**Consideration**

**All fixed cycles operate with METRIC dimensions internally.** If a fixed cycle is called up in an INCH program the variables are converted into metric values. After the execution of the cycle the variables will be processed in the program as INCH values.

**DRILLING**

**Definition** Drilling, centering

**Input** G0 --> G1 (and vice versa)  
change-over point  
depth of bore V1 mm abs.  
V2 mm abs.

**Sequence** spindle on

1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height


2 feed-in axis drives to V1 change-over to feed

3 feed-in axis drives to V2 in feed

4 retract to V1 in rapid


```

:
N9 T0101
N10 F500 S250 M3
N11 G81 V1=42 V2=7.5
:
N12 X125 Y175
N13 X128 Y204
N19 G80
:
    
```



tool selection  
preconditions  
call-up of cycle G81  
and definition of variables  
machining positions

cancellation of cycle



**BORING**

**DEFINITION**


Boring or end facing with dwell at the bottom of the bore

**Input**

change-over point  
 G0-G1 V1 mm abs.  
 depth of bore V2 mm abs  
 dwell V3 secs.  
 retract G0: V4 = 0  
 G1 V4 = 1

**Sequence**

- spindle on
- 1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height
- 2 feed-in axis drives to V1; change-over to feed
- 3 feed-in axis drives to V2 in feed
- 4 dwell at bottom of bore for free-cutting
- 5 retract to V1 in rapid or feed




**Example**

```

N9 T0101
N10 F500 S250 M3
N11 G82 V1=42 V2=-5 V3=10 V4=1
N12 X75 Y109
N13 X90 Y122
:
N19 G80
:
    
```

tool selection  
 conditions  
 call-up of cycle G82  
 machining positions  
  
 cancellation of cycle




**DEEP HOLE DRILLING**

**G83**

**Definition** Deep hole drilling in several feed-in movements with retract movements to remove swarf.


**Input**

change-over point	V1 mm abs.
final depth of bore	V2 mm abs.
minimum feed-in	V3 mm inc
depression factor	V4
first feed-in	V5 mm inc.
safety distance	V6 mm inc.



**Sequence**

- 1 spindle on
- 2 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height
- 3 feed-in axis drives to depth 1 ( $V5 \cdot 1$ ) in feed
- 4 in rapid to V1
- 5 back to depth 1 + V6
- 6 in feed to depth 2 ( $V5 \cdot (1 + V4)$ )
- 7 in rapid to V1
- 8 back to depth 2 + V6
- 9 in feed to depth 3 ( $V5 \cdot (1 + V4 + V4^2)$ )
- ect.



**Degression  
Factor**

The degression factor determines the individual feed-in depths for deep hole drilling. At each stage the previous feed-in depth is multiplied by the control with the degression factor in order to establish the next feed-in depth for the deep hole drilling cycle. The final depth is approached directly during the last feed-in movement. If the chosen degression factor or the remaining distance would produce a feed-in of less than V3 this is prevented by a corrected input for the feed-in.


**Example**

```

:
N4 T0101
N5 F500 S250 M3
N6 G83 V1=42 V2=10 V3=4.5 V4=0.9 V5=15 V6=4

N7 X92 Y17
N8 X88 Y42
:
N19 G80
    
```

tool selection  
conditions  
cycle call-up  
and definition  
of variables  
machining  
positions  
  
cancellation of cycle




**TAPPING**

**G84**

**Definition** Tapping with central feed-in.

**Input**


change-over point	V1 mm abs.
depth of bore (thread)	V2 mm abs.
rotation: M3/M4	V3 3 inward
M4/M3	V3 4 outward
feedrate	V4 mm/rev
dwell	V5 sec.



**Sequence**


spindle on, single block suppressed

- 1 positioning axes traverse the centre of the bore in rapid; feed-in axis remains at traversing height
- 2 feed-in axis drives to V1; change-over to feed
- 3 feed-in axis drives to depth V2 at feedrate determined by V4
- 4 reversal of spindle rotation; dwell at bottom of bore
- 5 retract to V1 in feed
- 6 spindle stop  
single block possible again



**Example**

N9	T0101	tool selection
N10	F500 S250 M3	conditions
N11	G84 V1=40 V2=-10 V3=3 V4=10 V5=5	call-up of cycle G84 and definition of variables
N12	X16 Y52	machining
N13	X27 Y48	positions
:		
N19	G80	cancellation of cycle



The following functions are activated:

- M3 spindle rotation clockwise
- M4 spindle rotation counter-clockwise
- M98 single block suppressed
- M99 single block possible

**Note**

- Feed conditions active before the call-up of the cycle are stored and reactivated automatically once the cycle has been completed.

- While G84 is active the reentry functions are not active.




- Feedrate 100% is set automatically;  
single block is suppressed automatically (M98).

**BORING**


**G85**

**Definition** Boring a rough bore with a boring tool. Oriented spindle stop at the bottom of the bore with eccentric retract.

**Input** change-over point V1 mm abs.  
depth of bore V2 mm abs.  
transverse movement V3 mm inc.  
at bottom of bore



- Sequence**
- spindle on
  - 1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height
  - 2 feed-in axis drives to V1; change-over to feed
  - 3 feed-in axis drives to depth V2 in feed
  - 4 oriented spindle stop, M19 at the bottom of the bore, angle = 0°
  - 5 transverse movement of abscissa axis by distance V3 (negative axis direction)
  - 6 eccentric retract of the feed-in axis to V1



**Condition** If cycle G85 is to be used an encoder is required to allow spindle orientation (M19); otherwise an error message is displayed.




**Example**

```

:
N9  T0101                                tool selection
N10 F500 S250 M3                          conditions
N11 G85 V1=40 V2=8 V3=3                  call-up of cycle G85 and
                                          definition of variables
                                          machining positions
:
N12 X59 Y74.5
N13 X47 Y83
:
N19 G80                                    cancellation of cycle
N20
:

```



The following functions are activated:

- M3 spindle rotation clockwise
- F feedrate active before call-up
- M19 spindle stop with orientation,  
remains active after execution of cycle

**REAMING**

**G86**

**Definition** After the 1st CYCLE START the reaming bit is sunk into the workpiece for a short trial feed-in and then retracted to allow measuring.


From the second CYCLE START onwards the tool is driven to the full depth.

**Input**

change-over point	V1	abs.
machining depth	V2	abs.
1st feed-in depth	V3	inc.
retract height for measuring	V4	abs.

**Sequence** spindle on

1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height



2 feed-in axis drives to V1: change-over to feed


3 feed-in axis drives down by V3 to first feed-in depth in feed

4 in feed to change-over point V1

5 in rapid to retract height V4; spindle continues to rotate;

program stop, **M0 is active**

diameter of the bore can be measured, and the spindle speed corrected



After 2nd CYCLE START:


6 in rapid to V1

7 in feed to bottom of bore V2

8 in feed to change-over point

**Example**

<pre> : N9  T0101 N10 F500 S250 M3 N11 G86 V1=40 V2=10 V3=15 V4=42  N12 X97 Y102 N13 X86 Y113 : N19 G80                 </pre>	<pre> tool selection conditions call-up of cycle G86 and definition of variables machining positions  cancellation of cycle                 </pre>
--	--



The following functions are activated:

- F = feedrate active call-up
- S = old, possibly corrected spindle speed
- M3
- G0, which remains active after the execution of the cycle


**THREAD MILLING**

**G87**

**Definition** A thread is cut by the helical motion of the tool.


**Input**

change-over point	V1	abs.
machining depth	V2	abs.
thread diameter	V3	abs.
thread pitch/rev.	V4	
right/left-hand thread:	V5	= 2 right
	V5	= 3 left



**Sequence**

- spindle on
- 1 positioning axes drive to centre of bore in rapid; feed-in axis remains at traversing height
- 2 feed-in axis drives to V1; change-over to feed
- 3 helical interpolation in feed down to the bottom of the thread
- 4 tool positioned to centre of bore
- 5 retract in rapid to V1



Example

```


:
N10 F500 S250 M3 T1212
N11 G87 V1=42 V2=34.5 V3=10 V4=0.35 V5=2

N12 X44 Y24
N13 X32 Y26
:
N19 G80

N20
    
```

conditions  
call-up for  
cycle G87 and  
definition of  
variables

cancellation  
of cycle



**DIMENSIONING**

**G90 A ABSOLUTE DIMENSIONS  
G91 INCREMENTAL DIMENSIONS**

**Definition**

Positions on workpiece contours can be defined with:

G90 absolute dimensions, i.e. all dimensional values relate to the active program zero point

or

G91 incremental dimensions, i.e. all dimensional values relate to the respective previous positions. It is advisable to use G91 for contours which need to be machined repeatedly in different places.

**Operation**


G90/91 are modal and exclude one another.

They can be programmed with or without axis information.

The axis displays are not influenced by these functions.

When G92 is cancelled G90 becomes active.


**Example G90**



program	points in drawing
N1 G90	
N2 G0 X120 Y60	P1
N3 G1 Y20 F300	P2
N4 G5 X115 Y15	P3
N5 G1 X80	P4
N6 X55 Y25	P5
N7 X30	P6
N8 Y60	P7
N9 X60	P8
N10 Y50	P9
N11 X80	P10
N12 Y60	P11
N13 X110	P12
N14 G5 X120 Y50	P13
N15 G5 X160	P14
N16 M2	

**Example G91**

all pieces of axis information relate to the coordinates of point P1



N1 G90 X120 Y60	P1
N2 G91	
N3 G1 Y-40 F300	P2
N4 G5 X-5 Y-5	P3
N5 G1 X-35	P4
N6 X-25 Y10	P5
N7 X-25	P6
N8 Y35	P7
N9 X30	P8
N10 Y-10	P9
N11 20	P10
N12 Y10	P11
N13 X30	P12
N14 G5 X10 Y-10	P13
N15 X40	P14
N16 G90	
N17 M2	


**SETTING POSITION STORES**

**G92**

**Definition**  
**G92 X Y Z E** G92 is used to assign a new value to the position at which the axis stands, and to display this value. There is no axis movement involved.

**G92** By programming G92 without axis values the machine coordinates are reactivated.

**Example**




**G92 S** Setting of upper spindle speed limit.

**Operation** Values can be set for up to 4 axes.  
G92 can be used in MDI or in automatic.  
G92 is active only in the block in which it is programmed.  
To cancel G92 no other functions must be programmed in the same block as G92.  
Any values within the input range can be used.  
The travel limits determined by the hardware and software limit switches are not affected.

<b>Programming</b>	<b>G92 X.. Y.. Z.. E..</b>	assign axis values
	<b>G92</b>	reactivate machine coordinates
	<b>G92 S..</b>	limit spindle speed

**Example**



program	points in drawing
N1 G90 F200	
N2 G1 X140 Y70	P1
N3 G92 X0	
N4 G1 Y30	P2
N5 G5 X-10 Y20	P3
N6 G1 X-55	P4
N7 X-65 Y30	P5
N8 X-85	P6
N9 X-95 Y20	P7
N10 X-100	P8
N11 G5 X-110 Y30	P9
N12 G1 Y70	P10
N13 X0	
N14 G92	
N15 M30	

**Application**  
**G92 X to E** G92 X to E is used to adapt a program compiled with dimensions from a drawing for a particular clamping position.

**Comments/Restrictions** G92 should **not** be used in conjunction with the following:

- active tool radius compensation **G41/42**  
active tool length compensations address T
- active field limitation **G25/26**  
(G92 resets any field limitation)

In addition the following points must be taken into consideration:

- G92 does not take any active zero shift into account;  
when G92 is cancelled **G54 - G59** are reset as well.
- If while **G92 S..** is effective a spindle speed in excess of the limit is programmed elsewhere in the program the set max. value will be output with automatic gear range selection.
- When **G92 is cancelled** (G92 without axis or spindle values) G1 is automatically activated.
- G92 (without axis addresses) sets **G27**, cancelling any field limitation.
- When a **field limitation** is set with **G25, G26** any zero shift with **G92 X.. Y..** is ignored.
- When G92 is cancelled **G90** is activated.




**FEEDRATES**

**G94 A feedrate direct**  
**G93 time programming**

**G94**                    **Direct specification of feedrate F in mm/min.**  
This type of feedrate output is active on switch-on.  
Axis movement is possible with the spindle at standstill.

**G94**  
**Programming**        **G94 F... = feedrate in mm/min**

With or without axis information. Feedrate F programmed with G94 is modal.




**G93**                    **Specification of the execution time for a path section.**

The corresponding feedrate is calculated by the control.

**Possible applications**        Complex movements involving more than one axis.  
Simultaneous movement of linear axes and rotary axes.  
Polygon contours for which block preparation time is of importance.

**G93**  
**Programming**        **G93 F... F = execution time in seconds**

With or without axis information. The execution time F programmed with G93 only applies for the block in which it is programmed.



**Operation**                G93/G94/G95 exclude one another.


**FEEDRATE MM/REV**

**G95**

**Definition** Programmed feedrates relate to the speed of the main spindle.  
The axis movements are derived from the actual spindle speed  
and are therefore synchronised with the spindle.  
The spindle speed determines the axis feedrate.

**Programming Example** **G95 F 1.67** Feedrate 1.67 mm/rev applies.  
Feedrates of linear axes = mm/rev.  
Feedrate of rotary axis = degrees/rev.

**Resultant Feedrate  $F_R$**   
 $F_R$  = feedrate in mm/min  
 $F$  = feedrate in mm/rev.  
 $S$  = spindle speed



**Example:**  $F = 2$  mm/rev. and  $S = 500$  rpm produce a resultant feedrate of 1000 mm/min.

Axis movements in feed only if the main spindle is running!

- Note:**
- Since the feedrate is derived from the actual spindle speed no axis movements are possible when there is a fault in the main spindle servo loop.
  - Spindle speed output in BCD is not permitted.
  - With G95 active no S-word is output via the BCD bus.

**AUTOM. CALCULATION OF CUTTING SPEED IN M/MIN**


**G96**

**Definition** The control calculates the spindle speed from the data for cutting speed and tool radius stored in the technology store of the programmed tool.

**Operation** With M3 or M4 active, the spindle speed is activated after the programming of a T-word. G96 and G97 cancel one another.

**Programming** On its own or together with other instructions.

**Spindle speed**  $n = \frac{S}{2 \cdot \pi \cdot R}$  formula for calculating the spindle speed  
 R = tool radius (in tool table)  
 S = cutting speed "



**Example:** A cutter radius of 20 mm plus a required cutting speed of approx. 25 m/min will result in the output of 200 rpm for the spindle speed.

**Usage** Before the call-up to G96 a starting speed can be selected (with G97). G96 must be cancelled before M5 (G97).

**Note** It is important for the calculations that the tool radius is defined in mm in the tool table.  
 The cutting speed is specified in mm/min.  
 The tool wear compensation (DR-value in tool table) is not taken into account in the spindle speed calculation.

**SPINDLE SPEED DIRECT**

**G97 A**

**Definition** The speed of the main spindle is determined with S directly in rpm.  
The spindle speed does not influence any axis movements.  
G97 is active on switch-on.

**Programming** **G97** no change in the spindle speed  
**G97 S...** new spindle speed S... is activated

Overriding the programmed spindle speed:

**G66** overriding is possible via the potentiometer on the manual panel


**G63** the override potentiometer is not effective

Effect of gear range selection:

**M40** automatic recognition and output  
**M41-44** direct programming of the gear range

see also **SPINDLE SPEEDS** chapter 3 **ADRESS S**  
**GEAR RANGES**  
**M-FUNCTIONS**

**M40** Automatic gear range selection and speed ranges for the individual gear ranges:



Selected gear ranges when different speeds are programmed:

- A: gear range II
- B: gear range III
- C: gear range IV

With speeds at which two gear ranges overlap the lower gear range (higher motor speed and higher torque) will be output.

**SUBPROGRAM END**

**G99**

**Definition** G99 designates the end of a subprogram.  
G99 is the instruction to jump back within the program from which the call-up was made to the position at which the subprogram was called up.  
The next program block will then be executed.

**Programming** G99 without any other instructions.

**Example**

N1 .	beginning of main program 5
N2 .	
N3 G22 P15	call-up of subprogram 15
.	
.	
N20 G22 P12	call-up of subprogram 12
.	
.	
N37 G22 P20	call-up of subprogram 20
N38 .	
N39 .	
N40 M2	main program end
(there must be M2/M30 between the main program and the associated subprograms!)	
N41 \$15	beginning of subprogram 15
N78 ...	
N79 G99	end of subprogram 15
N80 \$12	beginning of subprogram 12
N115...	
N116 G99	end of subprogram 12
N117 \$20	beginning of subprogram 20
N207...	
N208 G99	end of subprogram 20

**Note** The program from which the call-up is made can be a main program, a subprogram or a cycle.  
Maximum nesting depth is 10 (see under G21, G22).

**THREE-DIGIT G-CODES**

**G800 to G869**

**Definition** The control operates with 3-digit G-codes.  
The functional content of these codes must be defined by the machine tool builder or the user himself.

**Programming** The machining sequence is programmed as a cycle.  
Both the standard instructions as well as the parametric functions can be used to program these cycles.

Application examples:

- Machine specific operations such as
- delivery and removal of workpieces
- measuring, spot checks
- tool inspection
- punching/nibbling cycles
- control of auxiliary machinery

Simplification of programming by the use of cycles for

- the firm's own particular methods
- for the machining of bores,
- of standard parts, of part families,
- for calculations,
- for the adaptation of the CC 100 to
- special machines.


Cycle Numbers and Call-up	Programming	Call-up
cycle		G-function
1		G 801
.		.
.		.
69		G 869

**Example** A machining cycle written under cycle 45 is called up by G845.

**CONTOUR CYCLES**

**G890 to G898**

These 3-digit G-codes calculate positions which might not be provided on the drawing in all 3 main planes.



The control automatically makes the correct allocation of entered abscissa and ordinate values to the relevant axes, dependent on the plane selection.

**Axis Allocation**

	G17	G18	G19
abscissa A	X	Z	Y
ordinate 0	Y	X	Z

**Execution**

**Cycles G890 and G891 are pure calculating cycles.** The results obtained by calling them up can then be used in the course of the part program.

**Cycles G892 to G898 process the values by executing the contour.**

**Call-up of Contour Cycles in a Program**

**Operating Sequence**

Main mode EDIT



TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

--> program call, e. g. **9** **ENTER**

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	--------------	------	------	------

SEARCH GRAPHIC		SCROLL		MODIFY INSERT
-------------------	--	--------	--	------------------

			BORING CYCLES	CONTOUR CYCLES
--	--	--	------------------	-------------------



CYCLE                    3 \*\*\*\*\*                    M RWED    MEMORY

		joining  2 points	joining  1 point + 2 angles	 Chamfer
 point on circle	 tangent circles	 point on line	 Intersect. line/line	
				OK

The required cycle is to be selected with the or the key and confirmed with **OK**.


Once the variables have been defined and the cycle input confirmed with **ENTER** the contour cycle will be stored in the program.



INTERSECTION CIRCLE/CIRCLE

G890

Definition



Input

G890

V90 = A } 1st  
V91 = 0 } centre  
V92 = 1st radius  
V93 = A } 2nd  
V94 = 0 } centre  
V95 = 2nd radius

G17	G18	G19
X	Z	Y
Y	X	Z
X	Z	Y
Y	X	Z

Results

After the call-up the contents of the variables are as follows:

intersection P1	V90 = abscissa	V91 = ordinate
intersection P2	V93 = abscissa	V94 = ordinate

Position of the intersections, looking from the first to the second centre of the circle:

P1 lies to the right of the connecting line  
P2 lies to the left of the connecting line

Example


The calculated points P1/P2 could be used as follows:

```
N1 G0 X60 Y85
N2 G890 V90=75 V91=90 V92=5 V93=82 V94=100 V95=8.5 cycle call-up
N3 G1 F750
N4 X=V90 Y=V91 allocation of variables
N5 G2
N6 X=V93 Y=V94 R=V95 allocation of variables
N7 M30
```

**INTERSECTION LINE/CIRCLE**

**G891**

**Definition** This is a pure calculating cycle and it will not produce any axis movement.



**Input**

<b>G891</b>		<b>G17</b>	<b>G18</b>	<b>G19</b>
V90 = A	} centre of circle	X	Z	Y
V91 = 0		Y	X	Z
V92 =	radius			
V93 = A	} for point ①	X	Z	Y
V94 = 0		Y	X	Z
V95 = A	} ②	X	Z	Y
V96 = 0		Y	X	Z

**Results**

After the call-up the calculated values will be stored in variables as follows:

intersection P1            V90 = abscissa            V91 = ordinate  
intersection P2            V93 = abscissa            V94 = ordinate

**Application**

The calculated points P1/P2 can be used as follows:

```


N1  G0  X0  Y0
N2  G891 V90=40 V91=30 V92=15 V93=15           cycle call-up
      V94=30 V95=100 V96=45
N3  G1  F750
N4  X=V90   Y=V91           allocation of variables
N5  G2
N6  X=V93   Y=V94   R=V92   allocation of variables
N7  M30
    
```

**ROUNDING CORNERS (3 POINTS)**

**G892**

**Definition**

Calculation of positions to round corners with 3 known points.  
This cycle calculates the positions and then initiates the traversing movement.



**Input**

**G892**

① starting point = last programmed position

		G17	G18	G19
② intersection	V90 = A	X	Z	Y
	V91 = 0	Y	X	Z
③ end point	V92 = A	X	Z	Y
	V93 = 0	Y	X	Z

V94 = radius

V95 = 0 = machining up to P2

1 = machining up to end point ③

**End Point of Machining**

The end point of the machining is determined by the input for V95. When several contour cycles are linked together the previous contour cycle must not be machined up to the end point.

**Results**

1st transition point P1 V96 = abscissa V97 = ordinate

2nd transition point P2 V98 = abscissa V99 = ordinate

**Example**


N1 G1 X20 Y20 F100 starting position  
 N2 G892 V90=55 V91=60 V92=100 V93=30 V94=20 V95=1 cycle call-up  
 + variable allocation  
 N3 X110 Y65  
 N4 M30

**ROUNDING CORNERS (2 ANGLES)**

**G893**

**Definition**

Calculation of positions to round corners with known angle values.  
The cycle calculates the positions and initiates the traversing movement.



**G893**

**Input**

starting point (1) = last programmed position  
 angles V90 = alpha      V91 = beta  
 - input range      -180° to + 180°  
 - sign determines direction of rotation  
 - the abscissa is the reference axis

end point (2)

	G17	G18	G19
V92 = A	X	Z	Y
V93 = 0	Y	X	Z
V94 = radius for arc			
V95: 0 machining up to point P2			
1 machining up to end point			

**End Point of Machining**

The end point of the machining is determined by the input for V95. When several contour cycles are linked together, the previous contour cycle must not be machined up to the end point.

**Programming**

G893 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ... V95 = ...

**Results**


1st transition point P1      V96 = abscissa      V97 = ordinate  
 2nd transition point P2      V98 = abscissa      V99 = ordinate

**CHAMFERING**

**G894**

**Definition**

Calculation of positions to apply chamfers to straight contour elements.  
The cycle calculates the positions and initiates the traversing movement.



**Input**

**G894**

starting point      1 = last programmed position

intersection

2

G17	G18	G19
X	Z	Y
Y	X	Z
X	Z	Y
Y	X	Z

V90 = A

V91 = 0

end point

3

V92 = A

V93 = 0

V94 = length of chamfer

V95: 0 = machining up to point P2

1 = machining up to end point

**End Point of Machining**

The end point of the machining is determined by the input for V95. When linking several contour cycles the previous contour cycle must not be machined up to the end point.

**Results**

1st transition point P1    V96 = abscissa    V97 = ordinate

2nd transition point P2    V98 = abscissa    V99 = ordinate

**Example**

N1    G1    X80    Y5    F1000

starting position

N2    X50

last contour point before call-up

N3    **G894** V90=50 V91=40 V92=10 V93=45 V94=10 V95=1


cycle call-up and variable allocation

N4    M30

**CALCULATION OF THE END POINT OF AN ARC**

**G895**

**Definition** Calculation of the end point of an arc, of which only one coordinate is known.  
The cycle calculates the position and initiates the traversing movement if COND. SBP CALL-UP is high.



**Input**

**G895**

- starting point (1) = last programmed position .
- end point (2) V90 = A or 0-value  
V91 = 1: V90 represents abscissa  
V91 = 2: V90 represents ordinate
- centre of circle V92 = A  
(3) V93 = 0  
V94 = +radius (+) larger/equal 180°  
- smaller 180°  
V95 = direction of rotation = 2 : G2  
= 3 : G3

**Programming** G895 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ... V95 = ...


**Results** end point (2) V90 = abscissa V91 = ordinate

The missing coordinate value of the end point is calculated.

**TRANSITION POINT ARC/ARC tangential**

**G896**

**Definition**      The control calculates the transition point of two consecutive arcs with tangential transition and a reversal of the direction of rotation.  
The cycle calculates the positions and initiates the traversing movement.



**Input**

**G896**

starting point      ①      = last programmed position

1st centre of circle      V90 = A      V91 = 0

2nd centre of circle      V94 = A      V95 = 0

end point      ②      V92 = A      V93 = 0

direction of rotation      V96 = 2 corresponds to G2/G3  
V96 = 3 corresponds to G3/G2

**Programming**

G896 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ... V95 = ... V96 ...

**Results**


Transition point P1      V97 = abscissa      V98 = ordinate

**CALCULATION OF THE END POINT OF A STRAIGHT LINE**

**G897**

**Definition** Calculation of the end point of a straight line, of which only one coordinate is known.

The cycle calculates the positions and initiates the traversing movement.



**Input**

**G897**

starting point (1) = last programmed position

angle V92 =  $\pm 180$

end point (2) V90 = A or 0-value  
 V91 = 1: V90 represents abscissa value  
 V91 = 2: V90 represents ordinate value

**Programming**

G897 V90 = ... V91 = ... V92 = ...

**Results**

The unknown coordinate of the end point is calculated, after which the contents of the variables will be as follows:

V90 = abscissa value  
 V91 = ordinate value




**INTERSECTION OF TWO STRAIGHT LINES**

**G898**

**Definition** Calculation of the intersection of two straight lines from the entered angle values.

The cycle calculates the positions and initiates the traversing movement.



**G898**

**Input**

starting point	= last programmed position	
end point	V90 = abscissa	V91 = ordinate
angles	V92 = alpha	V93 beta

- input range -180° to + 180°
- sign determines direction of rotation
- the abscissa is the reference axis

V94 = 0: machining up to P2  
 = 1: machining up to end point

**End Point of Machining** The end point of the machining is determined by the input for V94. When several contour cycles are linked together the previous contour cycle must not be machined up to the end point.

**Programming** G898 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ...

**Results** The position of the intermediate point P2 is calculated and the axes drive to this position; the values are stored in the following variables:

V95 = abscissa value  
 V96 = ordinate value

**SURVEY OF FIRMLY ALLOCATED CYCLES**

	Function	Programmed under cycle, main mode	Call-up via
<b>User cycles</b>	freely programmable	1 - 69	G8nn
<b>MTB cycles</b>	priority routine	74	interface signal fast input on SERVO card
	MTB cycle	75 "	M22
	MTB cycle	76 "	M21
	MTB cycle	77 "	M6
	allocation of functions for keys F1 to F10 of customer keypad	78 "	customer keys
	referencing cycle	79 "	soft key selection

Cycles 1 - 69 are available for use by the enduser, unless predetermined by the MTB. These cycles can be used to program recurring machining tasks.

A cycle with the number nn is called up with G8nn. Input variables can be written together with the 3-digit G-code, for instance:

G824 V1 = ... V10 = ... V55 = ... (call-up for cycle 24)

Cycles 70 - 73 are routines which are used internally by the control and which have fixed functions. They are not available for use by the enduser.

## **4. PARAMETRIC FUNCTIONS**

# V 15 = ATG VX

**Range**

The following functions are available:  
 load instructions for numerical values, 125 variables V1 to V99, VA to VZ,  
 basic arithmetic functions, trigonometric functions, copy instructions,  
 logic operations, branching, access to NC data.

**The user can write his own cycles with parametric functions.**

CPC = Customer parametric Cycle  
 A CPC represents the solution of a problem in principle.  
 Values such as spindle speed, dimensions, tool no. etc. are kept variable.

Once the parametric program has been produced the only actions necessary for the execution are to load values for the variables and call up the program.

**Applications**

Production of customer's own cycles for:  
 automatic measuring cycles with calibration of the probe,  
 measuring of the workpiece, and automatic tool wear compensation  
 production counters, random sample counters  
 scale factors for similar parts,  
 variable programs of all types

**Programming**

During **panel input** the CPC key is pressed before the input of a computing function. This automatically activates the secondary function ( inscribed at the top) of the dual function keys.

During **external programming** the mnemonic codes used by the control when printing out parametric instructions must be used to write the program.

Example: load variable 5 with the content of variable 2 + value 10

**To store**

O	BLT	CPC	=	C	BRA	CPC	+	COR	BGT	Enter
V	5		E	V	2		G	1	0	

**To execute**

O	BLT	CPC	=	C	BRA	CPC	+	COR	BGT	START
V	5		E	V	2		G	1	0	

**External programming**

N12 V5 = V2 + 10 ( Note Only whole numbers are accepted)

One program line can contain several computing functions. They will be executed in the same sequence in which they were written.

Example: V17 = V2 \* V3 V25 = SIN V17 V26 = COS V17

**Note**

- The programming in each line must be either all conventional or all parametric.
- Parametric functions must always be programmed without space characters, e.g. ATG VX, in order to avoid syntax errors.

---

**Program Planning** Before starting to produce programs it is advisable to do some general program planning. This should take the following points into consideration:

- Is a program to be used completely independently?
- Or is the program to be used in conjunction with other program modules?  
If so, with which ones?
- Is the program to be produced as a main program, a subprogram or a cycle?
- Which other programs must/can be stored in the memory at the same time?
- Which variables will be used?

**Aims** Simplification of the continuing program administration.

- Rationalized program production
- Problem-free combination of programs
- Multiple use of program modules

**FORMS** The following forms help with program planning:

- Memory Allocation
- General Program Planning
- Variables
- Program Description

**Memory Allocation** This form shows which programs, cycles, subprograms etc. are stored in the control together.

**Program Planning** This form shows at a glance which variables are used by which program, and which are still available to be used.

**Variables** This form can be used when testing programs, by tracking the meaning and the contents of the variables.

**Program Description** This is an aid for the program user, and it should consist of at least a top sheet with

- a sketch of inputs/possibly the sequence
- required storage capacity, short functional description

**MEMORY ALLOCATION**

	name	no.	function, sequence	required storage capacity
<b>program</b>	_____	___	_____	_____
<b>assigned subprograms (local)</b>	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____

	name	no.	function, sequence	required storage capacity
<b>program</b>	_____	___	_____	_____
<b>assigned subprograms (local)</b>	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____

	name	no.	function, sequence	required storage capacity
<b>cycle (global)</b>	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____
	_____	___	_____	_____

PROGRAM PLANNING

PROGRAM / CYCLE		VARIABLES V								
SBP	function	1	2	3	4	5	6	7	8	9

VARIABLES (global)

L = loaded value  
 C = constant  
 Ca = calculated value  
 (temporary)

function	V	value	function	V	value
	0			0	
	1			1	
	2			2	
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8			8	
	9			9	
	0			0	
	1			1	
	2			2	
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8			8	
	9			9	
	0			0	
	1			1	
	2			2	
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8			8	
	9			9	
	0			0	
	1			1	
	2			2	
	3			3	
	4			4	
	5			5	
	6			6	
	7			7	
	8			8	
	9			9	




**LOAD FUNCTIONS**

- Load  $V_i$  directly with numerical value  $V1 = 9316$
- Load  $V_i$  with content of a variable (copy)  $V1 = V2$  or  $V1 = V2 + V15$   
 $V1 = V2 - 4$
- Load  $V_i$  with content of an NC address  $V1 = X$

**Definition** The variables to the left of the equal sign are loaded from the sources written on the right.

**Programming**



Several of these functions can be written into the same line.

**Example** N1 V12 = 1.6 V3 = V5 V4 = Z

**Execution** When N1 is carried out the programmed variables are loaded one after the other.

The sequence in which the variables are written determines the order of execution.

NC address values which can be loaded:

address	loaded value corresponds to:
XYZ E	absolute positions in the active type of dimension
A D R	in the machine coordinates or relating to the
I J K	zero point set with G92
T	T is loaded with 4-digits <div style="margin-left: 20px;"> <math>T \begin{matrix} cc &amp; oo \end{matrix}</math>  <span style="margin-left: 40px;">└─ last output tool</span>  <span style="margin-left: 40px;">└─ last effective compensation</span> </div>
F	feedrate in the active type of dimension as defined by G94 / 95 / 96
S	spindle speed or cutting speed as defined by G96 / 97

## ARITHMETIC FUNCTIONS

<b>Addition</b>	$V1 = V2 + V3$ $V1 = V2 + 157$ *)
<b>Subtraction</b>	$V1 = V2 - V3$ $V1 = V2 - 157$ *)
<b>Multiplication</b>	$V1 = V2 * V3$ $V1 = V2 * 157$ *)
<b>Division</b>	$V1 = V2 / V3$ $V1 = V2 / 157$ *)
<b>Square root</b>	$V1 = \text{SQR } V2$ **)

**Definition** Arithmetic functions, using the contents of variables or direct numerical values.

**Programming**  $VN = VM + VP$        $V1 = VN * 12$  \*)       $VJ = \text{SQR } V1$  \*\*)

**Example** Finding the square roots of a quadratic equation in a program line.

$$X_{1/2} = -\frac{P}{2} \pm \sqrt{\left(\frac{P}{2}\right)^2 - q}$$

with  $P = V1$   
 $q = V2$

$$V4 = V1 / 2 \quad V3 = V4 * V4 \quad V3 = V3 - V2$$

$$V3 = \text{SQR } V3 \quad V5 = V4 * -1 \quad VX = V5 - V3 \quad VY = V5 + V3$$

VX and VY will contain the solutions after the execution of the program line.

**Sequence** The sequence in which the functions are written determines the sequence in which they are executed.

**Note** \*) For arithmetic and trigonometric functions the numerical values can be entered directly with max. 3-digit, positive integer numbers or max. 3-digit negative integer numbers.

\*\*\*) CPC computing functions (SQR, COS, SIN, ATG) should be programmed without any space characters only with variables; numerical values are not permitted.

**INCREMENT / DECREMENT**

<b>Increment value</b>	<b>INC V1</b>
<b>Decrement value</b>	<b>DEC V1</b>

**Definition** The content of a variable is incremented or decremented by 1.  
Any digits after the decimal points are deleted.

**Programming** INC VN DEC VM

**Example** N1 V1 = 12 V4 = 1.7 V5 = -1.3  
.  
.  
.  
N13 INC V1 INC V4 DEC V5

After the execution of N13 the contents of the variables are as follows:  
V1 = 13 V4 = 2 V5 = -2

**Integer Number** A real number can be converted into the corresponding integer number by performing the INCREMENT and then the DECREMENT function.

**REGISTERING TIME** **TIM V1**

**Definition** The time elapsed since the start of the program is loaded into the variable (seconds).

**Programming** TIM VN  
N from 1 to 99 and from A to Z.

**Example**

```

N1 $5 ←
N2 G91
N3 G1 X1 F250
N4 TIM V1
N5 V2 = 50
N6 V3 = V2 - V1 BGT P5
    
```

registering time for G1-function  
storing value in V1,  
time limit 50 seconds;  
checking condition and branching;  
the program sequence is not  
completed until the time limit  
of 50 seconds is reached; other-  
wise a jump is made into SBP 5.

N M2

---

**TRIGONOMETRIC FUNCTIONS**

**Sine**  $VN = \text{SIN } V1$

**Cosine**  $VN = \text{COS } V1$

**Arc tangent**  $VN = \text{ATG } V1$

**Definitions** The sine or cosine value of an angle (in degrees) is formed (SIN/COS).

The corresponding angle (in degrees) is formed from the tangent (ATG).

**Programming**  $VN = \text{SIN } V1 \quad V0 = \text{COS } V2 \quad VP = \text{ATG } V3$

**Example**  $N1 \quad V10 = 30 \quad VX = \text{COS } V10 \quad VY = \text{SIN } V10$

.  
. .  
. .  
. .

**Operation** The sine or cosine of any angle can be formed.  
Angle values are to be entered via variables.  
The direct input of numerical values is not permitted.

## TOOLS

## LOAD TOOL STORE

COR = V1 R = V2 L = V3 \*\*)

**Definitions** The tool store is loaded.**Programming**  
N1 VN = 15  
N2 COR = VN R = VP DR = VR L = VQ S = VS  
VN from 1 to max. 48.

After the execution of N2 tool 15 will be loaded with the data from VP to VS.

## COPY TOOL DATA

COR = V1 V2 = RR V3 = L \*\*)

**Definition** Variables are copied from the tool store.**Programming**  
COR = VN VP = R VR = DR VQ = L VS = S  
VN from 1 to max. 48.**Operation** Values are only copied, i.e. the tool data do not affect the machined path.**Example**  
N1 V12 = 15 V13 = 15.0 V14 = 75  
N2 COR = V12 R = V13 L = V14After the execution tool 15 is loaded with  
R = 15.0 L = 75.0**Example**  
N1 V4 = 25  
N2 COR = V4 V1 = R V2 = L V3 = DR \*)

After the execution of N2 the contents of the variables will be as follows:

V1 = radius V2 = length V3 = tool wear of tool 25.

**Note** \*) The input of the tool wear (DR) depends on the radius (R); limit: 10% of radius.  
The DR value/ modification is entered as an incremental value.\*\*) The COR instruction should be programmed in **a single line** together with the variables.

## ZERO SHIFTS

Load zero shift G54 to G59	TRF = V1 X = V2 Y = V3
Copy zero shift G54 to G59	TRF = G54 V1 = X V2 = Y
Copy active zero shift G92	TRF = G92 V1 = X V2 = Y
Copy active pole (polar coordinates)	TRF = G20 V1 = X V2 = Y
Copy active scaling factor switching G36	TRF = G36 V1 = X V2 = Z

## Definitions

The zero shift table is loaded or values are copied from the zero shift table.  
The values of the zero shifts and the values of the pole position are copied.  
The values of the active scaling factor are copied into V1 for the active plane, and into V2 for a possible change in scaling factor in the third axis.

## Programming

## Load zero shift G54 to G59

N2 TRF = VN X = VP Y = VQ Z = VR E = VS

## Copy zero shift G54 to G59

N2 TRF = G54 VP = X VQ = Y VR = Z VS = E

**Copy pole** (the coordinates relating to the active G20 zero point of the active pole are copied)

N2 TRF = G20 V1 = X V2 = Y V3 = Z V4 = E

**Copy zero shift G92** (current difference between commanded position and machine position)

N2 TRF = G92 V1 = X V2 = Y V3 = Z V4 = E

## Example

N1 V1 = 54 V2 = 100 V3 = 200 V4 = 150 V5 = 70  
N2 TRF = V1 X = V2 Y = V3 Z = V4 E = V5  
N3 M2

After the execution of N2 the zero shift corresponding to G54 is defined as follows:

X workpiece zero point at coordinate 100  
Y workpiece zero point at coordinate 200  
Z workpiece zero point at coordinate 150  
E workpiece zero point at coordinate 70



**CONDITIONAL BRANCHING**

In addition to being dependent on signals program branching can be tied to the following conditions:

- mathematical comparisons
- modal effect of various G/M-functions
- whether or not mirror image is active

**SETTING CONDITION REGISTER**

**TST V1**

The basis of all types of branching described in the following text is the status of the

CONDITION REGISTER (CR).

After mathematical operations or after "TST" the control will load the result into the internal condition register with the values of the variables.

**TST must be used before the branching, if the variable on which the branching is to depend is not yet in the CR.**


**Programming**

**N10 TST VN**

Branching operations are only carried out correctly if the result from the preceding operation contains the conditions for the particular branching.

If, for instance, a multiplication is carried out in line 5 and no further instruction follows, which would set the condition registers, the result of this multiplication would still take effect in block 12 of the example on the next page.

General format for programming conditional jumps:



If the jump condition is not fulfilled, the subsequent block will be executed.



**CONDITIONAL BRANCHING / CONDITION REGISTER (CR)****Automatic  
Loading**

The condition register is loaded automatically by operations such as the basic arithmetic functions.

After the operation it will indicate what the result of the computation is compared to zero:

EQ	= equal zero
NE	= not equal zero
GT	= greater than zero
LT	= less than zero
LE	= less/equal zero
GE	= greater/equal zero

**Loading via  
TST**

Not all operations load the condition register automatically.  
Example: A value is copied into V15 from the tool table.

If a branching is to depend on the value contained in V15 after the copying the condition register must be set with TST 15 before the decision is defined.

**Programming**

N12	BLE	P27	jump to label 27, if condition "BLE" is fulfilled; otherwise continue at block 13
.	.	.	jump target
N20	\$27		jump target
	or		
N10	V12 =	V11-V10	calculation of required jump address
N11	TST	V15	set condition register
N12	BLE	V12	jump to address 28 (content of V12) if condition regarding V15 is fulfilled
.	.	.	
N31	\$28		jump target

**CONDITIONAL BRANCHING AFTER MATHEMATICAL COMPARISON**

The jump address can be defined by one of two means:

- **indicated**, as content of a **variable V** or
- **directly**, by specifying a **label with P**.

Conditional branching does not automatically set the condition register.

**BEQ** Branch if Equal to zero **BEQ V5**  
**BEQ P1**

All digits before and after the decimal point must be 0

**BNE** Branch if Not Equal to zero **BNE V5**  
**BNE P1**

The jump condition is fulfilled if at least one digit before or after the decimal point is not equal to zero.

**BGT** Branch if Greater Than zero **BGT V5**  
**BGT P1**

The condition is fulfilled if the result is a positive number of at least one increment.

**BLT** Branch if Less Than zero **BLT V5**  
**BLT P1**

The condition is fulfilled if the result is a negative number of at least one increment.

**BGE** Branch if Greater than or Equal to zero **BGE V5**  
**BGE P1**

The condition is fulfilled if the result is = 0 or positive.

**BLE** Branch if Less than or Equal to zero **BLE V5**  
**BLE P1**

The condition is fulfilled if the result is = 0 or negative.


**Note:** If several jump instructions are programmed in one block the user must check the corresponding jump addresses.

**Example**                    **JUMP AFTER COMPARISON WITH A VARIABLE VALUE**

The X-axis is to traverse to the value calculated for V7.

**Condition**                The traversing movement is to be carried out if the value in V7 exceeds 10 (content of V5).

If the value is greater the program is to be abandoned by making a jump onto the program end.



**Note**                    If the jump condition in block 15 is defined as "BGT", the movement will be carried out for V7 values of up to 10.000.

A V7 content of 10.001 will produce program stop.

The jump condition "BGE" in block 15 would produce a program stop for a content of 10.000 and above.

The jump condition "BEQ" in block 15 would only produce a program stop if V7 was exactly 10.000.

**BRANCHING CONDITION: NC INSTRUCTION**

**Definition**      Branching can be made dependent on the active state of certain modal conditions.

**The tests described below will set the condition register (CR) = 0, if the relevant condition is fulfilled.**

After the test branching can take place, dependent on the status of the condition register.

**G-FUNCTIONS      Test whether a particular G-function is active as a modal function      TST G1**

When testing for G1 the CR = 0 if G1 is active; the CR = 1 if G1 is not active.

**Programming**      N12 TST Gn

Range of G-functions (n) for which the test can be carried out:

G0, 1, 2, 3, 17, 18, 19, 39, 53-59, 62, 65, 66, 90, 93, 94, 95, 97

**Example**

N10	TST	G17	BEQ	P1	<pre> graph TD     N10 --- B1(( ))     N11 --- B2(( ))     N12 --- B3(( ))     B1 --- J1(( ))     B2 --- J2(( ))     B3 --- J3(( ))     J1 --- J2     J2 --- J3     J3 --- N19                 </pre>
N11	TST	G18	BEQ	P2	
N12	TST	G19	BEQ	P3	
N19	\$1				

check whether working plane G17 is active; if not, jump to label \$1

N30 G99

**M-FUNCTIONS      Test whether a particular M-function is active as a modal function      TST M41**

**Programming**      N12 TST M n

Admissible range for n: 3, 4, 5, 19, 41 - 44

**MIRROR IMAGE      Test whether mirror image function is active for one or several axes      TST QX**

**INCH/METRIC      The whether measuring system is defined as inch or metric      TST QM**

**Programming**      N12 TST Qn  
Admissible for n: X, Y, Z, E, M, M = metric

**AXIS INFORMATION**

**X = V1**

- Definition** NC addresses are loaded from variables.
- Operation** During subsequent program execution the control will carry out the instructions as with DIN programming.
- Programming** N10 X = V1 Y = V15

Admissible DIN addresses

axis traverse

X	Y	Z	E
I	J	K	
A	D	R	= VN
M	S	T	= V1

output M-functions/aux. functions  
T must be loaded with 4 digits,  
possibly with internal effect

determine feedrate

F = V1

select/set G-functions  
2 or 3-digit address

G = V1

- Example**
- N1 F500
- N2 V10=50 V11 = 27 V12 = 3 V13 = 15
- N3 V1 = 60
- N4 V2 = V12/V1
- N5 V3 = V2 + V11
- N6 V2 = V13/V1
- N7 V2 = V2/V1
- N8 V3 = V2 + V3
- N9 A = V3 D = V10
- N10 M2

**Execution** Axes traversing to a position which is defined by the following values:

	value
radius V10	50
angle V11 degrees	27
V12 minutes	3
V13 seconds	15

Axes X and Y traverse to the following positions:  
X = 44.529 Y = 22.742

**POSITIONING**

(Traverse axes with external command)

**POS**

Linear axes can be traversed with an external command during the execution of a program. The POS (axis) function must be written into the part program at the appropriate place. The interface signal DRIVES ON goes "low" for the particular axis(es) (servo loop is open). The current position is displayed. An external command can then be applied. Once the interface signal DRIVES ON is switched back on the servo loop closes. The active part program will then be resumed.

**Example**

<p>N1 G1 X50 Y20 Z10 F500</p> <p>N2 X100</p> <p>N3 M55</p> <p>N4 POS Y</p> <p>N5 POS Z</p> <p>N6 X10 Y10 Z15</p> <p>.</p> <p>.</p> <p>.</p> <p>.</p> <p>N15 M2</p>	<p>all servo loops are closed; traverse to axis positions</p> <p>interface signal DRIVES ON for Y and Z = "low" (via M-function, for instance); Y and Z axis are traversed with external command (servo loop open); interface signal DRIVES ON for Y and Z = "high" (servo loop closed); traverse to axis positions</p>
--	---

**Note:**

Each POS function only applies to one axis; if several axes are involved the POS functions must be programmed in separate blocks.

The POS function can only be applied for the E-axis if it is defined as a linear axis.


**STV - FUNCTION (SET VARIABLE FUNCTION)**

**Definition** During the course of a program execution it is possible to enter values into the variables table by MDI, via the serial interface or via the PLC. The updated variable values become active within the current program through programming of the STV function.

The STV function stops the program execution and interrupts the block preparation process. The updated value from the variable table is transferred into the working store. With the interface signal "STV" the program sequence is resumed. The new variable value will be processed by the program.

**Operation** - STV is not modal.  
- The complete variable table is updated with STV.

**Programming** The STV function must be programmed immediately prior to the variable which is to be changed.



**Example** Variables for a fixed machining cycle are loaded into the NC by the PLC via the STV function.


N15 V70 = 50 V75 = 115 loading current variables via  
 . MDI directly into the variable  
 . table or in program by means  
 . of load instruction

N19 G0 X = V70 Z = V75 traversing movement

N20 F500 S250 M3 machining parameters

N21 G81 V1 = 35 V2 = 109 1st boring operation

N22 STV  NC to interface **A18 Data 0**  
 (part program stops)

 interface to NC: data transfer  
 Axx Dxx V70  
 Axx Dxx V75  
 Axx Dxx V76  
 .  
 .

**A18 Data 1** - end of data transfer; program continues

N23 X = V70 Z = V75 next boring position defined  
 . by STV; 2nd boring operation  
 .

**Output** BCD output bus: **A18 Data 0**

**Input** BCD input bus: **A18 Data 1**

**Note** The function is applicable to the complete variable table (V1 to V99 and VA to VZ).




CPC SAMPLE PROGRAMS: 1. Ellipse

**Task** Path calculation for an ellipse (centre of ellipse = coordinates 0/0).  
The ratio between the two radii is to be 0.4. The program is stored as cycle 65. It is called up with G865. The ratio should be definable by one single variable.

<b>Sequence</b>	N1	jump address (label 1)	
	N2,3	calculation of X-coordinate	
	N4-6	calculation of Y-coordinate	
	N7	positioning to X/Y coordinates	
	N8,9	feed-in in Z (1st positioning only)	
	N10	increment angle until final value is reached	
<b>Used</b>	V1	starting angle alpha	0
<b>Parameters</b>	V2	incrementing angle in alpha	2
	V3	radius b	10
	V4	value for condition	
	V5	radius a (larger radius)	25
	V8	final angle	360
	V6	cosine --> X-component	
	V7	sine --> Y-component	
	V10	milling depth in Z	-0.5

**Advantages** The resulting program is considerably shorter than a conventional program, which would describe an ellipse as a contour made up of at least 10 arcs. It is also fully flexible with regard to the used radii and the ratio between them (b/a).

**Programming**



```

Cycle 65
N1  $1
N2  V6 = COS V1
N3  V6 = V6 * V5
N4  V7 = SIN V1
N5  V7 = V7 * V5
N6  V7 = V7 * V3
N7  X = V6  Y = V7
N8  G1
N9  Z = V10
N10 V1 = V1 + V2
N11 V4 = V8 - V1
N12 BGE P1
N13 G0
N14 M2
    
```

**Call-up and Example**


```

N1  G0  Z20
N2  G865 V1 = 1  V2 = 8  V3 = 10  V5 = 30  V8 = 359  V10 = 12
N3  Z20
N4  M30
    
```

**Note:** Careful selection of the V2 value (incremental angle) makes it possible to achieve an optimum combination of accuracy and speed. Angle values relate to the circle with radius a. The corresponding Y-coordinate is modified by radius b (V3)!  
The program will work in a counter-clockwise direction.

CPC SAMPLE PROGRAMS: 2. Row of Holes

Definition of the variables



Sequence

$X = V90$

$Y = V91$

$\Delta X = V92$

$\Delta Y = V93$

number of holes = V94

Program construction  
(solution)

N1 V40 = V90

N2 V41 = V91

N3 V44 = V94

N4 BEQ P1

N5 F500 S250 M3

N6 G81 V1=20 V2=0

N7 \$2

N8 G0

N9 X = V40 Y = V41

N10 DEC V44

N11 BEQ P1

N12 V40 = V40 + V92


N13 V41 = V41 + V93

N14 BRA P2

N15 \$1

N16 G80

N17 M2




CPC SAMPLE PROGRAMS:            3. Bolt Hole Circle

The following requirements need to be provided for:

- variable X/Y position
- variable number of holes
- variable angle related hole distribution

Definition of the Variables




- V33 calculated angle value
- V35 calculated number of holes
- V80 sine value for Y
- V81 cosine value for X
- V82 bolt hole circle radius
- V83 Y-position
- V84 X-position
- V85 calculated increase in angle

- V90 position of centre of circle in X
- V91 position of centre of circle in Y
- V92 bolt hole circle diameter
- V93 starting angle
- V94 incrementing angle
- V95 number of holes
- V96 hole distribution

V97 angle for hole distribution

- 1 = calculated angle
- 0 = defined angle (V94)

Sequence



Program Construction

- (solution)
- N1 F750
  - N2 V85 = V94
  
  - N3 TST V96
  
  - N4 BEQ P3
  
  - N5 V85 = V97/V95
  
  - N6 §3
  
  - N7 V33 = V93
  - N8 V35 = V95
  
  - N9 BEQ P1
  - N10 V82 = V92/2
  
  - N11 §2
  
  - N12 V80 = SIN V33 V81 = COS V33
  - N13 V83 = V82 x V80 V84 = V82 x V81
  - N14 V84 = V84 + V90 V83 = V83 + V91
  
  - N15 X = V84 Y = V83
  
  - N16 V35 = V35-1
  
  - N17 BEQ P1
  
  - N18 V33 = V33 + V85
  - N19 BRA P2
  - N20 §1
  - N21 G80
  - N22 M2

## **5. TECHNOLOGY**

---

**PROGRAMMING**

**INTERNAL PROCESSING OF TOOL TECHNOLOGY DATA**

When the relevant machining functions are called up the control automatically provides tool compensation according to the tool data in the technology store:

**Tool Geometry**    G40 to G42 tool radius  
                          T            tool length

The compensations for tool length and tool radius and their cancellation are programmed with separate instructions. Once called up the compensations remain active as modal functions. The relevant compensation group must be defined.

Tool radius compensation can be further defined by

G68/69 behaviour at outside corners.

All compensation data can be input via the keyboard after selection of TOOLS by soft key.

Parametric functions can be used to make allocations to tool compensation table data, and compensation data can be copied and applied.

**Feedrate**            The programmed feedrate (F-word) is interpreted in different ways:

G94/95    feedrate in mm per minute or per revolution  
G96/97    cutting speed / spindle speed

The feedrate applies as follows:

with G64    along the programmed contour (cutting point path)  
with G65    along the tool centre path

**Cutting Speed**    With G97    the control forms the spindle speed directly from the active S-word.

The programmer determines the cutting speed by programming the appropriate spindle speed.


With G96 the control calculates and outputs the required spindle speed depending on the S-address (cutting speed), as defined in the technology store, and the used tool radius

**Gear Ranges**        M41-44    direct selection in the program  
                          M40        selection made automatically by the control at the beginning of the block

**TOOL COMPENSATION**

**Definition** The control can convert a part-related program into a tool path.

When a tool compensation is programmed the control will automatically take into account the following tool-related characteristics, which are stored in the technology store:



<b>Tools</b>	L	length	mm
	R	radius	mm
	DR	radius wear	mm
	S	cutting speed	m/sec
		number of compensation groups	max. 48

**Without Tool Compensation** The control can carry out a program without any modification if the machine and the required machining do not require any adjustment. The block processing time is short. Geometry, spindle speed, output signals, and feedrate take effect as programmed.

**External Tool Compensation** This also applies to programs through which the cutter centre path is described by external calculations.

Any demands regarding values, which are to be determined indirectly, such as constant cutting speed, usage of the optimum spindle speed, must be realized through specific values for M and S for the particular program run.

See also chapter 1 INTERFACES for the transmission conditions.

**Compensation Call-up** The tool length compensation is called up via T. The radius compensation is called up with G41/42.


**Cancelling the Tool Compensation** Both tool length and radius compensation are cancelled with T00. G40 cancels the radius compensation alone.

**TOOL LENGTH COMPENSATION**

**ADDRESS T**

The tool length is taken into account when the T-word is called up.  
The effect of T is restricted to the tool length compensation.  
Tool length compensation can be used in all machining modes.

**General  
Format**



**Allocation**

Compensation group and output tool number can be freely combined in the call-up for T.

**Examples**

T can be programmed with 2 or 4 digits.

- |         |   |
|---------|---|
| T 00    | tool length compensation and path compensation are cancelled; no output |
| T 12    | compensation group 12 is selected; no output of number                  |
| T .. 02 | tool number 2 is output; tool length compensation remains unchanged     |
| T 0812  | compensation group 8 is selected; tool number 12 is output              |
| T 1212  | compensation group 12 is selected; the same number is output            |

**Effect**

**The first two digits behind the T (Txx) always effect the tool compensation call-up.**

The 3rd and 4th digits specify the tool number and are output at the interface, if they are programmed. The tool length L, which is stored in the tool table, is incorporated according to the sign into the values for the axis, in which the tool length compensation applies.

The compensation value takes effect  
- immediately for the axis display  
- for the path once the relevant axis is programmed.

**Examples**

	<b>T + Z programmed separately</b>	<b>T and Z programmed together</b>
N2	T08 corrected display for Z-axis	N2 T08 Z50 immediate phasing in of the compensation in Z-axis movement + corrected axis display
N3	Z50 phasing in of tool length compensation	

**Note**

When a tool number is programmed with 4 digits the last two are displayed in automatic mode to show the active tool number.



**TOOL LENGTH COMPENSATION**

**ADDRESS T**

**Call-up**

The tool length compensation is phased in and out during a movement in a linear mode. The feed-in axis is to be programmed on its own.

**Allocation**

Plane	tool length is compensated for in
G17 (X/Y)	Z
G18 (Z/X)	Y
G19 (Y/Z)	X

There are basically two situations in which the tool length compensation is used:

**Programming without consideration of the tool length.**

In this instance the effective length of the tool needs to be stored in the tool table.

The compensation value corresponds to the distance between spindle nose and the tip of the tool.

**Example:**  
complete  
tool length


G1 Z-50 F100 T08  
Content of tool length  $\delta = 100$   
The Z-axis will position to  $-50 + 100 = 50$

**Programming with reference to a zero tool**

When using this original tool, tool compensation value  $L = 0$  is applied. If a new tool is any shorter or longer, the difference  $L_{act.} - L_{orig.}$  is entered into the compensation store.

**Example:**  
difference  
in tool  
lengths

G1 Z50 F100 T08  
Tool length taken into account by the program: = 100 mm.  
Actual length of tool  $\delta = 90$  mm.  
Tool length compensation in Z-axis.  
Plane G17 (X/Y).  
Z will position to 40.



---

**TOOL RADIUS COMPENSATION**

**G40 / 41 / 42**

<b>Definition</b>	<p>The radius compensation converts the contour related part program into a cutter centre path (equidistant). The equidistant runs parallel to the programmed contour at a distance which corresponds to the active cutter radius. The side at which the equidistant runs with respect to the programmed path is determined with G41/G42.</p>
<b>Treatment of Corners</b>	<p>The control calculates</p> <ul style="list-style-type: none"><li>- intersections at inside corners and</li><li>- auxiliary arcs at outside corners (G68) or also</li><li>- intersections at outside corners (G69)</li></ul> <p>Whether G68 or G69 is active on switch-on is determined by M-parameter.</p>
<b>Feedrates F</b>	<p>Feedrate values modal and, when relating to the machining of the part contour, apply</p> <ul style="list-style-type: none"><li>- to the <b>cutting point</b> (G64) or</li><li>- to the <b>cutter centre path</b> (G65)</li></ul>
<b>Cutting Speed</b>	<p>The cutting speed can be determined indirectly by</p> <ul style="list-style-type: none"><li>- the determination of a fixed spindle speed for a given tool radius (G97 + S-word).</li></ul> <p>Alternatively, automatic and direct definition is possible via</p> <ul style="list-style-type: none"><li>- G96 with the S-word in the technology store.</li></ul>
<b>Cutter Radius</b>	
<b>R positive</b>	<p>R is stored in the tool table and represents the cutter radius relevant for the program execution.</p>
<b>R = 0</b>	<p>R can be set to 0 if, for instance due to extreme speed requirements, the part is programmed by describing the tool centre path. The program is then executed without any path compensation.</p>
<b>Tool Wear DR</b>	<p>Additive, small compensation for the nominal tool radius, which, for instance, takes into account the regrinding of the tool.</p> <p>If DR is programmed without sign this corresponds to an increase in the effective tool radius.</p> <p>Detailed description of the functioning of the <b>TOOL COMPENSATION</b> in the relevant chapter.</p>

**STARTING POINT, BEGINNING OF CONTOUR**

**Starting Point** In many cases it is not possible to drive directly onto the contour from the tool change point; usually it is necessary to position to an intermediary position (starting point).


The choice of a suitable starting point helps to avoid damage to the contour. The compensations are phased in during the movement onto this point.

If possible the starting point should allow a tangential approach to the contour, but at least it should be positioned so that there will be no reversal of the direction of any axis at the first contour point (free-cutting).

**Beginning of Contour** A linear workpiece edge should be chosen, otherwise an intermediary linear movement (of at least 3 increments) must be made.

**Compensation Call-up** Compensation call-up must be made while in a linear mode (G0, G1, G61). The block following directly after a call-up (G40, G41, G42) should also be linear.

**Sample Contour without Compensation Call-up**




Call-up of a compensation with positioning of the axis (es) in which the compensation is active:

Example: positioning in Z for call-up of T (XY plane)  
position in XY for G41, G42 (XY plane)

**Phasing in the Radius Compensation** When a radius compensation is called up the control phases in the relevant value in a linear traversing movement. The equidistant starts vertically above the beginning of the first path section for which the compensation is to apply.

ENTRY INTO CONTOUR FROM DIFFERENT STARTING POINTS



S1 - S4

The compensation value is phased in from the starting point to P1 in a linear movement. The contour is fully machined at all points and there is no damage to the contour.

S1

Cleanest contour entry through tangential approach movement.

S2

Good contour entry; starting point can also be used as end point.


S3

Lowest possible starting point without collision, considering contour section ④ - - > ①.

S4

Free-cutting at ① due to a change in direction!

Example with S2 as starting and end point incl. tool compensation




```

N1 G0 Z-10 T01
N2 G1 X-20 Y20 F200
N3 G41 X0 Y0 S500 M3
N4 X20
N5 G2 Y-20 R10
N6 G1 X10
N7 X0 Y0
N8 G40 X-20 Y20
N9 Z300 T00
N10 M2
    
```


**CONTOUR TRANSITIONS WITH G68 (AUXILIARY ARC)**

The following examples show how the tool compensation works on corners, by the generation of auxiliary arcs (outside corners) and the calculation of the angle bisector (inside corners).


**Transitions between linear path sections**



**Transitions between circular path sections**



**Discontinuous transitions**




t = tangential  
u = discontinuous


..... arc generated automatically by the control

CONTOUR TRANSITIONS WITH G69 (INTERSECTION)



Programming  
angular variation 0 to 90°





Execution



angular variation 0 to 90°



angular variation 90 to 180°




... movement generated automatically by the control

EXAMPLES

**G41 on outside contour** Contour programming with tool radius compensation to the left of the workpiece and phasing out of the compensation at the end of the machining.

The tool radius compensation value was stored in the technology table as the R-value.  
(in this example for T1 : R = 2.5 DR = 0.05 L = 250.0 S = 25.0)

— programmed path (workpiece contour)  
- - - corrected path (cutter centre path)




```

N1 G0 X125 Y90
N2 G1 F200
N3 G41 X125 Y60 T01
N4 Y50
N5 X105 Y40
N6 X90
N7 G5 X75 Y25
N8 G1 Y20
N9 X25
N10 Y60
N11 X45 Y80
N12 X70
N13 G3 X100 R15
N14 G1 X125 Y60
N15 Y50
N16 G40 Y20
N17 M2
    
```

**G42 on inside contour** Contour programming with cutter path compensation to the right of the workpiece and phasing out of the compensation at the end of the machining.  
(in this example for T3 : R = 3.25 DR = 0.06 L = 175.0 S = 17.5)

The tool radius compensation value was stored in the technology table as the R-value.



```

N1 G0 X95 Y50
N2 G42 T03 F300
N3 G1 X115 Y50
N4 G5 X130 Y35
N5 G1 Y20
N6 X55
N7 Y30
N8 G1 Y20
N9 G5 X25 Y45
N10 G1 Y70
N11 X40
N12 G3 X70 R15
N13 G1 X100 Y80
N14 X140
N15 Y60
N16 X115
N17 Y50
N18 G40 Y35
N19 M2
    
```

### **END POINT, CANCELLING THE COMPENSATION**

- End Point**            The return from the contour to the tool change point is usually not made directly, but via an intermediary position (end point).
- The choice of a suitable end point helps to avoid damage to the contour, and the tool length compensation can be phased out between the end point and tool change point.
- The end point should, if possible, allow a tangential exit from the contour with active radius compensation. It should be positioned so that there will be no free-cutting due to a change in direction when driving away from the contour.
- End of Contour**            The last section of the contour should be linear. Otherwise a short linear positioning movement (of at least 3 increments) must be inserted past the end of the contour.
- Cancelling the Compensation**            The cancellation must be made while in a linear mode (G0, G1, G61). In cases where the tool radius is relatively large in comparison to the contour radius the block following immediately after the cancellation (G40) must also describe a linear movement.
- With regard to the choice of the end points the same applies as for the choice of the starting point, in principle (see contour entry). The optimum exit movement is the direct extension of the last contour section (in analogy to starting point 1). Starting and end point are different in this case. A joint starting and end point (such as S2) is also possible.
- Referencing is not possible until tool radius compensation has been cancelled
- Cancelling Compensation for Inside**            Even when working within a restricted space the radius compensation must be cancelled in conjunction with a positioning movement, which must at least equal the tool radius.
- Contours**            To keep the required space to a minimum one of two methods should be used:
- continue in the direct extension of the last movement, or
  - move to a position which lies on the same side on which the radius compensation was active, i.e. the right side with G42.
- The recommended programming sequence is as follows (G17/G41 active):
- last contour machining (for instance with G2)
  - tangential exit from the contour in G1 (program X/Y only)
  - retract Z-axis with G1 (program Z on its own)
  - G40 with X/Y movement as an extension of the last movement (program only X/Y)
  - T00 with Z-movement (program Z on its own)
  - program end



## SPECIAL CASES - TOOL COMPENSATION

### CHANGE OF COMPENSATION

There should preferably be no compensation values active when selecting a new tool.

Any active compensation can only be changed for a new block within the contour description. The interpolation mode in the block in which the change is programmed and in the following block must be linear.

**The new compensation value will not be activated until a positioning instruction is carried out in the axis(es) which the compensation applies to.**

Example: G41 X5 Y7 T02 (XY plane)


The new compensation value is phased in gradually to become fully effective at the end of the first block in which the relevant axes carry out a movement.

### SWITCHING BETWEEN G41 and G42

Switching from G41 to G42 and vice versa should preferably take place without radius compensation being active.

If radius compensation is active switching between G41 and G42 is only possible during linear interpolation.

The control will generate an adjusting movement which must be taken into account during the programming!



For instance: Section P0 --> P1 can be extended to P1', and similarly P2 --> P3 can be started at P2', in order to achieve a smooth change-over movement.


In some cases it might be necessary to cancel compensations via G40, program intermediary positions, and make a new compensation call-up with G41/G42. The minimum length of path sections with which a compensation can be called up or cancelled is 3 increments.

**Example 1 Direct entry into and exit from contour**

Tool radius compensation is used (G17 active).

The contour entry and exit movements overlap.

Contents of tool table for T03 : R = 3.25 DR = 0.06 L = 175.0 S = 1.75



```

Program
N1 G0 X0 Y0 Z0
N2 G1 X65 Y35 F200
N3 G41 Y55 T03
N4 X35
N5 G3 Y15 R20.0
N6 G1 X90
N7 G3 Y55 R20.0
N8 G1 X60
N9 G40 Y35
N10 M2
    
```

— programmed path  
 - - - corrected path  
 . . . contour

**Example 2 Tangential entry into and exit from contour**


Tool compensations for length and radius (G17 active).

The max. possible tool diameter corresponds to the width of the keyway - 1 inc.

The compensations are phased in and out above the workpiece, which makes this procedure suitable for very limited spaces.

When activating or cancelling a compensation only the axis(es) involved in the radius compensation should be moved.

In the program below the tool table contains the following for T10 : R = 8.0 DR = 0 L = 0 S = 0



```

Program
N1 G0 Z5 M3 T10
N2 G42 X70 Y10
N3 G1 Y30 F200
N4 Z-2 F50
N5 G2 X90 Y50 R-20 F250
N6 G2 X90 Y10 I90 J30
N7 G1 X30
N8 G2 X30 Y50 I30 J30
N9 G1 X90
N10 G5 X90 Y11
N11 G1 Z5 F2000 M5
N12 Y50
N13 G40 X81 Y60
N14 Z100
N15 M30
    
```


To cancel the compensation (G40) a movement is required from 7 to 8 in Y positive, or in Y and X positive direction.

Recommended exit via end point such as E, E', E'' etc.; exit via end point such as N not recommended. Contour might be disturbed.

**SUPPRESSION  
OF CONTOUR  
ELEMENTS**


Not all programmed contour elements can be machined because of the radius of the used tool.

Programmed contour




Execution with G68

1. All contour elements are machined.




2. One element is suppressed, since tool radius is larger than contour element.



**Note:** If more than one contour element can not be machined due to the geometrical data the control will interrupt the machining and output an error message.


**Cancelling  
Compensation  
on Inside  
Corners**

Programmed contour




Cancelling compensation with different end points

1. All programmed contour elements are machined correctly.




2. One contour element is damaged.




E = end point programmed in conjunction with G40 for the cancellation of the radius compensation

**OUTSIDE CORNERS**


angular variation alpha  
between 0 and 90°



execution with G68




execution with G69




angle alpha larger than 90°  
and smaller than 180°


programmed contour




identical execution with G68/69




steps  
tool radius larger than  
contour radius



execution with G68



execution with G69





**6. APPENDIX**

**PROGRAMMING KEY**

G-CODES	Code	Functions	Group
	0	XYZE Positioning in rapid, with	a
	1	XYZE Linear interpolation at programmed feedrate	a
	2	xxR Circular interpolation, clockwise, 2 axes	a
	3	xxR Circular interpolation, counter-clockwise, 2 axes	a
	4	F Dwell in seconds	
	5	xxx Circular interpolation with tangential entry, 2 axes	a
	6	XYZE Linear interpolation in rapid with extended IN POS range	a
	17	Plane selection X/Y	b
	18	Plane selection Z/X	b
	19	Plane selection Y/Z	b
	20	XY Setting pole for polar coordinates	
	21	P Subprogram call-up depending on I/F signal	
	22	PL Subprogram call-up, unconditional	
	23	PL Jump to program label depending on I/F signal	c
	24	P Jump to program label, unconditional	c
	25	XYZE Field limitation, setting minimum values	d
	26	XYZE Field limitation, setting maximum values	d
	27	XYZE Cancelling field limitation	d
	36	- Scale factor switching	e
	38	xx Switch on programmable mirroring	e
	39	xx Switch off programmable mirroring	e
	40	Cancelling tool radius compensation	c
	41	xx Tool radius compensation to the left of the path	c
	42	xx Tool radius compensation to the right of the path	c
	53	Cancel zero shift	f
	54 to	Switch on zero shift	f
	59	XYZE	
	61	XYZE 'In Position' function on	g
	62	XYZE 'In Position' function off	g
	63	Feedrate and spindle speed set to 100%	h
	64	Feedrate applies to contour on circular contours	i
	65	Feedrate applies for tool centre path	i
	66	Feedrate/spindle speed can be modified via pot.	h
	68	Auxiliary arc on outside corners	j
	69	Intersection on outside corners	j
	74	Referencing	
	75	Measuring probe	
	80	Cancel fixed cycles G81 to G89	k
	81	V Drilling, centering	k
	82	V Boring with dwell	k
	83	V Deep hole drilling with positioning movements in rapid	k
	84	V Tapping with dwell	k
	85	V Boring with dwell/oriented spindle stop	k
	86	V Reaming	k
	87	V Thread milling	k
	90	XYZE Input in absolute dimensions	l
	91	XYZE Input in incremental dimensions	l
	92	XYZE Setting position stores	c
	S	Setting top limit for spindle speed	d
	93	S Time programming	
	94	F Feedrate direct in mm/min	m
	95	F Feedrate in mm/rev	m
	96	S Automatic calculation of cutting speed	n
	97	S Direct spindle speed programming	n
	99	Subprogram end	
	800to	Customer cycles: call-up via G-functions	
	889	with corresponding numbers	

Group identifications a to n: Functions of the same group exclude one another.

**G-CODES      3-digit**

Code	Function	Group
<b>Contour Cycles</b>		
890 V	intersection circle/circle	0
981 V	intersection line/circle	0
892 V	rounding corners (3 points)	0
893 V	rounding corners (2 angles)	0
894 V	chamfering	0
895 V	calculation of end point of arc	0
896 V	transition point arc/arc tangential	0
897 V	end point of straight line	0
898 V	intersection line/line	0

**Machine specific G-codes (cycles)**

Code Call-up	Function

<b>M-CODES</b>	<b>system specific functions</b>
Code	Internal effect
M0	program stop after execution of the block
M2	main program end, cycle end
M3 / M13	main spindle on CW / coolant on
M4 / M14	main spindle on CCW / coolant on
M5	main spindle stop / coolant off
M6	call-up of the automatic tool change cycle (cycle 77)
M19	orientation of main spindle to fixed position
M19(S. )	orientation of main spindle to programmable position (degrees)
M21	call-up of MTB cycle 76
M22	call-up of MTB cycle 75
M30	program end with return to beginning (continuation with Cycle Start)
M40	automatic gear range selection
M41-44	selection of fixed gear range 1 to 4
M98	SINGLE BLOCK command is not accepted
M99	SINGLE BLOCK command is possible, i.e. the effect of M 98 is cancelled

**MACHINE SPECIFIC M-FUNCTIONS**

Code	Function
------	----------



Parametric Functions

Instruction	Function	CR set	Time
V1 = n	load a numerical value	X	
X = V <sub>n</sub> , m = V <sub>n</sub> m = XYZZEIJKADGFRST	execution instruction		
V <sub>n</sub> = X, V <sub>n</sub> = p p = XYZZEIJKADFRST	transfer active data		
V1 = V2 + V3 (V1 = V1 + 10)	addition	X	
V1 = V2 - V3 (V1 = V2 - 12)	subtraction	X	
V1 = V2 * V3 (V1 = V2 * 10)	multiplication	X	
V1 = V2/V3 (V1 = V2/2)	division	X	
V1 = V2	copy	X	
V1 = SQR V2	square root	X	
INC V1	increment value, delete digits after decimal point	X	
DEC V1	decrement value, delete digits after decimal point	X	
V1 = SIN V2 (degrees)	sine ( $360^\circ \leq V2 \leq 360^\circ$ )	X	
V1 = COS V2 (degrees)	cosine ( $-360^\circ \leq V2 \leq 360^\circ$ )	X	
V1 (degrees) = ATG V2	arc tangent	X	
BSR V1 (BSR P5)	jump to subprogram (label 5) with no. V1		
BRA V1 (BRA P5)	jump to label no. V1 (label 5)		
BEQ V1 (BEQ P5)	jump to label no. V1, (label 5) if CR = 0		
BNE V1 (BNE P5)	jump to label no. V1, (label 5) if CR = 0		
BGT V1 (BGT P5)	jump to label no. V1, (label 5) if CR > 0		
BLT V1 (BLT P5)	jump to label no. V1, (label 5) if CR < 0		
BGE V1 (BGE P5)	jump to label no. V1, (label 5) if CR ≥ 0		
BLE V1 (BLE P5)	jump to label no. V1, (label 5) if CR ≤ 0		

Note: CR = condition register; time = execution time in ms

Instruction	Function	CR set	Time
COR = V1 R = V2 L = V3 DR = V4 S = V5 (COR = T1)	load tool no. V1 with values		
COR = T10 V1 = R V2 = L... (COR = T10)	copy values from tool no. 10		
TRF = V1 X = V2 Y = V3 Z = V4 E = V5 (TRF = G54)	load zero shift no. V1 with values		
TRF = G54 V1 = X V2 = Y V3 = Z V4 = E (TRF = G54)	copy values from the G54 table		
TRF = G20 V1 = X V2 = Y...	copy active pole		
TST V1	compare V1 with 0. set CR accordingly	X	
TST G1, TST G <sub>n</sub> n=0-3,17-19,36,39,53-59,62,63, 65,66,90,93,94,95,97	CR = 0 if G01 active  CR = 0 if G <sub>n</sub> active	X  X	
TST M41, TST M <sub>n</sub>  n = 3, 4, 5, 13, 41 - 44	CR = 0 if M41 active  CR = 0 if M <sub>n</sub> active	X  X	
TST QX, TST Q <sub>n</sub>  n = X,Y,Z,E	CR = 0 if X-axis mirrored  CR = 0 if <sub>n</sub> -axis mirrored	X  X	
TST QM	CR = 0 if metric dimensions	X	
TIM V1	record time from program start in seconds		
POS X (Y, Z, E)	axes traverse with external command		
STV	updating variables		

**Axis Information**

Format: +/- 7 digits, for instance 1.234567 or 123456.7

<b>X</b>	- X-axis	(mm/inch)
<b>Y</b>	- Y-axis	(mm/inch)
<b>Z</b>	- Z-axis	(mm/inch)
<b>E</b>	- E-axis	(mm/inch/degrees)
<b>I</b>	- centre of circle (X-direction)	(mm/inch)
<b>J</b>	- centre of circle (Y-direction)	(mm/inch)
<b>K</b>	- centre of circle (Z-direction)	(mm/inch)
<b>R</b>	- radius	(mm/inch)
<b>D</b>	- vector length (polar coord.)	(mm/inch)
<b>A</b>	- angle (polar coord.)	(degrees)

**M-functions  
Auxiliary  
Functions**

**M** (0..99) M-function (M0, 2,3,4,5,6,13,14,19,21,22,40, 41,42,43,44,98,99 have a predetermined internal effect)

**T** xx xx (0..99) tool number (output as location number)  
 └──────────┬──────────┘  
 (0..48) compensation group (activates tool length compensation)

**F** (0.001 .. 120000) feedrate (mm/min) or (mm/rev)  
 time (sec)

**S** (0..9999) spindle speed (rpm)

**Subprograms  
and  
Jumps**

**\$** (0..99) jump address or beginning of subprogram  
**P** (0..99) SBP number / label number (used in call-up)  
**L** (0..99) number of SBP repetitions (used in call-up)

**Special  
Characters**

(.....) texts and comments  
**N** (1..9999) block number  
**V** (1..99 and A..Z) CPC variables

**Control  
Characters**

**STX** - Start of Text (beginning of a data block such as a part program)  
**ETX** - End of Text (end of a data block, such as a tool table)  
**EOT** - End of Transmission (end of the transmission of one or several data blocks)  
**CR LF** - Record Separator (separates two records, such as 2 NC blocks).

**ASCII - Set of Characters**


ASCII Character	Parity Bit	7-Bit Code	ASCII Character	Parity Bit	7-Bit Code	Meaning of the Character
A	0	1000 001	NUL	0	0000 000	0
B	0	1000 010	SOH	1	0000 001	start of header
C	1	1000 011	STX	1	0000 010	start of text
D	0	1000 100	ETX	0	0000 011	end of text
E	1	1000 101	EOT	1	0000 100	end of transmission
F	1	1000 110	ENQ	0	0000 101	enquiry
G	0	1000 111	ACK	0	0000 110	positive acknowledgement
H	0	1001 000	BEL	1	0000 111	bell
I	1	1001 001	BS	1	0001 000	back space
J	1	1001 010	HT	0	0001 001	horizontal tabulator
K	0	1001 011	LF	0	0001 010	line feed
L	1	1001 100	VT	1	0001 011	vertical tabulator
M	0	1001 101	FF	0	0001 100	form feed
N	0	1001 110	CR	1	0001 101	carriage return
O	1	1001 111	SO	1	0001 110	shift out
P	0	1010 000	SI	0	0001 111	shift in
Q	1	1010 001	DLE	1	0010 000	data link escape
R	1	1010 010	DC1	0	0010 001	DC on
S	0	1010 011	DC2	0	0010 010	control 2
T	1	1010 100	DC3	1	0010 011	DC off
U	0	1010 101	DC4	0	0010 100	control 4
V	0	1010 110	NAK	1	0010 101	negative acknowledge
W	1	1010 111	SYN	1	0010 110	synchro
X	1	1011 000	ETB	0	0010 111	end of transmission block
Y	0	1011 001	CAN	0	0011 000	cancel
Z	0	1011 010	EM	1	0011 001	end of medium (paper)
			SUB	1	0011 010	substitute
0	0	0110 000	ESC	0	0011 011	escape (code switching)
1	1	0110 001	FS	1	0011 100	file separator
2	1	0110 010	GS	0	0011 101	group separator
3	0	0110 011	BS	0	0011 110	block separator
4	1	0110 100	US	1	0011 111	unit separator
5	0	0110 101	SP	1	0100 000	space
6	0	0110 110	!	0	0100 001	
7	1	0110 111	"	0	0100 010	
8	1	0111 000	#	1	0100 011	
9	0	0111 001	\$	0	0100 100	
			%	1	0100 101	
a	1	1100 001	&	1	0100 110	
b	1	1100 010	'	0	0100 111	
c	0	1100 011	,	0	1100 000	
d	1	1100 100	(	0	0101 000	
e	0	1100 101	)	1	0101 001	
f	0	1100 110	*	1	0101 010	
g	1	1100 111	+	0	0101 011	
h	1	1101 000	,	1	0101 100	
j	0	1101 001	-	0	0101 101	
j	0	1101 010	.	0	0101 110	
k	1	1101 011	/	1	0101 111	
l	0	1101 100	:	0	0111 010	
m	1	1101 101	;	1	0111 011	
n	1	1101 110	<	0	0111 100	
o	0	1101 111	=	1	0111 101	
p	1	1110 000	>	1	0111 110	
q	0	1110 001	?	0	0111 111	
r	0	1110 010	@	1	1000 000	
s	1	1110 011	[	1	1011 011	
t	0	1110 100	\	0	1011 100	
u	1	1110 101	]	1	1011 101	
v	1	1110 110	^	1	1011 110	
w	0	1110 111	-	0	1011 111	
x	0	1111 000	{	0	1111 011	
y	1	1111 001		1	1111 100	
z	1	1111 010	}	0	1111 101	
			~	0	1111 110	
			DEL	1	1111 111	

**OUTPUT OF ERROR MESSAGES**

**Definition**

The CC 100 M will transmit errors recognized internally to the interface controller. The error messages are output in coded form, one digit to indicate the error message group (0-2) and two further digits to indicate the error number (01 - 88).

**Example**



**Soft key operation  
for error display**

1. **EDIT**      Incorrect program blocks are automatically displayed with error numbers and descriptions.
  
2. **MACHINE**      Incorrect entries in MDI are displayed automatically with error numbers and descriptions.
  
3. **AUTOMATIC**      Incorrect program blocks, which are not recognized until RUN operation, cause program stop and a general error signal. To obtain information about the type of error you need to switch into INFO mode; there the error number and the description will be displayed.

Error message group 0:

A14 D0

Data	Meaning
1	syntax error
2	syntax error
3	
4	system error H-Size overflow
5	system error N-H-Size overflow
6	system error L-H-Size overflow
7	system error R-Size overflow
8	system error D-Size overflow
9	
10	repetition (L) without subroutine call
11	cutter comp. programmed without tool
12	this G code must be alone in block
13	this G/M code is not allowed with TEACH IN or MDI
14	max. 3 axes or A, D allowed
15	R or I, J, K not allowed
16	max. 2 axes out X, Y, Z allowed
17	TIM, COR, or TRF must be alone in block
18	max. 4 axes with value allowed
19	max. 4 without value allowed
20	max. 2 axes out of X, Y, Z, E or A, D allowed
21	enter Dwell time (F)
22	unadmissible G number
23	enter S without sign.
24	value too large
25	with D, F, or R, zero not allowed
26	repetition of address not allowed
27	max. 2 coordinates out of I, J, K allowed
28	no radius programmed with polar coordinates
29	max. 2 axes with polar coordinates (A, D)
30	max. 3 axes R or I, J, K
31	enter jump target (P)
32	jump target (P) allowed with G21/22/23/24
33	G code required with P or L
34	axis without value not allowed
35	only integer value
36	this M code must be alone in block
37	test not allowed
38	unadmissible tool number
39	E axis must be programmed alone
40	input range 1 to 127
41	with G 96, S value not allowed
42	with G 92, S value not allowed
43	max. 4 axes or A, D allowed
44	axis value not allowed
45	max. 2 digits with \$,P,L or M

**Error message group 0:**

**A14 D0**

Data	Meaning
46	only 2 or 4 digits with T
47	too many digits
48	max. 1 axis with value allowed
49	max. 4 digits with S
50	sign. not allowed
51	input range 0.001 to 5
52	enter value
53	Y(es) or N(o) required
54	
55	input range 0 to 999
56	input range 1 to 720
57	input range 0 to 4
58	input range 0 to 20000
59	input range 0 to 50000
60	input range 0 to 90000
61	input range 1 to 1000
62	input range -9999 to 9999
63	input range 0 to 100
64	input range 0 to 3
65	input range 0 to 359.999
66	input range 0 to 5
67	input range 1 to 100
68	E not allowed
69	F not allowed with G0
70	only X, Y, Z allowed
71	only P, L allowed
72	only X, Y, Z, E allowed
73	only X, Y, Z, E or M, T allowed
74	only X, Y, Z, E or F, S, M allowed
75	only X,Y, Z, E or S allowed
76	input range -100 to 100
77	DR value = -10 % to +10 % of R (1 mm or 0.05 i max)
78	input range 1 to 50000
79	with TEACH IN or MDI P, L not allowed
80	M 19 must be programmed alone or with S
81	incorrect input of variables
82	incorrect variable number
83	input range 12 to 48
84	input range 256 to 32767
85	M 06 must be programmed alone or with tool number
86	input range -10000 to 1 or to 10000
87	input range 0 to 9999
88	address modification must be alone in block
89	message has to start with "("

**Error message group 1:**

**A14 D1**

<b>Data</b>	<b>Meaning</b>
1	no previous movement before G5
2	full circle programming not allowed
3	radius value null or missing
4	negative root
5	G code not allowed in automatic mode
6	bad polar radius programmed
7	G95 and M5 or S value = 0
8	
9	G5 not allowed following G0
10	
11	incorrect circle definition
12	centre coordinates incorrect
13	programmed radius was rounded
14	tool radius too large (1)
15	tool radius too large (2)
16	tool radius too large (3)
17	tool radius too large (5)
18	no intersection possible parallel lines
19	no intersection possible line / circle
20	no intersection possible circle / circle
21	tool radius too large (4)
22	the circles are not tangent
23	M 30 or M 2 required
24	jump target not found
25	max. 10 subroutine levels
26	cycle does not exist
27	G99 and no subroutine active
28	M2 or M30 seen with cutter comp. active
29	G code not allowed with cutter comp. active
30	Highest spindle speed exceeded
31	1. gear range defined incorrectly
32	M3 or M4 missing
33	gear range inadmissible
34	G99 with subroutine or M2 with cycle
35	no feed programmed with G75/94/95/93
36	
37	
38	
39	input missing
40	rotary axis with circular interpolation
41	incorrect position programmed with E axis
42	cycle end is M2
43	subroutine end is G99
44	preset not allowed with active zero shift

The control will display the messages in clear text.



**Error message group 1:**

**A14 D1**

Data	Meaning
45	cycle unadmissible with cutter comp.
46	unadmissible value for G code
47	G code unadmissible with mirror function
48	G code unadmissible with cutter comp.
49	
50	
51	
52	one movement missing for cutter comp.
53	
54	block modified or not executed due to cutter comp.
55	max. 2 axes out of X, Y, Z, E or A, D allowed
56	V95 must be 0 or 1
57	transfer not possible
58	reentry not allowed with G84
59	probe not triggered
60	unadmissible jump target
61	double definition of axis (polar)
62	max. 1 axis with G2/3/5 and polar programming
63	max. 3 axes with G2/3/5
64	G0/1/5 and radius or I, J, K not allowed
65	G2/3 with radius and I, J, K not allowed
66	no new cutter comp. with G2/3/5
67	G21/23 with cutter comp. not allowed
68	cutter comp. not allowed without tool number
69	G40/41/42 not allowed with G2/3/5
70	no G2/3/5 following a zero shift
71	
72	G96 not allowed with S value
73	spind. speed calcul. not possible, tool radius = 0
74	G92 not allowed with G41/42/T
75	G code not allowed with cut. or length comp.
76	new plane not allowed with cutter comp.
77	V95 must equal 2 or 3
78	division by zero
79	coordinates do not comply with active plane
80	no tool active
81	unadmissible tool number
82	unadmissible G number
83	V91 must equal 1 or 2
84	this zero shift is already active
85	DR value = -10 % to +10 % of R (1 mm or 0.05 i max.)
86	spindle orientation not possible
87	calculation not possible
88	angle range -180 to +180 deg.

The control will display the messages in clear text.

**Error message group 2:**

**A14 D2**

Data	Meaning
1	99 programs exist
2	memory full
3	memory too small for jump target table
4	check sum error
5	undefined jump target
6	parity memory
7	duplication of jump target
8	69 CYCLES exist
9	memory too small to copy
10	file protected
11	
12	unadmissible file
13	file already exists
14	device not ready
15	parity error
16	incorrect data format
17	incorrect baud rate
18	timeout period expired
19	no corresponding file type
20	TEACH IN
21	movement not allowed with E, 2 blocks created
22	memory error, switch off
23	reference cycle does not exist
24	interruption, abort with clear block
25	inch / metric selection incorrect
26	no corresponding cycle
27	undefined key
28	reference not allowed with length comp.
29	movement not allowed, 2 blocks created
30	
31	warning sent by PLC
32	too many characters for one block
33	bad value for tool table size
34	size of memory changed, memory cleared
35	no machine reference, send axes to reference
36	
37	
38	
39	circle calculation not possible
40	limit

Data	Meaning
41	emergency stop
42	servo error
43	measuring system: marker missing
44	measuring system: not connected
45	measuring system: pulse is lost
46	measuring system: no feedback
47	bad axes parameters
48	gearbox not OK
49	interpolator stop error
50	axis error
51	code:
52	T (s)
53	/mn
54	/rev
55	conflict between hardware and software, NC stopped

**A**

- Access levels 2 - 3
- Addition 4 - 7
- Addresses 3 - 14
- Arc tangent 4 - 9
- Arithmetic functions 4 - 7
- ASCII character set 6 - 10
- ASCII control characters 1 - 7 6 - 3
- Automatic 2 - 9

**B**

- Battery 1 - 5
- BEQ / BGE / BGT / BLE / BLT / BNE 4 - 15
- Block number 3 - 3
- Block selection 2 - 4
- Boring 3 - 61
- Boring cycles 3 - 49
- BRA 4 - 12
- Branching conditinal 4 - 13
- Branching unconditional 4 - 12
- BSR 4 - 12
- Buffer battery 1 - 5

**C**

● Calculation cycles	3 - 76	
● Calculation end point - straight line	3 - 85	
● Calculation end point - arc	3 - 83	
● Cancelling compensation	3 - 41	5 - 11
● Chamfering	3 - 81	
● Change compensation	5 - 12	
● Checksum	1 - 22	
● Circular interpolation	3 - 22	
● Commands	2 - 3	
● Component parts	1 - 2	
● Conditional jump	3 - 34	4 - 13
● Conditional subroutine call	3 - 31	
● Condition register	4 - 13	
● Contour cycles	3 - 76	
● Contour transitions	3 - 46	5 - 8
● Control signals	1 - 6	
● Control characters	6 - 3	
● Copy tool data	4 - 10	
● COR	4 - 10	
● Corner rounding	3 - 81	
● Cosine	4 - 9	
● CPC programming	4 - 1	
● CP/MEM	1 - 5	
● Cursor function	2 - 4	
● Cutter centre path	3 - 45	
● Cutting path	3 - 45	
● Cutting speed	5 - 1	
● Cutting speed calculation	3 - 72	
● Cycles	2 - 21	3 - 2
● Cycles, MTB fixed	3 - 87	

**D**

● Data interfaces	1 - 5	2 - 20	
● Data interfaces V.24	1 - 6		
● Data interfaces 20 mA	1 - 6		
● Data lines	1 - 9		
● Decrement	4 - 8		
● Deep hole drilling	3 - 51		
● Delete	2 - 4	2 - 14	2 - 23
● DFS header	1 - 19		
● Dimensional units	2 - 3	2 - 5	2 - 15
● Dimensioning	3 - 67		
● Division	4 - 7		
● Drilling	3 - 55		
● Drip feeding	3 - 9		
● Dwell time	3 - 27		

**E**

● Edit	2 - 3		
● Editor	2 - 4		
● Effect of feedrate	3 - 45		
● End point calculations	3 - 83	3 - 85	
● Entry into contour	5 - 7		
● Error messages - display	2 - 2		
● Error message listing	6 - 9		
● Error messages - output	6 - 8		
● External VDU monitor	1 - 5		

**F**

- F-address 3 - 14
- Feed, linear interpolation 3 - 21
- Feedrates 3 - 70 5 - 1
- Feedrate 100% 3 - 44
- Field limitation 3 - 36
- File header 6 - 3
- Fixed cycles 3 - 49, 3 - 75, 3 - 87
- Fixed MTB cycles 3 - 87
- Fixed machining cycles 3 - 49
- Forms 4 - 3

**G**

- G-functions 3 - 20
- G-code, three digit 3 - 75
- Gear ranges 3 - 16

**H**

- Header 1 - 16

I/J

- I-address 3 - 22
- Increment 4 - 8
- Information 2 - 13
- Inch/metric switching 2 - 18
- In position logic 3 - 43
- Insert 2 - 4
- Interface V.24 1 - 5
- Interface 20 mA 1 - 5
- Interpolation in feed 3 - 21
- Interpolation in rapid 3 - 20
- Intersection circle / circle 3 - 78
- Intersection line / circle 3 - 79
- Intersection line / line 3 - 86
  
- J-address 3 - 22
- Joining 3 - 80
- Jump after comparison 4 - 16
- Jump conditional 3 - 34 4 - 13
- Jump instructions 3 - 5 3 - 32 4 - 12
- Jump unconditional 3 - 35 4 - 12

K

- K-address 3 - 24
- Keys, programmable 3 - 87



**L**

- L-address 3 - 32
- Linear interpolation in feed 3 - 21
- Linear interpolation in rapid 3 - 20
- Linear interpolation in rapid with  
extended in position range 3 - 28
- Load functions 4 - 6
- Load tool store 4 - 10

**M**

- M-address 3 - 15
- Machine 2 - 5
- Machine status display 2 - 14
- Main modes 2 - 1
- Manual machine operation 2 - 5
- Manual panel 1 - 4
- Measuring probe input 3 - 48
- Memory 2 - 3
- Memory allocation 3 - 2
- Messages 6 - 9
- Minicass operation 1 - 15
- Mirroring 3 - 39
- Modify 2 - 4 2 - 6
- MTB cycles 3 - 87
- MTB service 2 - 13
- Multiplication 4 - 7

**N/O**

- N-address 3 - 3
- Operating panel 1 - 3
- Operating panel connection 1 - 5
- Operating program 1 - 5
- Operator instruction programming 3 - 18
- Outside corners 5 - 15

**P/Q**

- P-address 3 - 31 4 - 12 4 - 15
- Panel 1 - 3
- Part programs 2 - 20 3 - 2
- Plane selection 3 - 28
- Polar coordinates 3 - 30
- Position stores 3 - 68
- Priority routine 3 - 87
- Program header in DFS format 1 - 19
- Programming code 6 - 1
- Programming key 6 - 1
- Program planning 4 - 2
- Program production 3 - 1
- Program transfer 2 - 20
- Programs 2 - 21 3 - 2

**R**

● R-address	3 - 23		
● Radius compensation	3 - 41	5 - 2	5 - 5
● Rapid, linear interpolation	3 - 20		
● Reaming	3 - 63		
● Reentry	2 - 10		
● Reference axes	2 - 5	3 - 47	
● Reference cycle	2 - 5	3 - 87	
● Registering time	4 - 8		
● Reset	2 - 13		
● Reset conditions	2 - 2		
● Rounding corners	3 - 79		

**S**

● S-address	3 - 16		
● Setting a pole	3 - 30		
● Setting condition register	4 - 13		
● Setting position stores	3 - 68		
● Sine	4 - 9		
● Spindle speed	3 - 72		
● Spindle speed 100%	3 - 44		
● Square root	4 - 7		
● Start conditions	2 - 2		
● Status display	2 - 13		
● Subdivision of VDU display	2 - 2		
● Subroutine call	3 - 5	3 - 33	
● Subroutine call, conditional	3 - 32		
● Subroutine end	3 - 74		
● Subtraction	4 - 7		
● Suppression of contour elements	5 - 14		

**T**

- T-address 3 - 14 5 - 4
- Tangential entry 3 - 26
- Tapping 3 - 59
- Teach In 2 - 7
- Terminal V.24 1 - 5
- Terminal 20 mA 1 - 5
- Thread milling 3 - 65
- Three digit G-codes 3 - 75
- TIM 4 - 8
- TRF 4 - 11
- Time programming 3 - 27 3 - 70 4 - 8
- Time registering 4 - 8
- Tool compensation 3 - 41 5 - 1
- Tool data transmission 2 - 25 3 - 19
- Tool length com. 5 - 3
- Tools 3 - 19 4 - 10 5 - 1
- Tool store loading 4 - 10
- Tool technology 5 - 1
- Transition point arc/arc 3 - 84
- Trigonometric functions 4 - 9

**U**

- Unconditional branching 4 - 12
- Unconditional jump 3 - 35
- User programmable keys 3 - 87

**V**

- Variables 2 - 12 2 - 25 3 - 19 5 - 1
- Variable transmission 2 - 25 3 - 19
- VDU monitor 2 - 2
- V.24 interface 1 - 5

**W/X/Y/Z**

- X-address 3 - 3
  
- Y-address 3 - 3
  
- Z-address 3 - 3
- Zero shifts 2 - 25 3 - 19 3 - 42 4 - 11
- Zero tool 5 - 4