

SIEMENS

Add 7 AddFEM (Front End Module)

Manual

Edition 07/2012

SIEMENS

Add 7

AddFEM Front End Module Manual

Preface
Table of contents




Fields of application	1
Configuration	2
Mode of operation	3
Technical specifications	4
Commissioning, operation, maintenance	5
Appendix	A

A5E00075541C-06

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.
NOTICE
indicates that property damage can result if proper precautions are not taken.


If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Preface

Product family Add 7

The Add-on products of the Add 7 product family provide a cost-effective solution for the specific high-performance requirements in the field of process control and automation engineering. The design of these products is based on many years of experience in the field of process engineering, and on solid expertise with respect to the current system generation in the Siemens "Totally Integrated Automation" program.

As part of the Add 7 product family, the AddFEM Front End Module satisfies the special requirements of high-speed turbine control systems (different signal types, redundancy, high-speed detection and signal preparation etc.)

Enhancement to module type 6DL3100-8AC compared to 6DL3100-8AA

6DL3100-8AC offers the option of operating the AddFEM in redundant mode (module redundancy), and/or to process signal preparation functions on the AddFEM.

The AddFEM 6DL3100-8AC can be programmed in RUN using DPV1 services.

Further support

If you have any questions about the use of the products described in this manual and do not find the right answers, please contact your Siemens partner at your local Siemens Office or Agencies.

CE Label

Our products are compliant with EC Directive 2004/108/EC "Electromagnetic Compatibility, EC Directive 73/23/EEC "Low-voltage Directive", and the European Harmonized Standards specified in those directives (EN).



You can view the EC Declaration of Conformity in the appendix. It is available to responsible authorities, according to the EC Directives mentioned earlier, at:

Siemens Aktiengesellschaft
Industry Sector Industry Automation Division
I IA CE SE PRM EN
Siemensallee 84
D 76181 Karlsruhe

Table of contents

1	Fields of application	1-1
1.1	Classification and features	1-2
1.1.1	Enhancement of 6DL3100-8AC variant (compared to -8AA/-8AB).....	1-4
1.1.2	Driver blocks	1-6
2	Configuration.....	2-1
2.1	AddFEM configuration	2-2
2.2	Connecting elements.....	2-3
2.3	Device model – module allocation (when using PCS 7)	2-5
3	Mode of operation	3-1
3.1	General functions	3-2
3.2	Operating principle of 2-channel speed monitoring with detection of the rotational direction	3-3
3.3	Operating modes	3-5
3.4	Redundancy functionality with AddFEM.....	3-7
3.4.1	Redundant PROFIBUS DP connection	3-9
3.5	Signal preparation functions with AddFEM (applies only to 6DL3100-8AC).....	3-11
4	Technical specifications	4-1
4.1	Technical specifications.....	4-2
4.2	Safety, environmental conditions and EMC	4-13
4.3	Processing times	4-17
5	Commissioning, operation, maintenance.....	5-1
5.1	Installing the AddFEM	5-2
5.2	Interconnection of the process signals	5-8
5.3	Operator control and display elements.....	5-17
5.4	Setting the PROFIBUS DP address	5-22
5.4.1	Setting the address of PROFIBUS DP A using the key switch and slide switch.....	5-22
5.4.2	Setting the address of PROFIBUS DP B using the key switch and slide switch.....	5-26
5.4.3	Verifying the PROFIBUS DP address setting.....	5-28
5.4.4	Resetting the AddFEM	5-28
5.4.5	Setting the PROFIBUS DP address in SIMATIC Manager	5-29
5.5	Resetting errors with module redundancy.....	5-30
5.6	Configuring the AddFEM	5-32

5.6.1	Adjustable parameters.....	5-33
5.6.2	Integration in automation systems.....	5-34
5.7	Troubleshooting.....	5-36
5.7.1	Failure and hot-swapping redundant AddFEMs.....	5-36
Appendix		1
A.1	Front connector pin assignment.....	1
A.2	EC Declaration of Conformity.....	3

Figures

Fig. 2-1	AddFEM, front view.....	2-2
Fig. 2-2	24 V DC module supply.....	2-3
Fig. 2-3	Device model – module allocation.....	2-5
Fig. 3-1	Mode 0.....	3-6
Fig. 3-2	Mode 1.....	3-6
Fig. 3-3	Mode 2.....	3-6
Fig. 3-4	Mode 3.....	3-6
Fig. 3-5	System configuration with two redundancy nodes.....	3-9
Fig. 3-6	Redundant PROFIBUS DP connection.....	3-10
Fig. 4-1	Trend of digital inputs with tolerances of input current le.....	4-4
Fig. 4-2	Count pulse inputs, current-/voltage diagramm including tolerances of input current le.....	4-7
Fig. 5-1	Dimensional drawing of the DIN rail mounting.....	5-3
Fig. 5-2	Dimensional drawing of screw-mounting.....	5-4
Fig. 5-3	24 V DC module power supply.....	5-5
Fig. 5-4	Process connector.....	5-8
Fig. 5-5	Wiring current inputs (non-redundant).....	5-9
Fig. 5-6	Wiring of current inputs (redundant wiring).....	5-10
Fig. 5-7	Configuration of redundancy diodes for redundant power supply.....	5-11
Fig. 5-8	Wiring voltage inputs with floating encoders.....	5-12
Fig. 5-9	Wiring voltage inputs to ground reference at encoder end.....	5-13
Fig. 5-10	Wiring of AddFEM analog inputs with simultaneous use of current and voltage inputs.....	5-14
Fig. 5-11	Possible redundancy configurations.....	5-15
Fig. 5-12	Operator controls of AddFEM and PROFIBUS DP address display.....	5-23
Fig. 5-13	Assigning the PROFIBUS DP address in SIMATIC Manager.....	5-29

Tables

Table 5-1	Display of operating states at the error/status LED.....	5-19
Table 5-2	Description of the error / status LEDs.....	5-21
Table 5-3	Setting the address of PROFIBUS DP A using the key switch and slide switch.....	5-25

Table 5-4	Setting the address of PROFIBUS DP B using the key switch and slide switch.....	5-27
Table 5-5	Verifying the PROFIBUS DP address settings.....	5-28
Table 5-6	Resetting the AddFEM	5-28
Table 5-7	Resetting errors	5-31
Table 5-8	Adjustable parameters.....	5-33
Table 5-9	Overview of automation systems.....	5-35
Table 5-10	Failure and hot-swapping AddFEM	5-37

1 Fields of application

1

Section overview

Section	Contents	Page
1.1	Classification and features	1-2

1.1 Classification and features

The add-on products of the Add 7 product family provide solutions for specific and high-performance applications in the field of process control and automation engineering.

The Front End Module of the Add 7 product family is tailored to the special requirements of high-speed turbine control systems (different signal types, redundancy, high-speed acquisition and preparation of process data, etc.) AddFEM supports the implementation of loop control systems in the gas-, steam- and water-driven and industrial turbines sector. The AddFEM is also suitable for integrated automation and loop control applications where the emphasis is set on high-speed system reaction times.

The AddFEM offers highly versatile combination options. It supports integration in SIMATIC S7 and SIMATIC PCS 7 systems, and in SPPA-T3000 or SIMADYN D. The AddFEM operates in DP standard slave mode, and is controlled via PROFIBUS DP. The loop control and automation functions are handled as usual by the automation processor.

Signal inputs and outputs

The AddFEM is equipped with analog and digital IOs, including counter inputs for the acquisition of velocity control data.

Due to the optimized composition of signals, and based on an organization by the various signal types, smaller applications can be easily handled by a single AddFEM module. More complex applications, of course, can be handled by integrating several modules.

Each AddFEM provides the following signal inputs and outputs:

- 12 analog inputs, of which six may be operated as current inputs, while the remaining six may be configured in SIMATIC Manager or COM-PROFIBUS for operation as current or voltage inputs
- 8 analog outputs
- 15 digital inputs, of which three are available as counting pulse inputs for the acquisition of velocity control data with and without detection of the rotational direction
- 16 digital outputs, optionally operable as digital inputs

Due to the design of its analog IO measuring ranges, the AddFEM does not require any additional signal transducers when operated in turbine loop control systems. In addition to the usual measuring ranges 0 mA to 20 mA, 4 mA to 20 mA and ± 20 mA, the module provides a ± 30 mA measuring range. An additional ± 50 mA measuring range at the analog outputs supports the control of final control element with higher current consumption, such as fuel control valves, without additional signal amplifier.

All analog and digital outputs are short circuit-proof and monitored, and can be wired in parallel with other outputs. The analog and digital circuits are electrically isolated.

For further technical specifications of the IO, refer to section 4.

Higher availability due to redundancy

Redundancy in this context refers to the integration of a "1 of 2" structure. Availability is enhanced by means of parallel operation of two AddFEM modules. If one AddFEM fails as a result of error, the standby module automatically takes over the functions.

Redundancy of an AddFEM 6DL3100-8AA is controlled by the integrated functions in the automation processor configuration. In contrast, this redundancy control is integrated in the system performance of an AddFEM 6DL3100-8AB/-8AC. The redundancy coupling function on this module is implemented by a fiber optic interface which is used to transfer the status and update data. The extensive, integrated redundancy mechanisms and self-diagnostics functions of AddFEM support automatic error detection and redundant changeover, without any user intervention.

Redundant PROFIBUS DP connection

The AddFEM is equipped with two PROFIBUS DP interfaces (DP A and DP B) which operate in parallel which support the implementation of redundant system structures. All process input data are routed to both PROFIBUS DP interfaces, whereas only the process output data of the currently active DP interface are passed to the output pins. The process output data of the currently passive DP interface are analyzed for the purpose of monitoring. The master standby status of both DP interfaces, i.e. the definition of which DP interface is active or passive with respect to the output data can be set by the automation processor.

Preparation functions

Certain partial automation functions, such as the position control of turbine loop control circuits, can be swapped to the AddFEM as preparation functions. These functions are referred to as front-end function (FEF.)

GSD file

The PROFIBUS DP parameters and properties of the IO (measuring ranges, filtering, for example) of an AddFEM operated on SIMATIC S7 and SIMATIC PCS 7 systems can be set in SIMATIC Manager using HW Config. When operated on a SIMADYN-D system, the corresponding settings are programmed using the COM-PROFIBUS software package.

For information on using the GSD file, refer to the "readme.pdf" on your AddFEM CD.

Module power supply

The AddFEM power supply is designed to operate at a rated voltage of 24 V DC, and at a typical current consumption of 20 W. Voltage dips with a duration of at least 10 ms are buffered. The inrush current is limited to 3 A.

The AddFEM is equipped with an internal 24 V DC power supply for the analog outputs. The 24 V DC load voltage for the digital outputs must be generated by an external power supply which is wired to the X7 connectors.

Design

The AddFEM enclosure is made of stainless steel, and is prepared for screw-mounting or rail mounting.

The signal state of the digital IO is indicated by signal LEDs.

The operating and error states of AddFEM are indicated at 12 separate LEDs. The mode of operation is set by means of a key switch and slider.

The AddFEM front panel features eight 10-pin connectors (total of 80 IO pins) for the connection of process IO signals.

Certifications

In addition to the CE label, the AddFEM is also certified to UL/CSA.

1.1.1 Enhancement of 6DL3100-8AC variant (compared to -8AA/-8AB)

The enhanced DPV1 services of AddFEM are in particular suitable to provide dynamic parameter data (in acyclic mode) to the front-end functions (FEF.) These enhanced functions also support configuration changes in Run (= CiR = Configuration in RUN). CiR lets you reconfigure AddFEM parameters, such as enabling unused channels, or editing the parameters of active channels when using sensors with different technical specifications. The functionality also includes an option of reporting alarms with implicit acknowledgment mechanism for use by the front-end functions.

PROFIBUS DPV1

Variant 6DL3100-8AC (DPV1 slave) supports DPV1 services to IEC 61158 part 3-6. The DP master, of course, also has to meet those requirements (refer to the DP master documentation.)

PROFIBUS DPV2

Variant 6DL3100-8AC supports the PrmCommand to PROFIBUS Guideline 2.212 for the changeover of communications redundancy (changeover between DPV1 channels A and B), and provides redundancy status data for diagnostics functions.

The table below shows the new functions of the AddFEM DPV1 slave:

Function	DPV0 slave 6DL3100- 8AA/8AB	DPV1 slave 6DL3100- 8AC	Comment
Cyclic data exchange	X	X	
Ayclic data exchange (read/write data record) DP master class 1 services (parameter assignment master) DP master class 2 services are not supported (SIMATIC PDM, for example)	-	X	Programming the AddFEM in RUN. Useful in particular to supply the front-end function with parameter values.
Diagnostics			
device-specific diagnostics	X	-	
ID-specific diagnostics	-	X	One alarm can be reported per diagnostics frame.
module status	-	X	
Channel-specific diagnostics	-	X	

Function	DPV0 slave 6DL3100- 8AA/-8AB	DPV1 slave 6DL3100- 8AC	Comment
Alarms · Diagnostics alarm · manufacturer-specific alarm	- -	X X	Supports DS0/DS1. This alarm is available to front-end functions.
Redundancy changeover Changeover of communication redundancy between DPV1 channels A and B.	-	X	Changeover using the PrmCommand, and reporting of the redundancy state as diagnostics data.

For further information about the configuration in the host system, refer to the relevant FEF manual. The FEF manuals are included on the AddFEM CD, in the folder of the corresponding order number.

1.1.2 Driver blocks

Depending on the automation processor used, you can control the AddFEM using the driver blocks, or, for example in turbine applications with SYMADYN-D, directly in the user program by means of PROFIBUS user frames.

Driver blocks are available for SIMATIC PCS 7 and are located in the "SIMATIC_PCS7_Driver" directory of the CD.

2 Configuration

2

Section overview

Section	Contents	Page
2.1	AddFEM configuration	2-2
2.2	Connecting elements	2-3
2.3	Device model – module allocation (when using PCS 7)	2-5

2.1 AddFEM configuration

The stainless steel enclosure of the AddFEM accommodates the power supply, processors, PROFIBUS DP interfaces, interfaces for process IO signals, redundancy and service interface (fiber optic system), switches and status displays.

All connecting elements are protected with labeled covers.




Fig. 2-1 AddFEM, front view

The AddFEM module is suitable for rail mounting, or for wall mounting on steel brackets.

Outer dimensions of the mounting elements: (W x H x D): 75 mm x 290 mm x 190 mm.

2.2 Connecting elements

Module power supply

The AddFEM is wired to the 24 V DC power supply via front connector.




Fig. 2-2 24 V DC module supply

The module current input is limited by an electronic circuit. It is also protected by an F 2.5 A fuse (internal fuse element for the protection against damage; not replaceable.)

The AddFEM can be operated on 19.2 V DC to 30 V DC.

The 19.2 V low limit is monitored.

Load power supply

The AddFEM is equipped with an internal 24 V DC load power supply for the analog outputs. The 24 V DC load voltage for the digital outputs must be generated by an external power supply which is wired to the X7 connectors.

Grounding and electrical isolation

The front panel of the module features a grounding screw below the power supply connector. Module enclosures installed on a non-conductive or ungrounded surface must be bonded to ground using this screw (EMC shielding measure.)

Isolated function areas:

- Microcontroller area, including the analog I/Os
- 24 V DC module power supply
- Digital I/Os

The 12 digital inputs are organized in groups of four, each with a common reference potential. This also applies to the three counting pulse inputs. The 16 digital outputs are distributed to two reference potentials.

Interfaces X1 and X2

- Redundancy interface X2
For redundant operation of two AddFEM modules.
- Service interface X1
For commissioning and maintenance.
Only with 6DL3100-8AC05 (AddFEM PoCo Plus), this interface is used as an additional redundancy interface for channel-selective redundancy switching of analog inputs for position feedback messages.

PROFIBUS DP connectors X3A und X3B

The AddFEM is equipped with two PROFIBUS connections for communication with the automation processor.

Process connections X4 to X7



The process IO signals are wired to sockets X4 to X7. The corresponding mating connectors are equipped with screw terminals for conductor cross-sections from 0.14 mm² to 1.5 mm² (AWG 28-16.)

2.3 Device model – module allocation (when using PCS 7)

The AddFEM features analog and digital inputs and outputs as well as count pulse inputs for speed detection. The AddFEM can be optionally equipped with a pre-processing function (FEF) (software function).

Signal types are allocated in logical modules (similar to a modular DP device with pluggable I/O modules) for the display and processing of the various AddFEM signal types in the higher-level PCS 7 host system. The allocation to logical modules corresponds to the numbering below the heading Slot for the hardware configuration, for example in HW-Config.

Steckplatz	DP-Kennung...	Bestellnummer / Bezeichnung	E-Adresse	A-Adresse	Kommentar
1	194	Grundgeraet	1..12	0..3	
2	219	Analog Eingaenge	13..36		
3	231	Analog Ausgaenge		4..19	
4	33DE	Digital Eingaenge	37..40		
5	16DA	Digital Ausgaenge			
6	213	Zaehler Eingaenge	41..51		
7					

* You can find the I/O assignments in the appendix A.1 "Front connector pin assignment"

Fig. 2-3 Device model – module allocation

3 Mode of operation

3

Section overview

Section	Contents	Page
3.1	General functions	3-2
3.2	Operating principle of 2-channel speed monitoring with detection of the rotational direction	3-3
3.3	Operating modes	3-5
3.4	Redundancy functionality with AddFEM	3-7
3.5	Signal preparation functions with AddFEM (applies only to 6DL3100-8AC)	3-11

3.1 General functions

Introduction

Disruptions or errors should be detected, localized and reported within the shortest possible time. The AddFEM performs a full self-test after POWER ON (Run Up Self Test), and periodically in normal cyclic operation (Cycle Self Test.) (see "Technical specifications", section 4.2)

Self-tests/inherent monitoring function:

Components and functions included in the test:

- RAM test
- RAM checksum test (calibration data, program code)
- FEPRAM checksum test (calibration data, program code)

Self-tests in cyclic mode

Certain self-test operations must be synchronized with the I/O cycle, and are thus part of this cycle.

Self-tests within the IO cycle:

- RAM test
- PROFIBUS functionality
- Data transfer host <-> AddFEM
- Data transfer <-> redundant AddFEMs
- Cycle times
- Power supply
- Channel errors of process IO
- Coprocessor monitoring by master processor

Delayed shutoff

After a brief host failure or loss of PROFIBUS DP communications, the process outputs will be shut down if a programmable tolerance time is exceeded.

This tolerance time can be set within a range from 10 ms to 3 s.

The default is 0.5 s.

(see section 5.6.1 "Adjustable parameters")

Analog input signal filters

The analog input signals can be filtered digitally. The system provides 50 Hz, 60 Hz, 16^{2/3} Hz and 500 Hz* line filters. The filter parameters are set separately for each analog input (channel-specific) in the parameter frame. Options:

- no filtering
- 50 Hz
- 60 Hz
- 16^{2/3} Hz
- 500 Hz*

Default is "Turned off", which means no filtering.

* Configurable as of version 14 of 6DL3100-8AC

3.2 Operating principle of 2-channel speed monitoring with detection of the rotational direction

Channels 1 and 2 of AddFEM 6DL3100-8AA version 8 or higher, or ADFEM 6DL3100-8AB/-8AC version 7 or higher can be operated in frequency counting mode with detection of the rotational direction. This function requires the connection of a suitable (dual-channel) encoder to channels 1 and 2. The leading signal is connected to channel 1, and the lagging signal to channel 2.

Channel 3 can be used as separate, additional single-channel monitoring function, without detection of the rotational direction.

The (signed) frequency recorded in dual-channel mode is indicated at both channels 1 and 2 as follows:

The system calculates the value of the indicated frequency separately for each channel, based on the pulses of the connected encoder. The sign (rotational direction) is determined by the phase offset of both channels and assigned to the channels accordingly.

Reaction to the failure of one of the two encoders:

If one of the two signals is lost, the velocity value of the faulty channel is stepped down to zero as in single-channel recording mode (see section 4 "Technical specifications".) The system freezes the sign status according to its value prior to the error. This method upholds the detection of the velocity at a single channel after an error has occurred. However, reversals of the rotational direction can no longer be detected.

Wire breaks can be detected by means of a parity check of the channel signals, for example. However, allowances must be made in this parity check for differences between the channel signals caused by mechanical inaccuracy in the velocity sensor (tooth edges) and acceleration (see the next section.) Due to the many possible applications, the channel-specific wire break detection cannot be configured on the module, but rather in plant-specific parameters on the host system.

Information about refreshing and possible velocity differences of both channels:

The internal algorithm of the module always calculates the frequency (for measuring the period) based on signal transitions, and thus at different times at the two "phase-shifted" encoders.

Velocity changes will therefore cause a slight deviation of the values indicated at channels 1 and 2, because one of the channels will always return (in alternating mode) the more recent value. The timeliness and accuracy can be increased in particular in the lower velocity range by forming an average of both channel values.

Allowances must be made for the following velocity difference (Δf) between both channels caused by acceleration actions:

$$\Delta f = \sqrt{f^2 + a} - f \quad (\text{at frequencies } \leq 125 \text{ Hz})$$

(a = acceleration, f = frequency)

$$\Delta f = a * 2 \text{ ms} \quad (\text{at frequencies } > 125 \text{ Hz})$$

Note: Simplified formula for encoders with detection of the rotational direction and channels operating at a phase shift of 90°.

3.3 Operating modes

System configurations

The AddFEM can be configured for operation in stand-alone or redundant mode on one or two PROFIBUS DP channels. There are four available system configurations. The configuration must be programmed. See also 5.6.1 "Adjustable parameters".

The AddFEM module does not automatically detect and adapt a configuration. The mode of operation is set up on the AddFEM using a PROFIBUS DP parameter frame, and is determined by the required system configuration.

Note:

The basic setting selected for the AddFEM redundancy mode supports the replacement of a 6DL3100-8AA module with a 6DL3100-8AB/-8AC module without conversion of the configuration.

Setting the mode of operation

When using SIMATIC S7, you can configure the PROFIBUS DP parameters in HW-Config of SIMATIC Manager. Use the COM-PROFIBUS software package to make the corresponding settings for other systems.

Mode	Host	AddFEM	PROFIBUS
0	single-channel	single-channel	1 PROFIBUS DP segment
1	redundant	single-channel	2 PROFIBUS DP segments
2	single-channel	Redundant	1 PROFIBUS DP segment
3	redundant	Redundant	2 PROFIBUS DP segment

Note

After POWER ON, the AddFEM holds the STARTUP (LED RUN flashes) state until its operating mode parameters are set (see section 5.6.1).

System configurations

Mode 0




Fig. 3-1 Mode 0

- SIMATIC AS-400, stand-alone with CPU 416, CPU 417
- AddFEM in non-redundant mode
- PROFIBUS DP integration only via PROFIBUS DP interface X3A

Mode 1




Fig. 3-2 Mode 1

- SIMATIC AS-400, redundant with CPU 417-H
- AddFEM in non-redundant mode
- PROFIBUS DP connection via PROFIBUS DP interface X3A and PROFIBUS DP interface X3B

Mode 2




Fig. 3-3 Mode 2

- SIMATIC AS-400, stand-alone (CPU 416, CPU 417) or
- SIMATIC AS-400, redundant with CPU 417-H
- AddFEM with redundant connection via fiber optic cable
- PROFIBUS DP integration of each only via PROFIBUS DP interface X3A

Mode 3




Fig. 3-4 Mode 3

- SIMATIC AS-400, redundant with CPU 417-H
- AddFEM with redundant connection via fiber optic cable
- PROFIBUS DP integration with PROFIBUS DP interface X3A and PROFIBUS DP interface X3B

3.4 Redundancy functionality with AddFEM

Increased availability due to redundancy

In this context, redundancy refers to the implementation of a "1 of 2" structure. Availability is increased by the parallel operation of two identical components. If one of the components fails as a result of error, the standby automatically assumes the functions in a bumpless operation. The comprehensive, integrated redundancy mechanisms and self-diagnostics functions of AddFEM provide an effective means of automatic error detection and changeover of redundant stations without operator intervention

Master/Reserve

The terms "master" and "reserve" are used below to distinguish the two AddFEM modules. The "reserve" AddFEM always operates in synchronism with the "master" AddFEM, i.e. not only in error case. The process outputs of the "reserve" AddFEM are passive, i.e. they do not output any process signals.

Features of redundant AddFEM modules

The system automatically changes over to the redundant unit if one of the AddFEM fails ("1-of-2" structure.) Bumpless transfer of master mode by means of redundant fiber optic interface.

After it has detected an error, the AddFEM initiates the master changeover, i.e. it shuts down the outputs of the previous master, and enables the outputs of the standby station. This is an almost seamless operation. (For information on tolerance-specific changeover gaps, refer to the section Technical specifications, section 4.1)

Fiber optic connection

Redundant AddFEM modules feature a serial, bidirectional fiber optic interface for redundant communication. This is used to exchange error / redundancy / update data.

Master/reserve preset

When both redundant AddFEM have a balanced error rating, the status is determined by the automation processor. This soft preset can also be applied, for example, to perform a cyclic M/R changeover (24 h intervals.)

Forced master/reserve setting

The AP assigns the master / reserve mode if the fiber optic connection is missing or faulty

Master / reserve changeover

The master module is the active controller until it detects an error in its own system. In this case, it passes master mode to the standby module.

Note: AddFEM PoCo Plus 6DL3100-8AC05 features additional channel-selective redundancy mechanisms (see AddFEM PoCo Plus manual).

The handover of the master roles is always performed through error weighting. The error weight of a module is derived from the weighted sum of all individual errors. Errors that always affect the function of the module (e.g. memory errors) have a higher weight, whereas channel errors are handled with the lowest priority for the error weight.

Channel errors that are included in the error weight are taken from the monitoring of the 12 analog registrations, the 8 analog outputs as well as the 16 digital outputs (which can also be used as digital inputs).

Each channel is weighted with the same factor for determining the error weighting.

1. The signal range is monitored for the analog registration. With 4 to 20 mA signals, a channel error is set at a high or low violation of the range.

Measuring range \ Signal limit	4-20mA	0-20mA	+20mA	+30mA	0-10V	+10V
High	22.96mA	23.70mA	23.70mA	35.55mA	11.85V	11.85V
Low	1.185mA	-3.511mA	-23.70mA	-35.55mA	-1.760V	-11.85

2. For the analog output, the requested output signal and output signal read back are compared to determine if they match. A short circuit to ground or wire break cannot be detected if the output is set to 0.

3. For the digital output, the signal is read back and monitored for short circuit to ground when the level is output as 1.

Master / reserve changeover without fiber-optic connection

The master station assigns the master / reserve mode if the fiber optic connection is missing or faulty. The decisive factor is here the current error rating of the modules.

Process IOs

Redundant AddFEM require absolutely "symmetrical", i.e. identical input and output signals (exception: "AddFEM PoCo Plus", see corresponding description).

Redundancy nodes

Redundant nodes represent fail-safety in systems containing several identical components. A redundancy node is considered independent, if the failure of one of the components does not impair the reliability of other nodes or of the entire system. In a "1-of-2" system, a component of the redundancy node may fail without impairing system functionality.




Fig. 3-5 System configuration with two redundancy nodes

The redundant automation processors AP A and AP B shown in Fig. 3-5 execute the same application software, such as a turbine loop control function, cyclically and in synchronism. One of the two systems (AP A or AP B) is the "master" station and actively controls the outputs. After an error has been detected in the master system, master control is automatically changed over to the standby station in a bumpless operation. The redundancy status and additional update information are exchanged between AddFEM A and AddFEM B across the redundancy coupling.

3.4.1 Redundant PROFIBUS DP connection

The PROFIBUS DP channels are basically of the same priority class. The AddFEM changes the channels if it detects a DP error, sign-of-life change / error, or when it receives a GCCL (Global Control Clear) frame. A changeover of DP channels by the AP is always initiated by the sign-of-life signal. Version 6DL3100-8AC supports

the PrmCommand to PROFIBUS Guideline 2.212 for the changeover of DP channels, and returns the redundancy status for diagnostics functions.




Fig. 3-6 Redundant PROFIBUS DP connection

The AddFEM and AP are interconnected via redundant PROFIBUS DP A and PROFIBUS DP B bus. Each AddFEM is equipped with two PROFIBUS DP connections. Both bus segments operate in parallel.

Input data (input) are always transferred in parallel to both automation processors. The AddFEM outputs only respond to the control signals of one of the two automation processors AP A or AP B, i.e. it always outputs either the output data of AP A or of AP B. For this reason, a master/reserve changeover also requires a corresponding adaptation of the AddFEM output status. The output information of the passive AP is analyzed for monitoring functions, and is then discarded.

The output-specific changeover is based on various criteria. The system always changes over to the operable interface as a reaction to coupling failure. In case of total failure, i.e. if both interfaces no longer receive any frames, the system outputs safety-oriented zero signals.

Note

In addition to the AddFEM's changeover of bus channels, the automation processor may also actively initiate a changeover, i.e. it can actively output a control command to set the active bus interface DP A or DP B.

3.5 Signal preparation functions with AddFEM (applies only to 6DL3100-8AC)

AddFEM 6DL3100-8AC supports signal preparation functions for the execution of specific automation functions, such as the position control in turbine control loops. These functions can be used to outsource time-sensitive functions requiring short cycle times for the transfer of data from the master AP to the AddFEM, and thus relieve the master AP from time-sensitive tasks. This signal preparation function is referred to as front-end function (FEF.)

The FEF functions are provided as preset functions, which can be especially configured with additional parameters by the user thus be optimized for the relevant process.

The following FEF functions can be ordered and the additional functions are described separately in the appropriate directories on the CD:

- 6DL3100-8AC02: AddFEM PoCo (position control) for fast control
- 6DL3100-8AC03: AddFEM SOE (Sequence of Event) for fast time-stamping of digital input signals.
- 6DL3100-8AC05: AddFEM PoCo Plus, extension of AddFEM PoCo, in particular the use of channel-selective redundancy.

Note: Additional customer-specific solutions that have been created only for a limited group of customers are not listed here; they are described separately.

Siemens offers an extended range of FEF functions. If your current automation components do not offer any solutions, or only cost-intensive solutions, for customer-specific applications, you can order customized solutions in the form of loadable FEF from Siemens.

Contact partner for the creation of further customized FEF applications:

Siemens Aktiengesellschaft
Industry Sector Industry Automation Division
I IA CE SE PRM EN
Kathrin Starschich
Wuerzburger Str. 121
D-90766 Fuerth, Germany
Phone.: +49 (911) 750-2331
E-mail: kathrin.starschich@siemens.com

4 Technical specifications

4

Section overview

Section	Contents	Page
4.1	Technical specifications	4-2
4.2	Safety, environmental conditions and EMC	4-13
4.3	Processing times	4-17

4.1 Technical specifications

General data	
Dimensions (H x W x D)	295 mm x 75 mm x 209 mm
Weight	2.8 kg
Input voltage, rated value permissible range	24 V DC static: 19.2 V DC to 30 V DC dynamic: 18.5 V to 30.2 V
Rated input current Module supply Load supply	0.8 A 8 A
Inrush current Peak Half intensity width	3 A, limited 100 ms
Buffering of power failure	at least 10 ms, at input voltage 19.2 V DC to 30 V DC
Cumulative power loss of AddFEM - Module supply - Supply at digital inputs - Supply at analog inputs - Switching and feed forward losses at digital outputs on load power supply	max. 33 W (cumulative) max. 20 W max. 4 W max. 1 W max. 8 W
Module power supply fusing	2.5 A, fast-blow (internal protection, not replaceable)
Load power supply fusing	2 x 7 A, fast-blow (internal protection, not replaceable)
<p><u>Electrical isolation</u></p> <p>The module consists of several electrically isolated function groups. The potential difference between these function groups may not exceed 50 V when the system is in operation. Assignment of signals and connections to the various function groups:</p> <ul style="list-style-type: none"> a) Analog IO (connectors X4/1 to X4/20, and X5/1 to X5/20), including the internal microcontroller area b) Count pulse inputs (connectors X6/1 to X6/4) c) Digital inputs 5 to 8 (connectors X6/6 to X6/10) d) Digital inputs 9 to 12 (connectors X6/11 to X6/15) e) Digital inputs 13 to 16 (connectors X6/16 to X6/20) f) Digital outputs 1 to 8 (connectors X7/1 to X7/10) g) Digital outputs 9 to 16 (connectors X7/11 to X7/20) h) PROFIBUS DP connector X3A i) PROFIBUS DP connector X3B j) Module power supply 24 V DC k) Enclosure 	

PROFIBUS DP interfaces	
Number of interfaces	2
Transmission rate	9.6 kbps to 12 Mbps
Max. cable length of a bus segment terminated at both ends	100 m
Permitted load on the 5-V power supply of the bus for the connection of further nodes without internal power supply	max. 80 mA per interface
For detailed information on PROFIBUS, refer to SIMATIC NET, PROFIBUS Networks manual, order no. 6GK1970-5CA20-0AA0!	

IO cycle times (PROFIBUS and connectors X4 to X7)	
Analog signal acquisition	666.667 μ s
Analog signal output	666.667 μ s
Digital signal acquisition ¹⁾	666.667 μ s
Digital signal output	666.667 μ s
Count pulse input	2 ms

¹⁾ Refresh signal at intervals of 666.667 μ s. Signal filtering incurs an additional dead time of 666.667 μ s between acquisition and output.

Digital inputs (channels 5 to 16)	
Number of inputs	12
Type of input to IEC 61131-2	Type 1
Voltage range	- 30 V DC to + 30 V DC
0 signal level	- 30 V DC to + 5 V
1 signal level	+ 11 V to + 30 V
48 V contact voltage	no
Connection of BEROs supported	yes
Min. current at input voltage	5 mA at 11 V (see Fig. 4-1)
Delay time (TID)	50 μ s at 0 > 1 signal transition 50 μ s at 1 > 0 signal transition
Displays	Front panel LEDs; indicate the converted values read by the internal microcontroller unit.
Terminal assignments	See appendix A, connector X6, page A-2




Fig. 4-1 Trend of digital inputs with tolerances of input current I_e

Digital inputs (channels 17 to 32)	
Depending on the configuration, the pins of connector X7 can be operated as digital output or as digital inputs (channels 17 to 32). Below are the technical specifications of these pins when used as digital inputs.	
Number of inputs	16
Type of input to IEC 61131-2	Type 1
Voltage range	- 30 V to + 30 V DC
0 signal level	- 30 V to + 5 V
1 signal level	+ 11 V to + 30 V
48 V contact voltage	no
Connection of BEROs supported	no
Input current	~0.34 mA at 11 V / ~0.84 mA at 24 V
Delay time (TID)	50 μ s at 0 to 1 signal transition 50 μ s at 1 to 0 signal transition
Displays	Front panel LEDs indicate the converted values read by the internal microcontroller unit.
Terminal assignments	See appendix A.1, connector X7, page A-2

Count pulse inputs ¹⁾ (channels 1 to 3)	
Number of inputs	3
Type of input to IEC 61131-2	Type 1 / 2
Voltage range	- 28 V DC to + 28 V DC
0 signal level	- 28 V to + 3 V
1 signal level	+ 8 V to + 28 V
Demand factor when operated at a voltage > 26 V	The count pulse inputs are also specifically designed to handle low input voltages (high signal detection => 8 V.) To limit power losses, either the input voltage must be limited to 26 V, or a 60% pulse/pause ratio with a maximum pulse width of 1 minute must be maintained, or only two of the three inputs may be set high at any given time.
Load	1 kΩ to 3 kΩ
Current/ voltage profile across the working range	See Fig. 4-1!
Dealy time (TID)	50 μs at 0 > 1 signal transition 50 μs at 1 > 0 signal transition
Cyclic evaluation of all signals	2 ms Noise pulses < 10.667 μs are suppressed by filtering. Additional hardware evaluation by counters.
Input frequency (f _m)	0 kHz to 20 kHz
Counter resolution	32 bit
Measuring accuracy	better than 10 ⁻⁴ of measrued value
Refresh interval	2 ms
Measuring time at frequencies < 800 Hz	20 ms
Filter	At each refresh scan cycle point, the system recalculates the frequency based on a mean value derived from the count pulses logged within the last 20 ms.
Detection of the rotational direction	The rotational direction can be determined by coupling channels 1 and 2. See section 3.2 (supported as of version 8 of 6DL3100-8AA, version 7 of 6DL3100-8AB, and by all versions of 6DL3100-8AC)
Displays	Front panel LEDs; indicate the converted values read by the internal microcontroller unit.
Terminal assignments	See appendix A, connector X6, page A-2

¹⁾ Count pulse inputs may also be used as digital inputs!




Fig. 4-2 Count pulse inputs, current-/voltage diagram including tolerances of input current I_e

Reaction of the count pulse/rotational direction detection functions to interruption of the pulses (due to wire break, for example)

A) Single-channel mode (without rotational direction detection)

(applies to 6DL3100-8AA/-8AB version 7 or higher, and to all 6DL3100-8AC)

Frequency output will be limited according to the period of the last recorded pulse if no more count pulses are received. The limit frequency F is derived from the period T since the last pulse by the formula

$$F = 1/(T - \text{dead time}) * 1.5$$

The dead time of 0 ms to max. 2 ms is derived from the detection cycle time.

In practical life, we derive the limit frequencies from the output limit (see the table below), provided the original frequency measured prior to the pulse failure was higher.

The value will be set to zero on expiration of 10 s. (frequencies below 0.1 Hz are not recorded.)

Interval T since last pulse	Limiting of frequency output to the values listed below
0 ms to max. 2 ms	Old frequency is retained. At a detection cycle ≤ 2 ms, a missing pulse can not be detected.
2 ms to max. 4 ms	Limiting to max. 750 Hz
4 ms to max. 6 ms	Limiting to max. 375 Hz
8 ms to max. 10 ms	Limiting to max. 187.5 Hz
18 ms to max. 20 ms	Limiting to max. 83.3 Hz
48 ms to max. 50 ms	Limiting to max. 31.3 Hz
98 ms to max. 100 ms	Limiting to max. 15.3 Hz
0.998 s to max. 1 s	Limiting to max. 1.5 Hz
9.998 s to max 10 s	Limiting to max. 0.15 Hz
> 10 s	Output will be set to 0, i.e. frequencies below 0.1 Hz will not be recorded, or always set to 0.

B) Reaction of the dual-channel count pulse / velocity detection

(with detection of the rotational direction) to channel failure:

(applies to 6DL3100-8AA version 8 or higher; 6DL3100-8AB version 7 or higher, and all 6DL3100-8AC)

If one of the two channels fails, the velocity value is stepped down to zero as in single-channel detection. The sign is frozen at the state it had prior to the error event. It is thus still possible to detect the velocity using only one channel, however, without detection of any changes in the rotational direction.

Note

For information on wire break monitoring, refer to section 3.2, "Operating principle of 2-channel speed monitoring with detection of the rotational direction"

WARNING

False signal acquisition when using old firmware versions and a wire break occurs

If modules with obsolete versions for count pulse/speed measurement with detection of rotational direction (e.g., for use of water turbines) are used, in the event of a sensor failure or wire break the speed and rotational direction may no longer be correctly detected at times.

This may cause property damage depending on the process control.

For speed measurement and rotational direction detection, use only modules with the following versions (or later):

6DL3100-8AA: Version 8

6DL3100-8AB: Version 7

6DL3100-8AC: All versions are permissible

Digital outputs ¹⁾	
Number of outputs	16 digital semiconductor outputs
Rated output voltage	DC 24 V
Output voltage at 0 signal	< 1 V
Output voltage at 1 signal	supply voltage – 2 V
Max. output current	500 mA Parallel wiring of outputs for higher currents is supported.
Output current at 100% demand factor	500 mA
Cumulative output current	8 A
Effect of repeated overload on multi-circuit modules	none
Monitoring of short-circuit to M	yes
Short circuit-proof	yes
Max. lamp load per output	5 W
Inductive loads	Connection of inductive loads is supported. Compared to standard suppression diodes, the suppression voltage of integrated suppression diodes is increased by 39 V, and accelerate the shutoff of the current and, thus, of the final control element. However, the maximum suppression power (1 W) may not be exceeded.
<u>Typical values:</u> Max. inductivity at $I \leq 500$ mA and $f \leq 1$ Hz	8 H (without external suppression diode)
Max. inductivity at $I < 250$ mA and any f	unlimited
Max. inductivity with external suppression diode	unlimited
Output delay (TQD, Totzeit) between command output and response of the output (start of current rise)	20 μ s at 0 > 1 signal transitions 20 μ s at 1 to 0 signal transitions
Output response time (TQT) between command output and transient state of the output current at 500 mA	50 μ s at 0 > 1 signal transitions 50 μ s at 1 > 0 signal transitions
Reaction to the interruption of runtime controlled by the master processing unit	Shutoff of the outputs
Reaction to dips and interruption of the power supplies L1+ or L2+ at X7/1 or X7/11	The output voltage follows the supply voltage.
Displays	The voltage level of the digital outputs is logged by the internal digital inputs of the module, and is then converted and read by the internal microcontroller unit. The microcontroller unit outputs the read states to the front panel LEDs.
Terminal assignments	See appendix A.1, connector X7, page A-2

¹⁾ Digital outputs may also be used as digital inputs!

Analog inputs	
Input impedance across the signal range for current measurement for voltage measurement	41.8 Ω 100 k Ω
Measuring error Max. error at 25 °C Temperature coefficient	$\pm 0.12\%$, at 0 V CMV ± 25 ppm/K
Max. error across the temperature range	$\pm 0.2\%$ relative to measuring range limit at a CMV of max. 2 V
Digital resolution of the D/A converter	13 bit + sign
Value of the least significant bit (LSB) bei Strommessung bei Spannungsmessung	4 μ A 2 mV
Highest permissible continuous overload (no damage)	60 V
Output of the digitized analog value under load	118 %
Input type	Differential
CMV range	± 6 V
CMV suppression DC 50 Hz 60 Hz	- 0.05 % / V 55 dB 55 dB
Total system input transfer time (TAID + TAIT)	52 μ s
Scan time including settling time	20 μ s
Scan cycle interval time	104.167 μ s
Input filter of the first order Transition frequency	880 Hz
Mean value formation across four measurements Transitional frequency including input filter	700 Hz
Max. short-term offset during any defined electrical error test	See EMC data (section 4.2)
Conversion method	successive approximation / parallel conversion of 4 channels
Mode of operation	autoscan
Calibration	not required
Terminal assignments	See appendix A.1, connector X5, page A-1!

Analog inputs (continued)		
Measuring ranges of current inputs / overflow range	0 mA to 20 mA / – 3.511 mA to 23.7 mA 4 mA to 20 mA / – 1.185 mA to 22.96 mA ± 20 mA / ± 23.7 mA ± 30 mA / ± 35.55 mA	
Signal limits of the current inputs (triggers channel error)		
Range	Low signal limit	High signal limit
0-20 mA	-3.511 mA	23.70 mA
4-20 mA	1.185 mA	22.96 mA
+/- 20 mA	-23.70 mA	23.70 mA
+/- 30 mA	-35.55 mA	35.55 mA
Measuring range/overflow range of voltage inputs only at channels 1 to 6	0 V to 10 V / -1.755 V to 11.85 V ± 10 V / ± 11.85 V	
Signal limits of the voltage inputs (triggers channel error)		
Range	Low signal limit	High signal limit
0-10 V	-1.76 V	11.85 V
+/-10 V	-11.85 V	11.85 V
Number and function of inputs	6 current measuring inputs, 6 current/voltage measuring inputs	
Crosstalk between channels at		
DC	≤ 60 dB	
50 Hz	≤ 60 dB	
60 Hz	≤ 60 dB	
Non-linearity	< 0.01 %	

Analog outputs	
Number of analog outputs	8
Max. error at 25°C	± 0.15 %
Temperature coefficient	± 100 ppm / K
Max. error across the temperature range	± 0.4 %
Value of the least significant bit (LSB)	13 bit + sign
Value of the least significant bit (LSB)	8 µA
Total system transfer time (TAQD + TAQT)	1 ms
Transient time across the full range	0.6 ms
Overshoot	0.2 %
Max. short-term offset during any defined electrical error test	See EMC data (section 4.2)
Terminal assignments	See appendix A.1, connector X4, page A-1
Max. permitted inductive load	1 H
Power Off operations	Buffer time up to 10 ms. With prolonged failure, power on is determined by software functions
Conversion method	parallel conversion of all 8 output channels
Current output range unipolar / overflow range / load	0 ... 20 mA / ± 23.5 mA / 480 Ω 4 ... 20 mA / – 4,96 bis + 22,96 mA / 480 Ω
Current output range bipolar / overflow range / load	± 20 mA / ± 23.5 mA / 480 Ω ± 30 mA / ± 35.55 mA / 300 Ω
Current output bipolar (only channels 1 to 4) ¹⁾	± 50 mA / ± 59.26 mA / 150 Ω
Output current monitoring tolerance	4 %
Cross-talk between channels at:	
DC	≤ 60 dB
50 Hz	≤ 60 dB
60 Hz	≤ 60 dB
Non-linearity	± 0.1 %
Output ripple	± 0.1 %

¹⁾ In order to protect the module, the analog outputs 1 to 4 are limited to an average load of 40 mA. The extension of the current range of those outputs to 50 mA / 59.26 mA is only intended for the control of final control elements with integral action. A max. current of 59,26 mA is provided to this purpose for a limited time.

The current is monitored by the software and limited as follows.

Mean value limiting: At a current output programmed for operation at ±50 mA, the mean value of the output current is calculated based on a delay element of the first order which has a time constant of 10 s. If the current exceed a mean value of 40 mA, both the output current and its mean value will be limited to ±40 mA.

4.2 Safety, environmental conditions and EMC

Certifications:

6DL3100-8AA/-8AB/-8AC is certified to:

- UL-Recognition-Mark: Underwriters Laboratories (UL) to Standard UL 508
- CSA-Certification-Mark: Canadian Standard Association (CSA) to Standard C 22.2 No. 142

CE label

6DL3 100-8AA/-8AB/-8AC meets requirements of EC Directive 2004/108/EC "Electromagnetic Compatibility"

Safety	
Device standard	EN 61131-2, IEC 61131-2, parts 11 to 14
Inherent heating	The enclosure made of steel sheet is subject to an excess temperature of approx. 20 K under full load. The temperature limit of 70 °C is thus exceeded at an ambient temperature of 60 °C, which still allows unprotected contact without any risk of injury (to DIN EN 61131-2.).
Power supply	The 24 V DC power supply must be a safety extra-low voltage which is safely isolated from mains. This isolation may be implemented in accordance with VDE 0100 Part 410 , HD 384.4.41 , IEC 60364-4-41 (as functional extra-low voltage with safe isolation PELV) or to EN 60950-1, IEC 60950-1 (as safety extra-low voltage SELV).
Installation safety requirements	6DL3100-8AA/-8AB/-8AC is an "open equipment" to DIN EN 61131-2 standard, and according to UL/CSA certification an "open type." In order to satisfy operational safety requirements with respect to mechanical strength, non-inflammability, stability and touch protection, the following installation methods are mandatory:: Installation in a suitable cabinet Installation in a suitable enclosure Certified only to DIN EN 61131-2: Installation in a closed switch room with appropriate equipment
Electrical isolation	Isolation of the areas specified in section 4.1 is designed for normal operation at a rated voltage of 50 V. The routine insulation test is carried out to UL 508 (test voltage/duration 707 V DC / 1 min, or optional at 849 V DC / 1 s when the test object is switched off.
Foreign matter and water-proofing	Degree of protection IP20 to IEC 529, i.e. protected against contact with standard test fingers. Not water-proof.
Sound emission	None

Mechanical ambient conditions	
<p>Continuous shock operational, screw-mount or rail-mount test object (see section 5.1)</p> <p>Packaged for shipping</p>	<p>Tested to DIN EN 60068-2-29: Half-wave sinusoidal: 10 g (100 m/s²) for 16 ms 100 shocks per axis Note: rail mounting to DIN EN 60715 (min. material thickness. 2.2 mm.) In addition to the side brackets, a center bracket is required for DIN rails with a length of 19 inches in order to ensure safe and rigid fixation of the module on the rails</p> <p>Tested to DIN EN 60068-2-27: Half-wave sinusoidal: 25 g (250 m/s²). duration 6 ms 1000 shocks per axis</p>

Dust endangering functionality	
<p>The AddFEM must be protected against the ingress of any conductive and corrosive matter. For other dust and sand particles, conditions of use to IEC 60 721-3-3 classe 3S2.</p>	
Special features	
QC	to ISO 9001

4.3 Processing times

Causes of redundancy changeover of redundant modules (only 6DL3100-8AB/-8AC)	
According to priority (error rating)	Cause
Forced reserve selection	- FRS signal from automation processor in case of failure of the redundant fiber optic connection - Mode selector switch to STOP
Module error	- RAM test error - Checksum of the program code in RAM or FEPROM is faulty - Failure of the 24 VDC power supply / undervoltage
Central unit failure	- PROFIBUS DP failure - Failure of automation processor (host-system)
Channel error	- Channel error at analog input, analog output, digital output, or - Failure of the 24 VDC power supply to the digital outputs
Channel error rating	- Sum of all channel errors. Identical rating of all channels.

CPU failure detection time	
PROFIBUS DP	The active reaction monitoring time is calculated based on the relevant values returned in the parameter assignment frame (see PROFIBUS standards)
Sign-of-life	2 x automation processor cycle

Channel error detection time ¹⁾	
Analog inputs Max. delay of qualifier QU (bit 0 of the relevant analog value AI 0 to 12) in the input frame	42.00 ms
Analog outputs Max. delay of qualifier AO 1 ... 8 in the input frame	12.667 ms 28.667 ms (at 6DL 3100-8AA up to version 6)
Digital outputs, or load voltage dips Max. delay of qualifier DO 1 ... 16 in the input frame	2.00 ms

¹⁾ The error detection times of signal evaluation are a multiple of the cycle time due to error filtering. Error filtering prevents the generation of an error message triggered by disturbance pulses or single error events

Cycle time of memory tests (only 6DL3100-8AB/-8AC)	
RAM test: "stuck-at-zero" and "stuck-at-one" error check	24.5 s
Checksum of the program code in RAM	1.2 s
Checksum of the program code in FEPRAM	2.5 s
Note: In cyclic mode, the program code in RAM will be used	

Changeover of PROFIBUS DP channels	
Gaps when changing over between PROFIBUS DP channels	no changeover gap

Changeover gaps with module redundancy (only 6DL3100-8AB/-8AC)	
Changeover gap with functional redundant fiber optic connection	
Digital outputs	0 to 100 µs
Analog outputs	0 to 300 µs
Changeover gap due to missing or faulty redundant fiber optic connection ²⁾	
Digital and analog outputs	1-2 automation processor cycles + 2 PROFIBUS DP tokens + 1 AddFEM cycle

²⁾ If the redundant fiber optic connection fails, the AP determines the master / reserve assignment. Decisive factor is here the current error rating of the modules.

5 Commissioning, operation, maintenance

5

Section overview

Section	Contents	Page
5.1	Installing the AddFEM	5-2
5.2	Interconnection of the process signals	5-8
5.3	Operator control and display elements	5-17
5.4	Setting the PROFIBUS DP address	5-22
5.5	Resetting the AddFEM	5-30
5.6	Configuring the AddFEM	5-32
5.7	Troubleshooting	5-36

5.1 Installing the AddFEM

The brackets of the AddFEM are adaptable and are thus suitable for mounting the AddFEM module on DIN rail, or for wall-mounting.

Always secure the 24 V DC power supply and process cables on the strain relief.

Installation to DIN EN 61131-2

6DL3100-8AA/-8AB/-8AC is an “open equipment” according to DIN EN 61131–2 standard, and an “open type” according to UL/CSA certification.

In order to satisfy safety requirements with respect to mechanical strength, non-inflammability, stability and touch protection, the following installation options are mandatory:

- Installation in a suitable cabinet
- Installation in a suitable enclosure
- Certified only to DIN EN 61131-2:
Installation in a closed switch room with appropriate equipment.

 CAUTION
Danger of burns to hands from hot surface
Hot surface can cause burns
The temperature rise of the metal enclosure at full load is approximately 20 K. At an ambient temperature of 60 °C, the temperature limit of 70 °C is exceeded. This limit represents the maximum temperature up to which unprotected contact without risk of injury (according to DIN EN 61131-2) is possible.
Do not touch the enclosure without appropriate protective measures when the ambient temperature is > 50 °C.

Mounting options

Module mounting options:

- Mounting on double DIN rail (factory configuration)
- Direct screw-mounting on a wall

DIN rail mounting

The minimum clearance (measured center <-> center) between the top and bottom DIN rail is 165.1 mm (see the dimensional drawing for DIN rail mounting.) The minimum stiffness of the DIN rail structure must be sufficient to ensure safe fixation of the module. We therefore recommend the installation of rails to DIN EN 60715 (minimum material thickness: 2.2 mm), with a fastening pitch of less than 25 cm. DIN rails with a length of 19 inches should be bolted at the sides and in the middle.

How to mount the AddFEM on the rail:

- Place the top fastening strap onto the top of the rail, then "hang in" the module.
- Push the lower fastening element onto the bottom DIN rail.
- The lower fastening element is slotted at the level of the enclosure bottom. Insert a flat screwdriver into this slot at an angle, working from the bottom (see the dimensional drawing of rail mounting), then push the blade towards the floor panel of the enclosure. This counters the spring force of the clip and forces the clip down. You can now snap the AddFEM onto the lower DIN rail.
- Remove the screwdriver. The AddFEM is now safely secured.




Fig. 5-1 Dimensional drawing of the DIN rail mounting

Grounding the module enclosure


The module enclosure must be grounded to ensure EMC compatibility. It suffices to mount the module onto grounded DIN rails (DIN rail mounting) or a grounded mounting panel (screw mounting).

If suitable mounting elements are not available, the enclosure must be connected to ground separately at the grounding screw on the front panel below the module's power socket. This screw can be connected to a grounded cable.

Additional information on system installation with respect to lightning protection, grounding etc., refer to the SIMATIC PCS 7 documentation on the Internet e.g. "Automation System S7-400 Hardware and Installation"

Connecting the module power supply

The 24 V DC power supply is connected to the AddFEM using the dual-pole connector of the AddFEM connector set, order no. 6DL9900-8AA. At an ambient temperature of 60 °C, the terminal temperature may reach 70 °C (The cable insulation should thus be certified for a temperature 75 °C.)



M: Bezugspotential
L+: Einspeisung +24 V

Fig. 5-3 24 V DC module power supply

Always use solid wire or stranded wire with wire end ferrules to connect the module to the 24 V DC power supply (stripping length: 7 mm).

Tightening torque of the screw terminals of the connector:
0.5 N/m to 0.6 N/m

<p>⚠ WARNING</p> <p>Danger, high voltage</p> <p>May cause death or serious injury</p> <p>The 24 V DC module power supply must be a safety extra low voltage (SELV) which is safely isolated to mains. Safe electrical isolation may be implemented to VDE 0100 part 410, corresponding to HD 384.4.41 and IEC 60364-4-41 (as functional extra-low voltage with safe isolation PELV) or EN 60950-1, IEC 60950-1 (as safety extra low voltage SELV)</p>

Connecting the load voltage supply for digital outputs

AddFEM supplies the 24 V DC load voltage to the analog outputs. The 24 V DC load voltage for the digital outputs must be generated externally, and is wired to the X7 connectors.

Connecting the process cables

Cable type: Cables carrying analog signals must be shielded in order to achieve maximum protection against interference (see "Supplementary data on safety, environmental conditions and EMC "). You may use unshielded cables for the transfer of digital signals.

In accordance with the UL / CSA certification of the matching front connectors for sockets X4 to X7 (connectors with 10 screw terminals, AddFEM connector set, order no. 6DL9900–8AA), process signals may only be connected using solid copper wire or stranded wire with wire end ferrules (stripped length: 9 mm). At an ambient temperature of 60 °C, the temperature in the area of the terminals may reach 70 °C. The cable insulation should therefore be certified to withstand a temperature of 75 °C.

Tightening torque of the screws when connecting wires: 0.22 N/m to 0.25 N/m.

<p>⚠ WARNING</p> <p>Danger, high voltage</p> <p>Dangerous contact voltages caused by transients or incorrect connections may occur in the process and be transferred to the module by way of the connectors. These voltages may lead to death or serious injury in the event of contact.</p> <p>Contact by the user with these voltages is possible at the following locations:</p> <ul style="list-style-type: none"> • <i>Locking screws of process connectors:</i> Contact with the locking screws used to secure the cable cores to the process connectors is possible when attaching the cables or handling the connection plugs. • <i>Pins on the module front connector:</i> If the process connectors are only partially inserted onto the module front connectors, dangerous contact voltages may be transferred from the fully inserted pins to the still exposed pins via the module. <p>Keep the protective cover of the AddFEM closed during normal operation.</p> <p>If you open the protective cover, first disconnect the connection to the process or take suitable precautions to prevent contact with the open pins or locking screws.</p>

Cable strain relief

The AddFEM front panel is equipped with a strain relief rack made of metal which is used to secure the cables and wires using cable ties. You can remove this rack, including the cables and wires mounted to this rack, by loosening the two screws, and then mount it onto the replacement module.

Clamping the cable shielding

The shielding of cables carrying analog signals and of PROFIBUS DP cables should be clamped and grounded upstream of the terminals on the module. If the cables are not grounded until further downstream at the strain relief, any high-energy interference from the shielding will be discharged across the module enclosure, and thus impair the module's resistance to interference.

You may use unshielded cables for digital process signals.

5.2 Interconnection of the process signals

Socket pin assignment




Fig. 5-4 Process connector

Of the 12 analog inputs, 6 can be used as current or voltage input, while the remaining 6 can only be used as current input.

The 16 digital outputs can also be used as inputs.

Of the 15 digital inputs, 3 can be used as counter input for velocity monitoring with / without detection of the rotational direction. For velocity monitoring with detection of the rotational direction, count pulse input 1 detects the leading, and count pulse 2 the lagging signal.

Wiring the current and voltage inputs

Ground reference:

All analog input channels are configured as differential inputs. Thus, each channel has the + input signal on its own – input (ground of the individual channel). This makes it possible to interconnect the current inputs of two AddFEM in series for redundant current injection.

Please note, however, that such channel-specific grounding (each – input of the channel) to the analog ground of the analog potential island on which all analog circuits are located (output with pins 10 and 20 of connectors X4 and X5) may not have a difference in potential (the "common mode voltage") exceeding +/- 6 V (see, "Common-mode voltage" in Figure 5-8).

This should be ensured with a suitable connection of the input signal circuit to the analog ground. This may be at the encoder end (for example, for non-floating voltage encoder) or at the AddFEM end (recommended made for current encoders). See the details in the example circuits described below.

Note: If there is no ground reference, analog measurement can still work, because the common-mode voltage is limited by naturally existing contact resistance. With only high-impedance ground reference, however, the analog measurement may be sensitive against electromagnetic interference or electrostatic discharge.

Wiring current inputs singular/non-redundant




Fig. 5-5 Wiring current inputs (non-redundant)

Note on ground reference: If only current inputs are used, we recommend the ground reference between the – inputs and the analog ground at the AddFEM end. Note: Connection of the analog ground to the cabinet ground (dashed line) is not required for the AddFEM in this case and is not recommended. If the current encoder (transmitter) requires a connection to cabinet ground, this connection can be made there.

Wiring of current inputs in redundant configuration




Fig. 5-6 Wiring of current inputs (redundant wiring)

Note on the Z diode (shown in green): See Figure 5-7

Note on ground reference: If only current inputs are used, we recommend the ground reference between the – inputs and the analog ground at the AddFEM end. Note: Connection of the analog ground to the cabinet ground (dashed line) is not required for the AddFEM in this case and is not recommended. If the current encoder (transmitter) requires a connection to cabinet ground, this connection can be made there.

Selection of the Z diodes for redundant wiring of the current inputs

Z diodes with higher voltage generally have a smaller leakage current and thereby ensure compliance to accuracy.

Increasing voltage of the Z diodes, however, also increases the common mode voltage (voltage between – input and M analog of the AddFEM 1 in Figure 5-6) if an error occurs (AddFEM 2 is pulled in Figure 5-6), reducing the accuracy of the AddFEM with the pulled partner module (by -0.05% per V, see "Technical specifications" in section 4.1).

The best results (low voltage and good insulation) can be achieved if, instead of 2.7V Z diodes (for 20 mA inputs) or 3.3 V Z diodes (for 30 mA inputs), a serial connection of two or three special diodes is used in the flow direction.

We recommend the use of diode ZPD1 (or BZX55C0V8) each connected in series of two (~ 1.6 V) or three (~ 2.4 V), as shown in Figure 5-6:

Manufacturer:
Diotec Semiconductor AG
D-79423 Heitersheim, Germany




Fig. 5-7 Configuration of redundancy diodes for redundant power supply

Wiring voltage inputs and ground reference

If it is ensured that all encoders connected to a given AddFEM are floating, grounding for voltage inputs can take place similar to current inputs (5-5) at the AddFEM end. This is illustrated in Figure 5-8.




Fig. 5-8 Wiring voltage inputs with floating encoders

If voltage encoders already have a connection to an external ground wire for voltage signals, the configuration shown in Fig 5-9 should be made. To securely limit the common mode voltage (see figure), M analog of the AddFEM should be connected to the ground line, which is also connected to the voltage encoder (transmitter).




Fig. 5-9 Wiring voltage inputs to ground reference at encoder end

Mixed use of current and voltage inputs

With mixed allocation of the analog inputs with current and voltage sensors, we recommend to create the ground reference only for the current inputs at the AddFEM end.

The ground reference of the voltage producing transmitter should be made only at the encoder end. Otherwise, the ground lines for the voltage signals will connect with the ground lines for the current signals at the AddFEM. If the current producing transmitters are not configured as floating, this leads to compensating currents between the two ground systems (and to a loss of accuracy in the voltage signals).

Note: The central ground point of the system is used to ensure that the ground reference for voltage signals is connected at a single point to the mass for the current signals, so that the common mode voltage at the voltage inputs of AddFEM is not exceeded (see Figure 5-10).




Fig. 5-10 Wiring of AddFEM analog inputs with simultaneous use of current and voltage inputs

Interconnecting redundant IO

All analog and digital outputs of an AddFEM can be wired in parallel to outputs of the same type at another AddFEM for the redundant control of final control elements (see Figure 5-11).

This applies likewise to the analog voltage inputs and digital inputs.

See Figure 5-5 and Figure 5-6 for redundant interconnection of current inputs.

Note:

Redundant AddFEM must be supplied with absolutely symmetrical I/O signals. Individual channels can also be operated in non-redundancy mode and wired differently only with AddFEM PoCo Plus 6DL3100-8AC05 with extended redundancy design in redundant configuration.





I/O signal	Configuration variants
AI (analog input)	See Figure 5.6
AO (analog output)	
DI (digital input and velocity detection)	
DO (digital output)	
Legend:	

Fig. 5-11 Possible redundancy configurations

Redundancy characteristics of the analog outputs

The analog outputs of redundant AddFEMs can only be enabled or disabled on the AddFEM master. A 50%/50% load distribution between the master and reserve module is only possible for the control outputs with AddFEM PoCo 6DL3100-8AC02 and AddFEM PoCo Plus 6DL3100-8AC05.

Cabinet technology

You may install the AddFEM alongside with distributed IO devices or master processing units of the SIMATIC S7, SIMATIC PCS 7 or SIMADYN-D family in the same switch cabinet. Siemens has optimized its switch cabinet technology according to the special requirements of these system families.

The cabinets consist of system-specific and neutral modules which are compliant with CE standard, i.e. these are compliant with EMC Directives on electromagnetic compatibility. The cabinets safely prevent unauthorized access, and mechanical influences, contamination and corrosion.

Due to their modularity and variability, the cabinets can be easily adapted to satisfy requirements of diverse plant types and dimensions.

Your contact partner for the configuration and installation of customized system cabinets:

Siemens AG
Industry Sector Industry Automation Division
I IA CE SE PRM EN 1
Mr. Rieder
Phone: +49 721 595-2528
Fax: +49 721 595-4711
Siemensalle 84
D- 76181 Karlsruhe

Hardware maintenance

Faulty AddFEM modules cannot be repaired on-site, and must be shipped back to SIEMENS. Always keep the AddFEM dry when cleaning it.

Accessories (cables and connectors)

Add FEM connector set for process cable connections and module power supply (one set required per AddFEM), order no. 6DL9900-8AA.

The set consists of:

- 8 connectors, each with 10 screw terminals for wiring the process cables of a module to sockets X4 A/B to X7 A/B
- 1 connector, with 2 screw terminals, for wiring the 24 V DC power supply to the module

PROFIBUS DP cables and connectors for the AddFEM:

The current order numbers for these accessories are available either in the Siemens catalog "Industrial Communication", or on the Internet at

<http://www.automation.siemens.com/mcms/automation/en/industrial-communications/profibus/Pages/Default.aspx>

Fiber optic cable for the redundant connection (1 cable per redundancy pair)

Note: Only 6DL3100-8AC05 requires two cables per redundancy pair

Length: 1.6 m. Siemens order no.: 6DL9901-8AA

5.3 Operator control and display elements


Operator controls

All control and display elements of the AddFEM are located on the front panel above the protective cover.


The AddFEM can be operated by means of a key switch and slide switch on the front panel. The various switch positions are described below.




Normal operation – analog outputs enabled.
In this position you can remove the key in order to prevent any unauthorized change of the operating mode.




Outputs are disabled.
In redundant mode of the AddFEM, this forces a master / reserve changeover, i.e. the AddFEM is now the “reserve” module. You can set the PROFIBUS DP addresses and reset the AddFEM. In this position you can remove the key in this position in order to prevent any unauthorized change of the operating mode.



Key switch position, with momentary action function.
Required for setting up the PROFIBUS DP addresses.



Reserved for function expansions.
You cannot remove the key when it is in this position.




Position 0 – Spring-loaded momentary action:
The PROFIBUS DP addresses are indicated on the signal LEDs in binary code.
The display is activated for the duration of approx. three seconds.

Position 1 – latching position: home position

Position 2 – latching position: no function


LED



Three LED arrays above the key switch. Each with 4 LEDs for alarm (left) and status signals (right).

Operating states

D The “POWER ON” to “RUN ACTIVE” operating states described below are indicated by the status and error LEDs. The states are listed in the order of the module startup sequence.



Operating states:

POWER ON	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>RED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	RED		RES	STOP		RUN	<p>LED test After power on or reset, all error and status LEDs are switched on for the duration of approx. two seconds.</p>
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
RED		RES																		
STOP		RUN																		
INIT	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>RED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	RED		RES	STOP		RUN	<p>Initialization phase Functions executed by the AddFEM in this phase:</p> <ul style="list-style-type: none"> • Setup of hardware functions • Self-test • Wait state, approx. 4 seconds until PROFIBUS DP frames are received • Indication of the address currently set at PROFIBUS DP A (socket X3A) in binary format on the 16 signal LEDs for the digital inputs. <p>If any fatal errors occur, the AddFEM is reset to and set to “RESET” state</p>
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
RED		RES																		
STOP		RUN																		
STARTUP	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>ED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	ED		RES	STOP		RUN	<p>Startup phase The AddFEM locks in the startup phase if it does not receive any PROFIBUS DP frames., the reasons being:</p> <ul style="list-style-type: none"> • The PROFIBUS DP master is not ready yet • The PROFIBUS DP connector is missing or defective, or not terminated yet.
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
ED		RES																		
STOP		RUN																		
LOAD PARAMETER	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>RED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	RED		RES	STOP		RUN	<p>Configuration If the parameters required for the operation of the respective AddFEM variant are not transferred by HOST (PROFIBUS DP master), the AddFEM will remain in this phase. Possible reason:</p> <ul style="list-style-type: none"> • Incorrect or missing driver block (T3000 HW proxy or PCS 7 driver) • With PoCo Plus as of FEF revision 03, the module remains in this state if parameter values are outside the permissible range (TN, SETO_TIME1 or YPI_TIME2 > 262 seconds)
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
RED		RES																		
STOP		RUN																		
CONNECT PASSIVE	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>RED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	RED		RES	STOP		RUN	<p>Connecting to the redundancy partner - reserve The system synchronizes data with the redundant partner (i.e. between the redundant AddFEM and this module) via the redundant fiber optic cable connection. The module then goes into RUN PASSIVE state.</p>
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
RED		RES																		
STOP		RUN																		
CONNECT ACTIVE	<table border="0"> <tr><td>INTF</td><td></td><td>DISO</td></tr> <tr><td>EXTF</td><td></td><td>USR1</td></tr> <tr><td>BUSF1</td><td></td><td>SSA</td></tr> <tr><td>BUSF2</td><td></td><td>USR2</td></tr> <tr><td>RED</td><td></td><td>RES</td></tr> <tr><td>STOP</td><td></td><td>RUN</td></tr> </table>	INTF		DISO	EXTF		USR1	BUSF1		SSA	BUSF2		USR2	RED		RES	STOP		RUN	<p>Connecting to the redundancy partner – master The system synchronizes data with the redundant partner (i.e. data of the redundant AddFEM and this module) via the redundant fiber optic cable connection. The module then goes into RUN ACTIVE state.</p>
INTF		DISO																		
EXTF		USR1																		
BUSF1		SSA																		
BUSF2		USR2																		
RED		RES																		
STOP		RUN																		









































































<p style="text-align: center; border: 1px solid black; border-radius: 10px; padding: 5px; width: fit-content; margin: 0 auto;">RUN-PASSIVE</p>	<p>INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN</p>	<p>RUN state - reserve The module is the RESERVE station and receives update data from the master module via the redundant fiber optic cable connection. The outputs are disabled, i.e. the module does not output any analog signals.</p>
<p style="text-align: center; border: 1px solid black; border-radius: 10px; padding: 5px; width: fit-content; margin: 0 auto;">RUN-ACTIVE</p>	<p>INTF  DISO EXTF  USR1 BUSF  SSA BUSF  USR2 RED  RES STOP  RUN</p>	<p>RUN state – active The module is master and transfers update data to the reserve module via the redundant fiber optic cable connection.</p>
<p style="text-align: center; border: 1px solid black; border-radius: 10px; padding: 5px; width: fit-content; margin: 0 auto;">STOP</p>	<p>INTF  DISO EXTF  USR1 BUSF  SSA BUSF  USR2 RED  RES STOP  RUN</p>	<p>STOP state Can only be set using the key switch. The outputs are disabled, i.e. the module does not output any analog signals.</p> <p>In STOP state, you can set the bus address and reset the AddFEM using the control switches.</p>
<p style="text-align: center; border: 1px solid black; border-radius: 10px; padding: 5px; width: fit-content; margin: 0 auto;">INIT</p>	<p>INTF  DISO EXTF  USR1 BUSF  SSA BUSF  USR2 RED  RES STOP  RUN</p>	<p>INIT state The firmware found is incomplete and thus not executable. The module freezes in INIT state. All red error LEDs flash. The error may have been caused by a defective component or faulty firmware download.</p> <p>To correct or avoid error: Download the firmware again, or ship the module to Siemens for repair.</p>

Table 5-1 Display of operating states at the error/status LED

Display functions of the error and status LEDs

LED	Error class/status	Display	Cause
INTF	Internal error	INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	The automatic monitoring function has detected an internal error. The INTF LED is lit in case of <ul style="list-style-type: none"> • Memory error • Corrupted analog signal calibration data in memory.
EXTf	External error	INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	External errors The EXTf LED is lit in case of LED lights for: <ul style="list-style-type: none"> • Faulty process signal "Analog Out" • Faulty process signal "Analog In" • Faulty process signal "Digital Out" • 24 V DC load voltage missing at digital outputs
BUSF1	Bus error 1	INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	PROFIBUS DP interface A (X3A). The LED is statically set when ... <ul style="list-style-type: none"> • ...the master monitoring function has responded
		INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	The LED flashes if configuration errors are detected, i.e. ... <ul style="list-style-type: none"> • ..the parameter assignment frame contains illegal parameter values. • .. the parameter values received do not match the configuration of the redundancy partner
BUSF2	Bus error 2	INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	PROFIBUS DP interface B (X3B). The LED is statically set when ... <ul style="list-style-type: none"> • ...the master monitoring function has responded
		INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	The LED flashes when configuration errors are found, i.e. ... <ul style="list-style-type: none"> • ..the parameter assignment frame received contains illegal parameter values. • ..the parameter values received do not match the configuration of the redundancy partner
RED	Redundancy error	INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	Relevant only with redundant configuration of the AddFEM. The LED is lit... <ul style="list-style-type: none"> • ...if the fiber optic cable connection between the two redundant AddFEM modules has failed.
		INTF  DISO EXTf  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	The LED flashes... <ul style="list-style-type: none"> • if the configuration of the redundant AddFEMs is not consistent.











































STOP	Offline (Stop)	INTF  DISO EXTF  USR1  SSA  USR2 RED  RES STOP  RUN	The AddFEM is in STOP. The outputs are disabled. A master / reserve changeover of the redundant module is forced, i.e. the module is set to "forced reserve." In this state, you can also set the PROFIBUS DP addresses and reset the AddFEM.
DISO	Output disabled	INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	All outputs are disabled for the duration of commissioning or maintenance work. The AddFEM is in STOP, or in (passive) reserve state in redundant mode.
USR1	User status 1	INTF  DISO EXTF  USR1  SSA BUSF2  USR2 RED  RES STOP  RUN	USER LED 1 Can be used in the signal preparation function (FEF) for specific applications. For more, refer to information in the operating instructions of the respective AddFEM FEF variant. e.g. AddFEM PoCo Plus
SSA	Set Slave Address	INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	The LED is lit when you set the PROFIBUS DP addresses
USR2	Users status 2	INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	USER2 LED: Can be used in the signal preparation function (FEF) for specific applications. For more, refer to information in the operating instructions of the respective AddFEM FEF variant. e.g. AddFEM PoCo Plus
RES	AddFEM is standby	INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	AddFEM in standby
RUN	"Online" status	INTF  DISO EXTF  USR1 BUSF1  SSA BUSF2  USR2 RED  RES STOP  RUN	All functions can be executed

Table 5-2 Description of the error / status LEDs

Legend: ● LED is lit * LED is flashing

Note: If you do not find the displayed error state in Table 5-2, check Table 5-1 to find displays for the operating states in order to determine if the AddFEM has remained in the module startup phase due to another error.

Note

For EXTF error displays for redundant AddFEM. The EXTF LED indicates errors in the process output signals (analog outputs, digital outputs). The reserve module assumes the master function if a signal error is detected on the master module. The EXTF error display, (e.g. after a wire break at the analog output remains stored on the reserve module, however, and cannot be reset because reserve module no longer outputs signals and therefore cannot check the line status.

Refer to section 5.5 "Resetting errors with module redundancy" for the procedure for EXTF, if the display has been caused by an "Analog out" process signal error (e.g. wire break at an analog output) or "Digital out" process signal error (e.g. short circuit to ground).

5.4 Setting the PROFIBUS DP address

Each PROFIBUS DP node must be assigned a unique address which can be set in the number range "1" to "125." You can set the PROFIBUS DP address of your AddFEM using the key switch and slide switch, or in SIMATIC Manager. Both options are described below. For redundant PROFIBUS DP connections, it may be useful to assign the same address to both PROFIBUS DP of an AddFEM module. You may also set different addresses. Any address you assign will be written to the non-volatile memory area of AddFEM and is thus retained after power failure. When operating three to four AddFEMs on each PROFIBUS DP segment (typical configuration in turbine control systems), you should preferably assign addresses in the lower range, for example, "2", "3", "4" or "5", in order to simplify setup procedures.

5.4.1 Setting the address of PROFIBUS DP A using the key switch and slide switch

The next section describes how to set the addresses of PROFIBUS DP A and B. This setting is made with the help of the key switch and slide switch. The status LED returns the setup status. The signal LEDs temporarily indicates the set PROFIBUS DP addresses in binary format. The display is coded according to the tables below.

		PROFIBUS DP address A (X3A)							
		1	2	3	...	16	...	125	
LED „Digital Input“	1	X	-	X	...	-	...	X	
	2	-	X	X	...	-	...	-	
	3	-	-	-	...	-	...	X	
	4	-	-	-	...	-	...	X	
	5	-	-	-	...	X	...	X	
	6	-	-	-	...	-	...	X	
	7	-	-	-	...	-	...	X	
	8	-	-	-	...	-	...	X	

		PROFIBUS DP address B (X3B)							
		1	2	3	...	16	...	125	
LED „Digital Input“	9	X	-	X	...	-	...	X	
	10	-	X	X	...	-	...	-	
	11	-	-	-	...	-	...	X	
	12	-	-	-	...	-	...	X	
	13	-	-	-	...	X	...	X	
	14	-	-	-	...	-	...	X	
	15	-	-	-	...	-	...	X	
	16	-	-	-	...	-	...	X	

Legend: "-" = LED is dark
 "X" = LED is lit or flashes











Fig. 5-12 Operator controls of AddFEM and PROFIBUS DP address display

Setting the PROFIBUS DP address for bus A using the key switch and slide switch

No.	Action	Key switch and slide switch	Display	Step sequence
1	Preparing AddFEM for setup	<p>Turn the key switch to "STOP", set the slide switch to spring-action position</p> 	<p>Status LED "USR1" flashes</p>  <p>Status LED "USR1" flickers</p> 	<p>..wait until the status LED "USR1" flickers!</p> <p>Next, go to step 2...</p>
2	Function mode 1: Set PROFIBUS DP address for interface A (X3A).	<p>Release the slide switch. The slide switch returns to position 1 by spring force</p> 	<p>Status LED "SSA" flashes</p>  <p>The 16 signal LEDs for the digital inputs indicate the currently set addresses of DP A (left LEDs 1 to 8 flashing) and DP B (right LEDs 9 to 16 static) in binary representation.</p>	<p>Continue with step 3...</p>
3	Confirm function mode 1	<p>Turn the key switch to "MRES" and release it.</p> 	<p>Address is assigned the default value 1.</p> <p>Indication of the current address in accordance with row 2.</p>	<p>Continue with step 4...</p>
4	Set the address	<p>Set the relevant address in slide switch position "0". Each button action increments the address by the count of "1"</p>  <p>Press the slide switch longer than 3 seconds to increment the station address automatically.</p>	<p>Indication of the current address in accordance with row 2.</p>	<p>Hold the slide switch in position 0 until the address is set.</p> <p>Next, continue with step 5.</p>

Continued below!









No.	Action	Key switch and slide switch	Display	Step sequence
5	Confirm the new address.	Turn the key switch to "MRES", and then release it to save the new address. 	The 16 signal LEDs for the digital inputs indicate the new address statically for the duration of approx. three seconds.	Continue with step 6.
6	Set "RUN" mode	Set the key switch to "RUN" 		Settings are completed

Table 5-3 Setting the address of PROFIBUS DP A using the key switch and slide switch

5.4.2 Setting the address of PROFIBUS DP B using the key switch and slide switch

This section offers step-by-step instructions to commissioning and maintenance personnel for setting up the address of PROFIBUS DP B (connector X3B on the AddFEM) using the AddFEM operator controls (key switch and slide switch.).

Note: The procedure described below corresponds in essence with setup procedures for PROFIBUS DP A. However, in step 2, the user needs to press the slide switch once again in its 0 position 0 to set function mode 2, "Set DP address B."

No.	Action	Key switch and slide switch	Display	Step sequence
1	<p style="text-align: center;">↓</p> <p>Prepare the AddFEM for setup</p>	<p>Turn the key switch to "STOP", set the slide switch to spring position 0.</p> 	<p>Status LED "USR1" flashes</p>  <p>Status LED "USR1" flickers</p> 	<p>Wait until the status LED "USR1" flickers!</p> <p>Continue with step 2...</p>
2	<p>Function mode 2: Set PROFIBUS DP address for interface B (X3B).</p>	<p>Release the slide switch.</p> <p>The slide switch returns to position 1</p> <p>Press the slide switch once again in position 0 to set function mode 2!</p>   <p>Release the slide switch!</p>	<p>Status LED "SSA" flashes</p>  <p>The 16 signal LEDs for the digital inputs indicate the currently set addresses for DP A (left LEDs 1 to 8 static) and DP B (right LEDs 9 to 16 flashing) in binary representation.</p>	<p>Continue with step 3...</p>

Continued below!





No.	Action	Key switch and slide switch	Display	Step sequence
3	Confirm function mode 2	Turn the key switch to "MRES" and release it. 	Indication of the current address in accordance with row 2.	Continue with step 4...
4	Set the address	Set the relevant address in slide switch position "0". Each button action increments the address by the count of "1"  Press the slide switch longer than 3 seconds to increment the station address automatically.	Indication of the current address in accordance with row 2.	Hold the slide switch in position 0 until the address is set. Next, continue with step 5
5	Confirm the new address.	Turn the key switch to "MRES", and then release it to save the new address. 	The 16 signal LEDs for the digital inputs indicate the new address statically for the duration of approx. three seconds.	Continue with step 6.
6	Set "RUN" mode	Set the key switch to "RUN" 		Settings are completed

Table 5-4 Setting the address of PROFIBUS DP B using the key switch and slide switch

5.4.3 Verifying the PROFIBUS DP address setting

You can verify your settings of the PROFIBUS DP addresses in online mode. For procedures at the AddFEM, see the table below.



No.	Action	Key switch and slide switch	Display	Step sequence
1	View PROFIBUS DP addresses	<p>Key switch in "RUN" or "RUN P" position</p>  <p>Operate the slide switch in position 0 and then release it.</p> 	The 16 signal LEDs for the digital inputs indicate the new address statically for the duration of approx. three seconds	Settings are completed

Table 5-5 Verifying the PROFIBUS DP address settings

5.4.4 Resetting the AddFEM

Procedure for resetting the AddFEM:



No.	Action	Key switch and slide switch	Display	Step sequence
1	Reset the AddFEM	<p>Key switch to STOP" position</p>  <p>Hold the slide switch in 0 position for at least 10 seconds, then release it.</p> 	The ADDFEM will be reset on expiration of a delay time of approx. 10 s. After restart, all status LEDs will be switched on for the duration of approx. 1 s.	Settings are completed

Table 5-6 Resetting the AddFEM

5.4.5 Setting the PROFIBUS DP address in SIMATIC Manager

You may optionally use a SIMATIC programming device (PG) in preference of the key and slide switches described earlier to set the PROFIBUS DP addresses. The SSA frame (SSA : SET SLAVE ADDRESS) containing the new PROFIBUS DP address is here transferred to the AddFEM via PROFIBUS DP. Having received this frame, the AddFEM automatically saves the new address to its non-volatile memory area for reuse. This setting is made separately for PROFIBUS DP A and PROFIBUS DP B.

To set the PROFIBUS DP address, connect the PG (PG 740, PG 760 etc.) to the AddFEM by connecting an MPI patch cable to PROFIBUS DP interface X3A or X3B.

Run SIMATIC Manager, then select "PLC" -> "Assign PROFIBUS Address" to immediately assign a new address. The dialog box also indicates the old, current address.




Fig. 5-13 Assigning the PROFIBUS DP address in SIMATIC Manager

5.5 Resetting errors with module redundancy

External errors at the analog or digital outputs (for example, due to external wire break) cannot be reset by the reserve AddFEM after an error is cleared because the reserve AddFEM no longer outputs signals and therefore cannot check the line status. In order to restore the correct redundancy status after external error correction, these errors must be reset manually on the reserve module.

Use the procedure described below to do this.

Exception: Only applicable to 6DL3100-8AC05: the option now exists to use a T3000 driver command for online functional testing of analog outputs that were switched off due to errors and to restart these outputs without any disruption. For more information, see the manual for AddFEM PoCo Plus 6DL3100-8AC05

NOTICE

Master/reserve switchover is possible following deletion of the saved errors on the reserve AddFEM, in spite of the presence of output errors

If the saved errors on the reserve AddFEM are deleted, this module can initially assume the role of master AddFEM again despite the continued presence of other errors at the outputs.

Only after the reserve AddFEM (with deleted output errors) assumes the master role is it capable of checking the process execution, detecting pending errors of the outputs again, and responding to errors appropriately.

If the causes of the errors at the outputs have not been eliminated, the signal output may be incorrect or missing up until conclusion of the error check (duration: maximum of 12.66 ms for the analog outputs), which may lead to process disturbances.

You should therefore ensure that the cause of the error is eliminated before performing this procedure.

NOTICE

Processing of out-of-date error status in the event of a forced master/reserve switchover

A forced master/reserve switchover (e.g., by turning the key-operated switch on the master AddFEM to STOP) also causes the reserve AddFEM to check and correct the error status after it assumes the master role.

However, the higher-level drivers initially process the old error status still saved. As a result, corresponding reactions, e.g., switchover from automatic to manual for upstream controller blocks, may be triggered for a brief time. Depending on the configuration, the reactions may cause process disturbances.

Therefore, you should only use the procedure describe below.

No.	Action	Key switch and slide switch	Display	Step sequence
1	Initial situation		Module is reserve and EXTF is displayed 	Continue with step 2
2	Delete stored errors	Turn the key switch to "MRES" and hold. 	Status LED "USR1" flashes 	Hold key switch and wait until status LEDs "USR1" and "EXTF" are off (after about 2 sec.) Continue with step3
3	Errors are deleted after about 2 seconds	Release key switch 	Status LED "USR1" and "EXTF" are off 	Continue with step4
4	Set "RUN" mode.	Turn key switch to "RUN" 		Deletion of stored errors is complete

Table 5-7 Resetting errors

5.6 Configuring the AddFEM

The AddFEM is configured via PROFIBUS DP according to procedures defined in the PROFIBUS standard.

The CD supplied with your AddFEM contains a GSD file you can edit using the usual PROFIBUS configuration tools, such as HW-Config or COM-PROFIBUS. Based on this file, the configuration tool generates a master parameter data set. This set will be saved to memory in the automation processor (AP), and downloaded to the AddFEM within the initialization phase.

For further information, refer to the description of the configuration tool used.

For further information on using the GSD files, refer to "readme.pdf" on the AddFEM CD.

5.6.1 Adjustable parameters

Parameter	Range/Value	Remarks
Operating mode AddFEM	"Standard not redundant " "AS red., AddFEM not red. " "AS not red., AddFEM red. " "AS red., AddFEM red."	Mode 0 Mode 1 Mode 2 Mode 3 (see also section 3.3 "Operating modes")
Redundant AddFEM	"No redundant partner" "PROFIBS-Address: 1"	This parameter is available only with "SIMATIC PCS7" configuration. Default setting is "No redundant partner"
Input type/range AI 1 Input type/range AI 6	"Current 4...20 mA" "Current 0...20 mA" "Current +/-20 mA" "Current +/-30 mA" "Voltage +/-10 V" "Voltage 0...10 V"	The analog inputs 1 to 12 support channelselective adjustments. The analog inputs 1 to 6 can be programmed for operation as voltage or current input mode.
Input type/range AI 1 Input type/range AI 6	"Current 4...20 mA" "Current 0...20 mA" "Current +/-20 mA" "Current +/-30 mA"	Analog inputs 7 to 12 can only be use in current input mode.
Output type/range AO 1 Output type/range AO 8	"Current 4...20 mA" "Current 0...20 mA" "Current +/-20 mA" "Current +/-30 mA" "Current +/-50 mA"	The analog outputs 1 to 8 support channel selective adjustments. They are implemented for operation in current output mode Note: If the current range is set to +/- 50 mA, the analog outputs are limited to a mean load of 40 mA to protect the module. Please see technical specification: Analog outputs
Counter 1	"Ident. of rot. direction off" "Ident. of rot. direction on"	Counter 1 can be programmed for operation with or without detection of the rotational direction. If detection of the rotational direction is enabled, channel 1 returns the leading and channel 2 the lagging signal.
Filter AI 1 Filter AI 12	"No filter" "Filter 50 Hz" "Filter 60 Hz" "Filter 16 2/3 Hz" "Filter 500 Hz"	A filter function can be programmed for each analog input to suppress the relevant mains frequency. Sth system provides filters for 50 Hz, 60 Hz, 16 2/3 Hz and 500 Hz ¹⁾ . The filtering can be set individually for each analog input (channel-selective). Default setting is "No filter" i.e. disabled! ¹⁾ As of version 14 of 6DL3100-8AC
Delayed shutoff (if the host CPU becomes unavailable briefly. For details please see 0 "Delayed shutoff ")	"0 ms" "10 ms" "20 ms" "50 ms" "100 ms" "200 ms" "500 ms" (default) "1 s" "2 s" "3 s"	The AddFEM is capable of compensating short-term gaps in the execution cycle of the host CPU, for example, when the system updates redundant APs. A "hard" shutoff of the outputs is not carried out unless the set tolerance time has expired

Table 5-8 Adjustable parameters

5.6.2 Integration in automation systems

Siemens provides drivers and / or configurations for the integration of AddFEM in various host systems. Those drivers support the easy integration of AddFEM in different system environments. A description of this integration and of its configuration is available in the manuals and documentation of the relevant systems.

5.6.2.1 Overview of automation systems

System	CPU/PROFIBUS interface	AddFEM type	GSD	Comment
SPPA-T3000	S7 400 with internal on-board PROFIBUS interface or with CP443-5 EXT expansion module	6DL3100-8AC 6DL3100-8AC02 6DL3100-8AC03 6DL3100-8AC05	SiT680A3.GS? (Standard for SPPA-T3000)	GSD model name: AddFEM/SPPA-T3000 <ul style="list-style-type: none"> Suitable for hardware proxies on the SPPA-T3000 system Configuration of AddFEM in HW Config as "redundant standard slave" (automatic integration in redundant bus systems) is supported Diagnostics interrupts are supported No editable parameters – parameters are always assigned in acyclic DP-V1 jobs Front-End-Function: configurable PoCo, PoCo Plus and SoE
S7-400/FM458 TXP AS 620T	S7 400/FM458-1_DP with internal on-board PROFIBUS interface, with external EXM448 expansion module	6DL3100-8AC	SiF080A3.GS? (Standard for FM458)	GSD model name: AddFEM/FM458 <ul style="list-style-type: none"> Suitable for integration in the DP interface of FM458 Diagnostics interrupts are not supported Basic functionality (IO) + redundancy changeover of AddFEM with fiber optic connection Front-End-Function: not configurable
SIMATIC PCS7	S7 400 with internal on-board PROFIBUS interface or with CP443-5 EXT expansion module	6DL3100-8AC 6DL3100-8AC02 6DL3100-8AC03	Si0580A3.GS? (Standard for SIMATIC PCS 7)	GSD model name: AddFEM/PCS7/PARAM <ul style="list-style-type: none"> Suitable for PCS7 channel drivers Configuration of AddFEM in HW Config as "redundant standard slave" (automatic integration in redundant bus systems) is supported Diagnostics interrupts are supported Front-End-Function: configurable PoCo and SoE
TXP AS 620 B	SIMATIC S5 155H/ AS 620 B with PROFIBUS communications module	6DL3100-8AC	SiT080A3.GS? (Standard for TXP AS 620 B)	GSD model name: AddFEM/TXP S5 <ul style="list-style-type: none"> Suitable for integration in TXP S5 with IM308-C Diagnostics interrupts are not supported Front-End-Function: not configurable
SIMADYN D TXP AS 620 T	PM6 (PM5) with CS7 communications module, and SS52 communications module for the PROFIBUS DP interface	6DL3100-8AA	Si0180A3.GS?	GSD model name: Add FEM, Type -8AA Basic functionality (only IO)
		6DL3100-8AB	Si0280A3.GS?	GSD model name: Add FEM, Type -8AB Not for new projects!
S7-400/FM458 TXP AS 620T	S7 400/FM458 EXM448 expansion module for the PROFIBUS DP - interface	6DL3100-8AA	Si0180A3.GS?	GSD model name: Add FEM, Type -8AA Basic functionality (IO) + redundancy changeover of AddFEM with fiber optic connection
		6DL3100-8AB	Si0280A3.GS?	GSD model name: Add FEM, Type -8AB Not for new projects!

		6DL3100-8AC	SIF080A3.GS?	GSD model name: AddFEM/FM458 <ul style="list-style-type: none"> • Suitable for integration in the DP interface of FM458 • Diagnostics interrupts are not supported • Basic functionality (IO) + redundancy changeover of AddFEM with fiber optic connection • Front-End-Function: not configurable
--	--	-------------	--------------	---

Table 5-9 Overview of automation systems

5.6.2.2 Integration in SIMATIC PCS7

For information on the integration of AddFEM in SIMATIC PCS7, refer to the following documentation:

AddFEM
Getting Started – First steps in commissioning

SIMATIC_PCS7_Driver

The manuals are located on the AddFEM CD

5.6.2.3 Integration in SPPA-T3000

For information on the integration of AddFEM in SPPA-T3000, refer to the Online documentation of the system.

5.6.2.4 Integration in TELEPERM XP

For information on the integration of AddFEM in TXP, refer to this TXP documentation:

Manual

SPPA-T2000
(TELEPERM XP)
Automation system AS 620
Field bus

Release 8.1

Section 15 of this manual contains the operating instructions

Flexible Field device integration in TXP:

5.7 Troubleshooting

5.7.1 Failure and hot-swapping redundant AddFEMs

The decisive factor in ensuring uninterrupted operation of the AddFEM modules is their hot-swap capability.

Initial situation

Failure	Reaction of the AddFEM modules
An AddFEM fails	The partner module assumes the master function

Replacement requirements

With 6DL3100-8AC, different revisions are capable of redundancy (with the exception of revision 13).

The following should be noted for revision 13 only:

The module to be coupled with revision 13 must have the same revision or a later revision.

Procedure

NOTICE
<p>Undesired master/reserve switchover (when redundancy cable is inserted online)</p> <p>If the fiber optic redundancy connector is inserted while the reserve module is switched on and in RUN mode, this can cause multiple undesired master/reserve switchovers in the event that errors with equal error weight are pending on both modules (e.g., due to external faults in process signals connected to both modules).</p> <p>If the input signals for the master and reserve AddFEM differ only slightly, multiple switchover may cause a disturbance in the process execution.</p> <p>Therefore, you should always follow the described procedure for module replacement (see step 5 in Table 5-10).</p>

Step	What to do	Reaction of the AddFEM
1	Turn the key switch on the relevant module from RUN to STOP position	The partner module assumes the master function and changes to CONNECT_ACTIVE mode. (RES LED flashes)
2	Remove the fiber optic cable of the redundant connection ¹⁾	Both AddFEM modules signal an error in the redundant connection (RES LED is lit).
3	Disconnect the power supply	
4	Disconnect the process signal cables, then remove the module	
5	<ul style="list-style-type: none"> • Install the new module • Connect the process signal cables • Turn the key switch to STOP position • Connect the fiber optic cable of the redundant connection • Connect the power supply 	
6	Turn the key switch from STOP to RUN	The AddFEM modules automatically run the CONNECT routine. The new module assumes the reserve function

Table 5-10 Failure and hot-swapping AddFEM

¹⁾ If a redundant fiber optic connection is faulty or missing, the AP determines the master / reserve assignment based on the current error rating.

Appendix

A.1 Front connector pin assignment

Connector X4

Pin no.	Name	Function	Pin no.	Name	Function
1	NC	n.c.	11	NC	n.c.
2	S1+	Analog output channel 1	12	M1+	Analog input channel 1+
3	S2+	Analog output channel 2	13	M1-	Analog input channel 1-
4	S3+	Analog output channel 3	14	M2+	Analog input channel 2+
5	S4+	Analog output channel 4	15	M2-	Analog input channel 2-
6	S5+	Analog output channel 5	16	M3+	Analog input channel 3+
7	S6+	Analog output channel 6	17	M3-	Analog input channel 3-
8	S7+	Analog output channel 7	18	M4+	Analog input channel 4+
9	S8+	Analog output channel 8	19	M4-	Analog input channel 4-
10	M	Reference potential AO / AI	20	M	Reference potential AI

Connector X5

Pin no.	Name	Function	Pin no.	Name	Function
1	NC	n.c.	11	NC	n.c.
2	M5+	Analog input channel 5+	12	M9+	Analog input channel 9+
3	M5-	Analog input channel 5-	13	M9-	Analog input channel 9-
4	M6+	Analog input channel 6+	14	M10+	Analog input channel 10+
5	M6-	Analog input channel 6-	15	M10-	Analog input channel 10-
6	M7+	Analog input channel 7+	16	M11+	Analog input channel 11+
7	M7-	Analog input channel 7-	17	M11-	Analog input channel 11-
8	M8+	Analog input channel 8+	18	M12+	Analog input channel 12+
9	M8-	Analog input channel 8-	19	M12-	Analog input channel 12-
10	M	Reference potential AI	20	M	Reference potential AI

Connector X6

Pin no.	Name	Function	Pin no.	Name	Function
1	1N	Reference potential channels 1, 2, 3	11	3N	Reference potential channels 9,10,11,12
2	1	Counter/digital input channel 1	12	9	Digital input channel 9
3	2	Counter/digital input channel 2	13	10	Digital input channel 10
4	3	Counter/digital input channel 3	14	11	Digital input channel 11
5	NC	n.c.	15	12	Digital input channel 12
6	5	Digital input channel 5	16	13	Digital input channel 13
7	6	Digital input channel 6	17	14	Digital input channel 14
8	7	Digital input channel 7	18	15	Digital input channel 15
9	8	Digital input channel 8	19	16	Digital input channel 16
10	2N	Reference potential channels 5, 6, 7, 8	20	4N	Reference potential channels 13, 14, 15, 16

Connector X7

Pin no.	Name	Function	Pin no.	Name	Function
1	1L+	Power supply L+ channels 1 ... 8	11	2L+	Power supply L+ channels 9 ... 16
2	1	Digital output channel 1 or Digital input channel 17	12	9	Digital output channel 9 or Digital input channel 25
3	2	Digital output channel 2 or Digital input channel 18	13	10	Digital output channel 10 or Digital input channel 26
4	3	Digital output channel 3 or Digital input channel 19	14	11	Digital output channel 11 or Digital input channel 27
5	4	Digital output channel 4 or Digital input channel 20	15	12	Digital output channel 12 or Digital input channel 28
6	5	Digital output channel 5 or Digital input channel 21	16	13	Digital output channel 13 or Digital input channel 29
7	6	Digital output channel 6 or Digital input channel 22	17	14	Digital output channel 14 or Digital input channel 30
8	7	Digital output channel 7 or Digital input channel 23	18	15	Digital output channel 15 or Digital input channel 31
9	8	Digital output channel 8 or Digital input channel 24	19	16	Digital output channel 16 or Digital input channel 32
10	1M	Reference potential ch 1 ... 8	20	2M	Reference potential ch 9 ... 16

Note: The digital outputs can also be used as digital inputs. This is especially important for AddFEM SOE. If the connector pins are used for digital outputs, the values of the digital inputs continue to be read to monitor the signal status of the outputs.

A.2 EC Declaration of Conformity

SIEMENS

EG-Konformitätserklärung EC Declaration of Conformity

No. A5E00047256H DS02

Hersteller,
Manufacturer: Siemens AG, Industry, Industry Automation (I IA)

Anschrift,
Address: Würzburger Str. 121, D-90766 Fürth

Produkt-
bezeichnung:
Product description AddFEM 6DL3100-8Axxx.....
(Komponenten siehe Anhang)
(components refer to annex).....

Das bezeichnete Produkt stimmt in der von uns in Verkehr gebrachten Ausführung mit den Vorschriften folgender Europäischer Richtlinien überein:

The product described above in the form as delivered is in conformity with the provisions of the following European Directives:

2004/108/EG Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über die elektromagnetische Verträglichkeit

Council Directive on the approximation of the laws of the Member States relating to electromagnetic compatibility


Die Konformität mit den Richtlinien wird nachgewiesen durch die Einhaltung folgender Normen:
Conformity to the Directives is assured through the application of the following standards:

Referenznummer <i>Reference number</i>	Ausgabedatum <i>Edition</i>	Referenznummer <i>Reference number</i>	Ausgabedatum <i>Edition</i>
EN 61000-6-2	2005.....	EN 61000-6-4	2007
.....


Fürth, den / the 20.05.2011

Siemens Aktiengesellschaft

Dr. Ralf Michael Wagner
Head I IA CE SE.....
Name, Funktion
Name, function


Unterschrift
signature

Klaus Indefrey
Head I IA CE SE R&D.....
Name, Funktion
Name, function


Unterschrift
signature

Diese Erklärung bescheinigt die Übereinstimmung mit den genannten Richtlinien, ist jedoch keine Beschaffenheits- oder Haltbarkeitsgarantie nach §443 BGB. Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten.
This declaration certifies the conformity to the specified directives but contains no assurance of properties. The safety documentation accompanying the product shall be considered in detail.

Siemens Aktiengesellschaft: Chairman of the Supervisory Board: Gerhard Cromme; Managing Board: Peter Loescher, Chairman, President and Chief Executive Officer; Roland Busch, Brigitte Ederer, Klaus Helmrich, Joe Kaeser, Barbara Kux, Hermann Requardt, Siegfried Russwurm, Peter Y. Solmssen, Michael Suess;
Registered offices: Berlin and Munich, Germany; Commercial registries: Berlin Charlottenburg, HRB 12300, Munich, HRB 6684; WEEE-Reg.-No. DE 23691322



Anhang zur EG-Konformitätserklärung Annex to EC Declaration of Conformity

No. A5E00047256H DS02

Die Produktfamilie AddFEM 6DL3100-8Axxx, für die die CE-Kennzeichnung gilt, besteht aus folgenden Komponenten:

The AddFEM product family to which the CE marking applies with respect to 2004/108/EC consists of the following components:

6DL3100-8AA	AddFEM
6DL3100-8AB	AddFEM
6DL3100-8AC	AddFEM
6DL3100-8AC02	AddFEM PoCo
6DL3100-8AC03	AddFEM SoE
6DL3100-8AC04	AddFEM FSO
6DL3100-8AC05	AddFEM PoCo Plus

Siemens Aktiengesellschaft: Chairman of the Supervisory Board: Gerhard Cromme; Managing Board: Peter Loescher, Chairman, President and Chief Executive Officer; Roland Busch, Brigitte Ederer, Klaus Helmrich, Joe Kaeser, Barbara Kux, Hermann Requardt, Siegfried Russwurm, Peter Y. Solmssen, Michael Suess;
Registered offices: Berlin and Munich, Germany; Commercial registries: Berlin Charlottenburg, HRB 12300, Munich, HRB 6684; WEEE-Reg.-No. DE 23691322