## **SIEMENS**

Data sheet 3UG4617-2CR20



DIGITAL MONITORING RELAY FOR THREE-PHASE LINE VOLTAGE AUT. CORRECTION OF PHASE SEQUENCE PHASE FAILURE 3X 160 TO 690V AC 50 TO 60 HZ UNDERVOLT. AND OVERVOLT. 160-690V HYSTERESIS 1-20V OFF DELAY 0-20S 1 W FOR POWER SYSTEM FAULTS 1W FOR PHASE CORRECTION SPRING-LOADED TYPE

## Figure similar

| Product function  |   | Phase monitoring relay |  |
|---|---|------------------------|--|
| Measuring circuit:                                      |   |                        |  |
| Type of voltage for monitoring                          |   | AC                     |  |
| Number of poles for main current circuit                |   | 3                      |  |
| Measurable voltage at AC                                | V | 160 690                |  |
| Adjustable voltage range                                | V | 160 690                |  |
| Adjustable response delay time                          |   |                        |  |
| <ul> <li>with lower or upper limit violation</li> </ul> | s | 0.1 20                 |  |
| Relative setting accuracy                               | % | 0.2                    |  |
| Relative metering precision                             | % | 5                      |  |
| Accuracy of digital display                             |   | +/-1 digit             |  |
| Relative repeat accuracy                                | % | 1                      |  |
| General technical data:                                 |   |                        |  |
| Design of the display                                   |   | LCD                    |  |
| Display version LED                                     |   | No                     |  |
| Product function  |   |                        |  |
| <ul> <li>undervoltage detection</li> </ul>              |   | Yes                    |  |

| Overvoltage detection   |    | Yes   |
|---|----|---|
| <ul> <li>phase sequence recognition</li> </ul>  |    | Yes   |
| Phase failure detection   |    | Yes   |
| Phase unbalance   |    | Yes   |
| <ul> <li>Overvoltage detection 3 phase</li> </ul>   |    | Yes   |
| <ul> <li>undervoltage detection 3 phases</li> </ul>   |    | Yes   |
| <ul> <li>Voltage window recognition 3 phase</li> </ul>  |    | Yes   |
| Auto-reset  |    | Yes   |
| Adjustable open/closed-circuit current principle  |    | No  |
| Starting time after the control supply voltage has been applied   | ms | 1 000                                       |
| Response time maximum   | ms | 450   |
| Type of voltage of the control supply voltage   |    | AC  |
| Control supply voltage  |    |   |
| ● at AC   |    |   |
| — at 50 Hz rated value  | V  | 160 690                                     |
| — at 60 Hz rated value  | V  | 160 690                                     |
| Operating range factor control supply voltage rated value   |    |   |
| • at AC   |    |   |
| — at 50 Hz  |    | 11  |
| — at 60 Hz  |    | 1 1   |
| Surge voltage resistance rated value  | kV | 6   |
| Consumed active power   | W  | 2   |
| Protection class IP   |    | IP20  |
| Electromagnetic compatibility   |    | IEC 60947-1 / IEC 61000-6-2 / IEC 61000-6-4 |
| Vibration resistance acc. to IEC 60068-2-6  |    | 1 6 Hz: 15 mm, 6 500 Hz: 2g                 |
| Shock resistance acc. to IEC 60068-2-27   |    | sinusoidal half-wave 15g / 11 ms            |
| Installation altitude at height above sea level maximum   | m  | 2 000                                       |
| Conducted interference due to burst acc. to IEC 61000-4-4   |    | 2 kV  |
| Conducted interference due to conductor-earth surge acc. to IEC 61000-4-5                                     |    | 2 kV  |
| Conducted interference due to conductor-conductor surge acc. to IEC 61000-4-5                                 |    | 1 kV  |
| Electrostatic discharge acc. to IEC 61000-4-2   |    | 6 kV contact discharge / 8 kV air discharge |
| Field-bound parasitic coupling acc. to IEC 61000-4-3  |    | 10 V/m                                      |
| Insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value | V  | 690   |
| Degree of pollution   |    | 3   |
| Ambient temperature   |    |   |
| <ul><li>during operation</li></ul>  | °C | -25 +60                                     |

| <ul><li>during storage</li></ul>                                  | °C | -40 <b>+</b> 85 |
|---|----|-----------------|
| during transport  | °C | -40 +85         |
| Galvanic isolation  |    |                 |
| <ul> <li>between entrance and outlet</li> </ul>                   |    | Yes             |
| <ul><li>between the outputs</li></ul>                             |    | Yes             |
| <ul> <li>between the voltage supply and other circuits</li> </ul> |    | Yes             |

| chanical data:  fidth mm 22.5 eight mm 94 epth mm 91 ounting position any equired spacing for grounded parts  • forwards mm 0  • Backwards mm 0  • at the side mm 0  equired spacing with side-by-side mounting  • forwards mm 0  equired spacing with side-by-side mounting  • forwards mm 0  equired spacing with side mm 0  equired spacing with side mm 0  equired spacing with side mm 0  • Backwards mm 0  • at the side mm 0  • at the side mm 0  • downwards  • downwards  • downwards  • downwards  • downwards  • downwards  • at the side mm 0  equired spacing for live parts  • forwards mm 0  • Backwards mm 0  • at the side mm 0   |                     |
|--|---------------------|
| eight mm 94 epth mm 91 ounting position equired spacing for grounded parts  • forwards mm 0  • Backwards mm 0  • upwards mm 0  • downwards mm 0  • forwards mm 0  • at the side mm 0  • forwards mm 0  • backwards mm 0  • forwards mm 0  • at the side mm 0  • forwards mm 0  • at the side mm 0  • downwards mm 0  • downwards mm 0  • downwards mm 0  • downwards mm 0  • at the side mm 0  |                     |
| epth ounting position any equired spacing for grounded parts  • forwards   |                     |
| equired spacing for grounded parts  • forwards  • Backwards  • at the side  • upwards  • downwards  • forwards  • forwards  • downwards  • downwards  • forwards  • forwards  • forwards  • forwards  • Backwards  • at the side  • upwards  • forwards  • Backwards  • at the side  • upwards  • at the side  • upwards  • downwards  • at the side  • upwards  • downwards  • downwards  • downwards  • downwards  • at the side  • upwards  • at the side  • mm  0  • at the side   |                     |
| equired spacing for grounded parts  • forwards  • Backwards  • at the side  • upwards  • downwards  • forwards  • forwards  • at the side  • upwards  • forwards  • forwards  • at the side  • upwards  • forwards  • at the side  • upwards  • downwards  • downwards  • downwards  • at the side  • upwards  • forwards  • mm  0  • at the side  |                     |
| <ul> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>forwards</li> <li>at the side-by-side mounting</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>upwards</li> <li>downwards</li> <li>mm</li> <li>at the side</li> <li>upwards</li> <li>forwards</li> <li>mm</li> <li>at downwards</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>mm</li></ul>                         |                     |
| Backwards  at the side  upwards  downwards  downwards  forwards  Backwards  at the side  upwards  forwards  Backwards  at the side  upwards  forwards  at the side  forwards  mm  continuous                               |                     |
| <ul> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>equired spacing with side-by-side mounting</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>mm<td></td></li></ul>             |                     |
| <ul> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>equired spacing with side-by-side mounting</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>mm<td></td></li></ul>             |                     |
| <ul> <li>downwards</li> <li>downwards</li> <li>equired spacing with side-by-side mounting</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>forwards</li> <li>at the side</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>mm<!--</td--><td></td></li></ul> |                     |
| equired spacing with side-by-side mounting  • forwards  • Backwards  • at the side  • upwards  • downwards  • forwards  • forwards  • at the side  • mm  0  mm  0  equired spacing for live parts  • forwards  • Backwards  • at the side  • at the side  mm  0  mm  0  mm  0  mm  0  mm  0  |                     |
| <ul> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>forwards</li> <li>mm</li> <li>at the side</li> <li>mm</li> <li>mm</li></ul>                        |                     |
| <ul> <li>Backwards</li> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> </ul> mm  mm  mm  mm  mm  mm  mm  mm  mm  m  |                     |
| <ul> <li>at the side</li> <li>upwards</li> <li>downwards</li> <li>downwards</li> <li>forwards</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>mm</li> <li>m</li></ul>                   |                     |
| <ul> <li>upwards</li> <li>downwards</li> <li>equired spacing for live parts</li> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>o</li> </ul>  |                     |
| downwards     equired spacing for live parts     forwards     Backwards     at the side      mm     0      mm     0      mm     0      mm     0      mm     0  |                     |
| equired spacing for live parts  • forwards   |                     |
| <ul> <li>forwards</li> <li>Backwards</li> <li>at the side</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> </ul>   |                     |
| <ul> <li>Backwards</li> <li>at the side</li> <li>mm</li> <li>mm</li> <li>0</li> </ul>  |                     |
| • at the side mm 0   |                     |
|  |                     |
| • upwards mm 0   |                     |
|  |                     |
| • downwards mm 0   |                     |
| ounting type snap  | o-on mounting       |
| roduct function removable terminal for auxiliary and Yes ontrol circuit  |                     |
| /pe of electrical connection sprin   | ng-loaded terminals |
| /pe of connectable conductor cross-sections  |                     |
| • solid 2x (0  | ).25 1.5 mm²)       |
| • finely stranded  |                     |
| — with core end processing 2 x (0  | 0.25 1.5 mm²)       |
| — without core end processing 2x (0)   | 0.25 1.5 mm²)       |
| at AWG conductors  |                     |
| — solid 2x (2  | 24 16)              |
| — stranded 2x (2   |                     |

| Outputs:  |     |            |
|---|-----|------------|
| Number of NO contacts delayed switching                           |     | 0          |
| Number of NC contacts delayed switching                           |     | 0          |
| Number of CO contacts delayed switching                           |     | 2          |
| Ampacity of the output relay                                      |     |            |
| ● at AC-15  |     |            |
| — at 250 V at 50/60 Hz  | Α   | 3          |
| — at 400 V at 50/60 Hz  | Α   | 3          |
| • at DC-13  |     |            |
| — at 24 V   | Α   | 1          |
| — at 125 V  | Α   | 0.2        |
| — at 250 V  | Α   | 0.1        |
| Thermal current of the switching element with                     | Α   | 5          |
| contacts maximum  |     |            |
| Operating current at 17 V minimum                                 | mA  | 5          |
| Continuous current of the DIAZED fuse link of the output relay    | Α   | 4          |
| Mechanical service life (switching cycles) typical                |     | 10 000 000 |
| Electrical endurance (switching cycles) at AC-15 at 230 V typical |     | 100 000    |
| Operating frequency with 3RT2 contactor maximum                   | 1/h | 5 000      |

## Certificates/ approvals:

General Product Approval EMC Declaration of Conformity Certificates











Type Test
Certificates/Test
Report

| Test<br>Certificates     | Shipping<br>Approval | other        | Railway             |
|--------------------------|----------------------|--------------|---------------------|
| Special Test Certificate | Lloyd's<br>Register  | Confirmation | Vibration and Shock |

## Further informatior

Information- and Downloadcenter (Catalogs, Brochures,...)

LRS

http://www.siemens.com/industrial-controls/catalogs


Industry Mall (Online ordering system)


http://www.siemens.com/industrymall

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3UG4617-2CR20

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) <a href="http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3UG4617-2CR20&lang=en">http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3UG4617-2CR20&lang=en</a>





08/12/2017 last modified: